



Sustainment Management System Support

[Knowledgebase](#) > [BUILDER](#) > [Frequently Asked Questions](#) > [What if the building is going to get Demolished, Transferred or Vacant?](#)

What if the building is going to get Demolished, Transferred or Vacant?

Paul Paisley - 2020-08-31 - [Comments \(0\)](#) - [Frequently Asked Questions](#)

Question:

What if the building is going to be demolished, transferred, or vacant?

Answer:

If the building's "Current Status" changes from Active to any of the following:

- Demolished,
- To be acquired,
- To be built,
- To be demolished,
- To be transferred, or
- Vacant

You can designate this change by selecting the building, going to the General Info tab on the right-side pane of the page and selecting from the drop down menu under Current Status.

See attachment for more information of where this drop-down menu is located.

The screenshot shows the BUILDER software interface. On the left is a tree view of the inventory. The main pane is titled 'General Info' and contains various fields for building information. A red box highlights the 'Current Status' dropdown menu, which is currently set to 'Active'. The dropdown options are: Active, Demolished, To be acquired, To be built, To be demolished, To be transferred, and Vacant. Other fields visible include Building No. (000), Building Name (WHSE SUP AND EQUIP BSE), Building Use (442758 - WAREHOUSE SUPPLY AND EQUIPMENT BASE), and a table for Condition metrics (BCI, BFI, BPI, FCI) with values (70, 100, 100, 100). There are also checkboxes for 'Check box to override automated updates and manually enter replacement cost' and 'Check box to override automated updates and manually enter FCI'.

- Tags
- [acquired](#)
- [Building](#)
- [built](#)
- [Current Status](#)
- [Demolished](#)
- [Facility](#)
- [General Info](#)

- [Status](#)
- [transferred](#)
- [vacant](#)