

BUILDER™ Inventory Guide

Version 3.5.2

September 4, 2019

Disclaimers and Restrictions

Disclaimer



This program is furnished by the U.S. Army Corps of Engineers Engineering Research and Development Center - Construction Engineering Research Laboratory (ERDC-CERL) and is accepted and used by the recipient with the express understanding that the United States Government, the U.S. Army Corps of Engineers, and ERDC-CERL make no warranties, expressed or implied, concerning the accuracy, completeness, reliability, usability, or suitability for any particular purpose of the information and data contained in this program or furnished in connection therewith, and the United States shall be under no liability whatsoever to any person by reason of any use made thereof. This program is a property of ERDC-CERL. The recipient agrees not to assert any proprietary rights therein or to represent this program to anyone as other than a government property; furthermore, this program can only be copied for legitimate backup purposes by the user.

Hold-Harmless Statement

ERDC-CERL makes no guarantee as to the precision of the predictive elements of the BUILDER™ or ROOFER™ software. ERDC-CERL shall not be held responsible for damages or losses which are due to facility mismanagement decisions based upon predicted outcomes of facility asset performance from the BUILDER™ or ROOFER™ software.

Information Re-Use Restrictions

End Users are strictly forbidden from re-using any information from the BUILDER™ or ROOFER™ system (compiled code or stored data) to provide similar capabilities in other tools. End Users may use the report outputs and may access their own inventory data, as stored in the database, to facilitate their own organization's business management practices. Any other use of or access to the data is strictly forbidden.

Copyright Warning

The computer program described in this documentation is protected by copyright law and international treaties. Unauthorized reproduction or distribution of the program, or any portion of it, may result in severe civil and criminal penalties, and will be prosecuted to the maximum extent possible under the law.

Protected by the following U.S. Patents: 7,058,544; 7,734,488; 7,769,568.

Documentation Copyright ©2019 US Army Corps of Engineers (USACE). All rights reserved.

Table of Contents

Welcome to BUILDER™	4
Using this Guide	5
Prerequisite	5
Companion Guides	5
What's New in BUILDER 3.5	6
New Features Introduced in BUILDER 3.5.0	6
BUILDER 3.5.0 Bug Fixes	8
BUILDER 3.5.2 Documentation	8
Introduction to Inventory	9
Planning Inventory	9
Inventory Rollup	12
Working with Organizations	15
Organization Tasks	15
Add an Organization	16
Edit Organization Inventory Data	19
Delete an Organization	23
Working with Sites	25
The Importance of Geography to the Site Level	25
Site-Level Properties	25
Property Inheritance	26
Site Tasks	26
Add a Site	26
Edit Site Inventory Data	29
Delete a Site	38
Working with Complexes	39
Grouping Buildings into Complexes	39
Complex Tasks	39
Add a Complex	40
Edit Complex Inventory Data	45

Delete a Complex	51
Working with Buildings	53
Building Information	53
Building Tasks	54
Add a Building	55
Edit Building General Information	59
Edit Additional Building Inventory Data	64
Delete a Building	70
About the Mission Dependency Index	72
About the Building Current Status Property	72
Use Current Status to Track Non-Current Inventory	75
About Identifying Systems, Components and Sections	78
Defining Systems	78
Defining Components	78
Defining Sections	79
Inventory Suggestions	80
BUILDER Systems and Components	83
Working with Systems	86
Add, View, or Delete a System	86
Working with Components	95
Add, View, or Delete a Component	95
Working with Sections	104
Add, Edit, or Delete a Section	104
The Effect of the "Estimated" Checkbox for a Component-Section	116
Working with Section Details	119
Add, Edit, or Delete Section Details	119
Remote Inspection and Inventory Entry Using BuilderRED	128
What is BuilderRED?	128
Collecting Inventory Data	128
Performing Inspections	128
Export Data to BuilderRED	128

Import Data from BuilderRED to BUILDER	138
Working with Rapid Inventory Methods	143
Method Availability	143
List of Rapid Inventory Methods	144
Copy Inventory to Another Building	145
Copy Sections	147
Building Templates	149
Working with Building Templates	150
About Creating a Template	151
About Managing the Template Library	152
About Using a Template to Create Inventory	152
Building Template Tasks	152
Add Building Inventory Using a Template	153
Import a Building Template	160
Copy Building Inventory to a Template	163
Add a Building Template	165
Edit Building Template Data	173
Delete a Building Template	180
Manage the Template Library	181
Export a Building Template	183
Reports	186
Generate a Report	186
Export a Report	188
APPENDIX A: About Rollup	190
Automated Rollup	190
Appendix B: Facility Condition Index	192
Definition of \$current repair needs	192
Glossary	193
Index	201

Welcome to BUILDER™

BUILDER, part of the Sustainment Management System, provides facility managers with the tools needed to generate the greatest impact from maintenance and rehabilitation activities, and to plan and defend maintenance budgets.

The primary measure used in BUILDER is the *condition index* (CI) rating, using a 0-to-100 point scale. After real property inventory has been subdivided into hierarchical levels of increasing fineness, down to the Component-Section level, the condition index for each Component-Section is computed from inspection data that records the type, severity, and density of each distress found.

Deterioration curves, developed from experience over time, show the optimal point at which work should be done to avoid more costly rehabilitation projects later.

Another measure available in BUILDER is the *functionality index* (FI), also on a 0-to-100 point scale in keeping with the SMS design philosophy. It is computed from assessment data that records the functionality issues present in a building. Based on the severity and density of those issues, building modernization requirements can be identified.

Based on condition index and/or functionality index scores, BUILDER can generate recommended work items automatically. Using cost books associated with BUILDER, cost estimates are attached to the work items. Managers can then choose which work items to fund. The cost of *not* funding work items can be determined using Scenarios.

With the assistance of the Scenarios simulation engine included as part of BUILDER, managers can develop long-range work plans based on a sound investment strategy. By providing an objective description of condition (a core BUILDER functionality) and an automated means of exploring various options under different budget scenarios (Scenarios), BUILDER and Scenarios together make multi-year work plans easier to formulate and funding requests easier to justify. The goal is optimal facility performance for the dollars invested.

For information, announcements, links to documents, and discussion forums, visit the SMS community user's group website at <https://www.sms.erdcdren.mil>.



Developed by U.S. Army ERDC-CERL
9/4/2019

Using this Guide

This guide explains how to create and maintain real property inventory in the Sustainment Management System with BUILDER™.

Prerequisite

This guide assumes that you are already familiar with the material in the *BUILDER™ Getting Started Guide*, which can be downloaded from the user support site.

Companion Guides

At the user support site you should be able to download the following user guides to assist with additional tasks:

- *BUILDER™ Condition Assessment Guide*
- *BUILDER™ Work Configuration Guide*
- *BUILDER™ Reference Data Guide*

What's New in BUILDER 3.5

This topic describes changes made in BUILDER Version 3.5.

New Features Introduced in BUILDER 3.5.0

Inventory Improvement

- **Component-Section Status Tracking.** Users can assign a status to individual Component-Sections. Note: In this release, business processes such as work generation, rollups, and inclusion in the navigation tree are unaffected by Component-Section status; however, the design implemented allows for expanding this capability to alter business processes at a later date.
- **Custom Configuration of Building Templates.** BUILDER Administrators can configure the allowable maximum percent difference in square footage between a building template and the building it is to be applied to. Previously the percentage was fixed at 10%.
- **Building Summary Screen Additions and Alterations.** New to the Building summary screen:
 1. Building renovation year (last year renovated)
 2. A series of checkboxes to indicate that the Building does not contain one or more of the following Systems: Plumbing; Fire Suppression; HVAC; Electrical
 3. A checklist to indicate that the Building cannot be inspected for one or more of the following reasons: not accessible; locked; secure building (escort required); under renovation.
 4. Building Status now allows some simultaneous selections through use of a second, auxiliary field.
- **Local / Selective Inventory Unlock.** This feature allows users to select particular facilities or systems to be unlocked, instead of the former “all or nothing” approach. This granular “un-locking” ability is located under **Tools > Unlock My Buildings**.

Scenarios

- **Multi-Year Scenario Work Item Tracking.** As BUILDER customers begin to incorporate Scenarios and work plans into their standard practices, there are year-to-year overlaps in planning and execution that require additional functionality in the application. The process and construction time that can be associated with a BUILDER work item often drags a work item execution year out from the generation year. The Scenarios module now provides the

option to not re-generate Work Items with statuses indicating that funds have been allocated. This will simplify the work and budget projections as Scenarios will no longer be counting work items that have been addressed via previous funding streams.

- **POM Scenarios.** Scenarios Work Generation in Support of Program Objectives Memorandum (POM) is a new feature that allows BUILDER users to set FCI targets for their facilities as a part of their Scenario configuration. This allows Scenarios to output the funding required to meet those FCI targets, in addition to the recommended work actions. To do this, FCI targets can be established alongside work configuration Policy settings. BUILDER Scenarios generates the recommended work candidates based on the user's work configuration settings (Policy Sequences / Prioritization) and then begins "funding" work items for each facility in priority order until the FCI target is achieved. The output is a list of work items that need to be accomplished in order to meet the target FCI.
- **BUILDER Scenarios Screen Refresh.** The Microsoft Silverlight technology used to refresh BUILDER's Scenario module a few years ago is no longer supported by multiple browsers. In order to ensure continued support and access to BUILDER Scenarios, Silverlight has been replaced using Angular technology allowing for cross-browser functionality.
- **API Coverage for Scenarios.** The BUILDER web-service API has been expanded to allow privileged users to create, configure, edit, and delete Scenarios through web-based API calls.

Cost Modifiers

Users can create custom cost modifiers (adders and multipliers) that can be specified for a given BUILDER hierarchy level (Site, Building, Component-Section, etc.), and users can apply those modifiers to the specific instances that they apply to. This gives increased granularity to apply cost modifiers where they are required without over-applying them.

Functionality Assessment

- A new convenience enables assessors to select the image button for a question, take a picture with their tablet camera, and immediately attach a photo to the question.
- Users now have the ability to crop and cancel pictures.

Catalog Improvement Package (Reference Books, etc.)

- **Service Life Book Improvements** – Data fields have been added to the BUILDER database for tracking BUILDER component section service life performance; average, max, min, standard deviation, etc. This will allow

easier tracking of performance trends and ultimately refined life-cycle models.

- **Revised Data Structure for Cost Storage** – Data fields have been added to the BUILDER database to allow for seamless integration with third party cost data sources. This includes the ability to name the source of a given cost book as well as link the cost record entries to a third party reference identification number.
- **Reference Book Import/Export capability** – This addition allows BUILDER users to export custom cost books to an excel sheet that can then be edited and re-imported to BUILDER for more rapid cost record updating.
- **Editable Component Importance Indexes (CII) Values** – The data storage method utilized by BUILDER's cost and service life books has been applied to the Component Importance Indexes, allowing users to create custom CII Books in the same way as cost and service life books.

BUILDER Auditing Expansion

BUILDER's auditing capability has been expanded, allowing database administrators to track critical additions, edits or deletions made during users' work planning and work configuration tasks. For details, see the BUILDER 3.5.0 release notes.

BUILDER API Expansion

- **Electronic Acceptance of Cost Data.** The BUILDER web-service API has been expanded to allow privileged users to modify BUILDER cost book information and records via web-based API calls. This allows for more seamless integration with third-party cost sources as updates can be configured to be an automated back-end process.
- **Scenario API Additions.** The BUILDER web-service API has been expanded to allow privileged users to create, configure, edit, and delete Scenarios through web-based API calls.

BUILDER 3.5.0 Bug Fixes

For a list of bug fixes, please see the release notes.

BUILDER 3.5.2 Documentation

In the inventory topic ["BUILDER Systems and Components" on page 83](#), the table showing UNIFORMAT II Levels 2 and 3 (corresponding to BUILDER Systems and Components) has been expanded and revised to reflect BUILDER's conformance with the NAVFAC version of UNIFORMAT II.

Introduction to Inventory

Planning Inventory

This topic

- Provides valuable advice about how to plan the organizational structure of your inventory.
 - Provides links to features that can potentially help streamline the inventory process.
-

Your BUILDER™ inventory serves as the foundation for all that you will do with the BUILDER application. The first steps in using BUILDER are (1) to plan the hierarchical asset "tree" describing the physical inventory you manage (the subject of this topic) and (2) to construct the upper levels of that tree. The next step is to perform inventory to fill the database represented by that hierarchical tree.

The process of putting initial data into BUILDER will probably be your single most intensive effort in working with the program, but it is a one-time effort that can be aided by features described in the section on [Rapid Inventory Methods](#).

Tip: Crucial to the planning process for a new implementation of BUILDER is the issue of who decides the scope and organization of the hierarchical asset tree. It is recommended that this high-level planning step—determining the scope and organization of the tree—not be contracted out, even if "filling in" the asset tree at the lower levels (Buildings or Complexes and below) will be performed by contractors. A useful planning guidance document for government agencies and their contractors is ERDC/CERL Special Report 16-3, *BUILDER™ Sustainment Management System Implementation Planning Guide*.

Planning the Organizational Structure

Organization Level

Because the most convenient approach is to build out the BUILDER asset tree from the top down, if you are introducing BUILDER for the first time and creating the tree structure for your real property data, it is preferable to analyze in advance the final scope anticipated for entry and management of properties, and to create the Organization levels that will be needed in the long run even if they will not be filled with content in the short run.

Organizations are unique in the BUILDER hierarchy in that they can be nested multiple levels deep if desired. Note, however, that this flexibility brings with it the responsibility for careful planning.

Site Level

Begin by grouping your Buildings into logical management units, typically by their geographic regions, which are represented by [Site records](#) in the BUILDER database. The Site provides a natural way to group Buildings and to apply properties that are regional in nature, such as the cost of operations and maintenance (O&M) work and the heating, ventilation and cooling (HVAC) climate.

Building Level

Next, [create Building records](#) for the Buildings at one of your Sites. A Building record includes critical information such as how the Building is used, its size, age, and number of floors. You will find that BUILDER also allows you to store, at your option, a variety of other information about a Building, such as whether it is a historical structure or a whether it is a child-occupied facility. You will also have the option to establish a [Mission Dependency Index](#) to measure quantitatively how critical the Building is to the mission for which it is used.

Complex Level

Conceptually, the Complex level in the BUILDER hierarchy comes between the Site level and the Building level. However, unlike a Site, a Complex for organizing Buildings is *optional*, and a Complex is often not created until after its constituent Buildings (or at least some of them) have been added to BUILDER.

System Level

After establishing the Building level, you begin working down toward the end level of Component-Sections hierarchically, starting with the major Systems of a Building. The Systems in BUILDER are specified by the UNIFORMAT II Classification for Building Elements (Level 2), as shown in [BUILDER Systems and Components](#).

You will create the Building's Systems by selecting each applicable System from a dropdown pick list. See [BUILDER Systems and Components](#) for a list of available Systems.

For advice on how best to allocate inventory into Systems, Components, and Sections, see ["About Identifying Systems, Components and Sections" on page 78](#).

Component Level

Each System is further decomposed into Components (UNIFORMAT Level 3 elements). Again, you will create the Component records by selecting from a pick list of Components applicable to a given System. The topic [BUILDER Systems and Components](#) shows a selection of typical Components for some of the BUILDER Systems.

Component-Section Level

Creating the Component-Section ("Section") records is the most difficult and time-consuming aspect of creating the BUILDER inventory

After creating records for at least one System and at least one Component in a System, you are ready to add records that describe the individual physical items in the Building: the doors, walls, windows, plumbing fixtures, heating units, etc. These items are called Component-Sections, or simply Sections.

Component-Sections are the management unit in BUILDER. You inspect them and plan work for them, and BUILDER applies its condition assessment algorithms to them in calculating their condition index.

BUILDER uses embedded data and automated processes to determine a wealth of information about each Component-Section: its expected service life, its likely subcomponents and how its condition affects the Section as a whole, and the cost of replacing, painting, repairing, and removing it. As you might imagine, for an automated system to be able to do all of this, there are some strict rules about how you define Component-Sections.

A Component-Section consists of items that meet all of these criteria:

- All belong to the same Component.
- All are of the same Component type.
- All are of the same material/equipment category.

For example, in the Component "Exterior Doors," glass personnel doors and metal overhead doors belong in different Sections.

As long as the requirement for not mingling (a) types or (b) material/equipment category in the same Component-Section is met, you will have considerable flexibility in how you group similar items together to form a Component-Section. For example, wood doors on different sides of the Building could be grouped together. Alternatively, if weather degradation based on compass orientation is a significant factor, then west doors, north doors, etc. might be assigned to separate Component-Sections.

Once a Component-Section has been identified by (1) Component type and (2) material/equipment category, BUILDER will have sufficient information to establish a clear link between the Section (Component-Section) and the embedded data and computations that BUILDER brings to the process in order to help you with your management tasks.

Additional Guidance

Details, examples, and some suggestions about how to undertake the process of completing your BUILDER inventory are contained in the topic [Identifying Systems, Components and Sections](#).

Inventory Rollup

Plant replacement value and remaining service life are inventory-related pieces of information that are aggregated upwards through the inventory tree by use of a "rollup." This topic introduces both automated and manual rollups in BUILDER.

Only inventory-related processes performed by a rollup are explained here. Condition and functionality information aggregated by a rollup are explained elsewhere in the documentation.

What does a Rollup Do?

Inventory-related processes accomplished by a rollup are as follows:

- The current remaining service life (RSL) is estimated for all Sections.
- RSL information is reflected upwards through the inventory tree.
- Plant Replacement Value (PRV) is updated at all levels. For example, if new Sections, Components, or Systems have been added to a Building, its PRV will increase.

To see a full list of all rollup processes, not just those pertaining to inventory, see ["APPENDIX A: About Rollup" on page 190](#)

Automated Rollup

BUILDER automatically "rolls up" inventory, condition, and functionality information nightly. (For installations with U.S. Army Corps of Engineers support service, this begins at about 6:00 p.m.). Starting at the Section level, aggregated Section-level information in each Component is recorded for the Component; aggregated Component-level information is recorded for each System; aggregated System-level information is recorded for each Building, and so forth up the entire inventory tree.

Manual Rollup

You can manually initiate a rollup if you wish. It's a good idea to do so when:


- You have entered a large quantity of inventory into BUILDER; or
- You believe that PRV or RSL information has changed since the last automated rollup and you wish to see the latest values.

Roll Up a Building

To roll up a Building,

1. Navigate to the Building in the inventory tree.
2. Right-click.
3. Select "Rollup Building" from the list of options.

While the rollup is being performed, a popup window similar to the one below will be displayed onscreen:




Roll Up a Complex

To roll up a Complex,

1. Navigate to the Complex in the inventory tree.
2. Right-click.
3. Select "Rollup Complex" from the list of options.

While the rollup is being performed, a popup window similar to the one below will be displayed onscreen:




Roll Up a Site

Caution: Rolling up an entire Site can take an extremely long time (sometimes hours). If you initiate this rollup and want to cancel it, the only way to do this is to activate the "X" at the upper right of your browser window to close the window. Then log back into BUILDER from another browser window.

To roll up a Site,

1. Navigate to the Site in the inventory tree.
2. Right-click.
3. Select "Rollup Site" from the list of options.

While the rollup is being performed, a popup window similar to the one below will be displayed onscreen:



Full Rollup

If you have Administrator permission in BUILDER, you can initiate a manual rollup of the entire asset tree by selecting **Tools > Administration > Manual Condition Rollup** from the main menu. See the BUILDER Administration section of the documentation for instructions and screen shots.

Working with Organizations

An Organization is the highest level possible in the hierarchical asset tree. This topic briefly introduces the features of an Organization, and how to use it in organizing real property inventory. It also provides links to the operations that can be performed at the Organization level.

Organization is the highest level in the asset tree. (The tree may be referred to generically as the asset tree, or specifically as the inventory tree, condition tree, or functionality tree when performing tasks in one of those areas.) Tasks performed at the Organization level are generally prioritization, planning, and budgeting, rather than day-to-day management.

The Organization level in the BUILDER hierarchy is an optional level above the Site level, enabling progressive aggregation of information up the inventory tree. Progressive aggregation is possible because unlike other levels in the BUILDER hierarchy, Organizations can be nested multiple levels deep if desired. This allows the hierarchical structure of the inventory tree to be made as deep as it needs to be to reflect the structure of your company or organization.

The usefulness of an Organization is that if multiple Sites are to be managed, or if it is desired to aggregate BUILDER information across a region or network comprising more than one Site, then Sites can be grouped into one or more Organizations. Even though Organization is the highest level available, however, it is not a required level in the hierarchy. An individual inventory tree may start with either one (and only one) Organization, or one (and only one) Site at the topmost level of that tree.

Note: Preferably, Organizations should be established before Sites.

This task is best assigned to a BUILDER Administrator, once the initial [planning stage](#) has been performed.

Organization Tasks

Tasks that can be performed on Organizations are:

["Add an Organization" on the next page](#)

["Edit Organization Inventory Data" on page 19](#)

["Delete an Organization" on page 23](#)


Add an Organization

This topic shows how to add an Organization and describes the required information to be entered. Additional information that can be entered is described in ["Edit Organization Inventory Data" on page 19](#).


Permissions Note: This action requires Master Planner or Administrator permission for the relevant location in inventory.

To add a new Organization, navigate in the inventory tree to the Organization you wish to add the new Organization under, and do one of the following:

- a. Right-click the existing (parent) Organization. Then select "Add Organization" from the options.



- b. Alternatively, select the existing (parent) Organization. Then activate the **Add Organization** icon on the main toolbar, above the navigation tree.



The "Add Organization" popup window will appear.

Add Organization

Cancel Add

Organization Number: 00001

Organization Name: Test

Relation to 0001 - Testing:

Child

Enter Required Organization Data

This documentation segment describes the minimum data to be entered when creating a new Organization. Other data that can be entered is described in ["Edit Organization Inventory Data" on page 19](#).

In the "Add Organization" popup window, enter the following required data:

1. **Organization ID Number.** Enter the identifying number for the Organization. Organization Number may be left blank if you wish to supply only a name.

You must enter at least Organization name or an Organization number, and the combination of the two must be unique among the Organizations in the navigation tree.

Specifications: The ID Number is limited to 12 alphanumeric characters.

2. **Organization Name.** Enter the identifying name for this Organization, limited to 50 alphanumeric characters. Organization Name may be left blank if you wish to supply only a number. You must enter at least a Organization name or an Organization number, and the combination of the two must be unique among the Organizations in the navigation tree.

Specifications: The name is limited to 50 alphanumeric characters.

Best Practice Recommendation: Avoid using single quotes, double quotes, and ampersands. These characters can interfere with query formation.

3. **Relation.** Specify the relation of the Organization being created to the selected existing Organization or Site on the inventory tree. There are three options for the relation:

- a. **Child** - The Organization will be placed under the selected Organization. Note that a child Organization can only be created when an Organization is selected in the inventory tree.
- b. **Parent** - The Organization will be placed above the selected Organization or Site.

WARNING: Do NOT use the parent relation option without engaging in close *advance* coordination with a BUILDER support representative.

- c. **Sibling** - The Organization will be placed at the same level as the selected Organization.

Note: The top ("root") level Organization is not allowed to have a sibling Organization.

Confirm or Cancel

Once the required minimum Organization data is entered,

- a. Activate the **Add** button on the popup toolbar to create the Organization.
- b. Alternatively, to close the window without creating the Organization, activate the **Cancel** button.

Login Again to View

To see the new Organization in the inventory tree, log out of the program and then log back in again.

Note: This action is needed only for newly created Organizations. Other levels of newly-created inventory will appear immediately in the tree.

Edit Organization Inventory Data

This topic describes the information that can be found and edited at the Organization data screen.

To edit data in an Organization, select the Organization in the inventory tree. This topic describes what you will encounter in the content area of the screen

The screenshot displays the Sustainment Management Systems WITH BUILDER interface. The top navigation bar includes 'Work Configuration', 'Work Plan', 'Scenarios', 'Reports', and 'Tools'. The left sidebar shows the 'Inventory' tree with 'Sample Org' selected. The main content area shows the 'Organization' data screen for 'Sample Org' (Number: 011). The screen is divided into two tabs: 'General Info.' and 'Assessment History'. The 'General Info.' tab is active, showing 'Calculated Data' (PRV: \$11,099,570) and 'Index Data' (a table with metrics and values). The 'Reference Settings' section includes dropdown menus for 'Cost Book', 'Inflation Book', 'Service Life Book', 'Policy Sequence', and 'Prioritization Scheme'.

Metric	Value
CI	56
FI	99
PI	68
FCI	81.516

Toolbar

- **Save.** Saves changes made to the Organization data.
- **Comment.** Allows you to add, edit, and view comments about the Organization.
- **Reports.** Launches the Report Selection tool, which gives you access to a list of standard reports relevant to Organization inventory. See ["Generate a Report" on page 186](#).

ID Line

On the ID line, you can edit the following:

- **Organization ID Number.** The ID Number is limited to 12 alphanumeric characters.
- **Organization Name.** Organization Name is allowed 50 alphanumeric characters. **Best Practice Recommendation:** Avoid using single quotes, double quotes, and ampersands. These characters can interfere with query formation.

General Information Tab

Initially after an Organization is selected in the inventory tree, the General Information (**General Info.**) tab is shown and the following information can be edited:

Index Data (Read-Only)

The following index data is shown under Index Data; the metric shown is for the Organization as a whole.

- **Condition Index (Organization CI).** The Organization CI displays the average CI of the Buildings in the Organization, weighted by replacement cost. This metric provides an overall sense of the condition of the group as a whole.
- **Functionality Index (Organization FI).** The Organization FI displays the average FI of the Buildings in the Organization, weighted by replacement cost. This metric provides an overall sense of the functionality of the Organization as a whole.
- **Performance Index (Organization PI).** The Organization PI displays the average PI of the Buildings in the Organization, weighted by replacement cost. This metric provides an overall sense of the performance of the Organization as a whole.
- **Facility Condition Index (Organization FCI).** The Organization FCI displays the average FCI of the Buildings in the Organization, weighted by replacement cost.

Calculated Data (Read-Only)

- **Plant Replacement Value (PRV).** The aggregate Plant Replacement Value of the Buildings in the Organization.

Reference Settings

Each reference setting provides a dropdown list of options to select from:

- **Cost Book.** From the dropdown list, select either the Reference cost book or a custom cost book to be used for the entire inventory of the Site. The cost book selected will provide inventory replacement and defect repair costs for inventory.
- **Inflation Book.** From the dropdown list, select either the Reference inflation book or a custom inflation book to be used for the entire inventory of the Site. The inflation book selected provides inflation multipliers per year for the projected replacement costs and defect repair costs for the inventory.
- **Service Life Book.** From the dropdown list, select either the Reference service life book or a custom service life book to be used for the entire inventory of the Site. The service life book selected will estimate the remaining service life of Component-Sections in the inventory on the basis of its life expectancy and condition. Also, the service life is used in estimating a rate of deterioration in the condition index of a Component-Section when no more than one inspection has been recorded.
- **Policy Sequence.** From the dropdown list, select either the Reference policy sequence or a custom policy sequence to be used for the entire inventory of the Site. The policy sequence selected will establish the order of precedence for applying policies so that only one standard is chosen for the inventory in the Building.
- **Prioritization Scheme.** From the dropdown list, select the prioritization scheme to be used for the entire inventory of the Site. The prioritization scheme selected will prioritize and rank your work plan in a quick, objective, repeatable, and representative method with the touch of a button.
- **CII Set.** Select either the Reference (default) CII set, or a custom CII set if available.
- **FCI Goal.** Select an FCI goal from the dropdown list.
- **Cost Multiplier Library.** Select the cost modifier library you wish to use for the entire inventory of the Site. The active library selected determines the cost modifiers available for assignment at the Complex, Building, System, Component, or Section levels contained in the Organization.

CAUTION: Reference data can be set at the Organization level and at the Site level. If this data is set at both levels, the reference settings at the Site level will override the reference settings at the Organization level.

Contact Information Tab

The contact information for the Organization can be viewed and edited by selecting the Contact Information (**Contact Info.**) tab.

SUSTAINMENT MANAGEMENT SYSTEMS WITH **BUILDER** This information system is approved for UNCLASSIFIED//FOUO data

Work Configuration Work Plan Scenarios Reports Tools

Inventory

- Sample
 - Sustainment Management System
 - 010 - Sample Site
 - 011 - Sample Org
 - 012 - Sample Site 01**
 - 001 - Building One
 - 013 - Building Two
 - 025 - Building Three

Save Comment Reports Lookup location

Number: 012 Name: Sample Site 01

General Info. **Contact Info.** Assessment History Building Info. GIS Layers Attachments (0)

Name:

Address:

City:

State:

Zip Code:

Phone #:

Fax #:


Email:

WWW:

All of the additional Organization information is optional. It includes data regarding the official point of contact (POC) for the Organization:

- **Name.** Enter the name of the Organization point of contact. Limit: 30 alphanumeric characters.
- **Address.** Enter the official street address of the Organization. Limit: 30 alphanumeric characters).
- **City.** Enter the city of the Organization. Limit: 15 alphanumeric characters.
- **State.** Enter the state of the Organization. Limit: 2 alphanumeric characters.
- **Zip Code.** Enter the zip code of the Organization. Limit: 10 alphanumeric characters.
- **Phone Number.** Enter the phone number of the Organization POC. Limit: 20 alphanumeric characters.
- **FAX Number.** Enter the FAX number of the Organization POC. Limit: 20 alphanumeric characters.
- **Email Address.** Enter the email address of the Organization POC. Limit: 75 alphanumeric characters.
- **WWW.** Enter the URL (Web address) for the Organization. Limit: 75 alphanumeric characters.

Assessment History Tab



The **Assessment History** tab provides a graph of the condition, functionality, performance, and FCI history of the Organization, displaying the Organization CI, Organization FI, Organization PI, and Organization FCI over time.


Delete an Organization

This topic shows how to delete an Organization, which also deletes all other records (Sites, Buildings, etc.) contained in the Organization.


Permissions Note: This action requires Administrator permission. If the inventory item is empty of any contents, then the deletion may also be performed by a Master Planner with permission for the relevant location in inventory.

To delete an Organization, navigate to it in the inventory tree and do one of the following:

- a. Right-click the Organization. Then select "Delete Organization" from the options, as shown below.



- b. Alternatively, select the Organization, then activate the **Delete Organization** icon on the menu toolbar.



WARNING: Deleting an Organization will also delete all inventory (Complexes, Buildings, Systems, Components, and Sections) in that Organization. This is a significant step to take and should only be done when you are certain that you wish to clear the entire inventory of the Organization you have selected.

Best Practice Recommendation: Making frequent backups of your inventory database will protect you from significant data losses if mistakes in deleting are made.

Working with Sites

A Site is the level in the asset tree that ties your real property inventory to a physical location. This topic briefly introduces the features of a Site and how to use it in organizing your real property inventory. It also provides links to the operations that can be performed at the Site level.

Your BUILDER inventory can contain Buildings or facilities at a number of different geographic locations (Sites). If this is the case, then multiple Sites will be needed in your inventory tree structure, one for each geographic location. Alternatively, if all Buildings or facilities to be managed (or to be gleaned for information) are in the same geographic location, one Site will usually suffice.

The Importance of Geography to the Site Level

Knowing the geographic location of a Building is extremely important; therefore it is necessary to create a Site record for each geographic location before you can add Buildings to the database.

When creating a Site, keep in mind that the Site level in the hierarchy is not simply a method for subdividing inventory. It is the level where geographic factors are incorporated into BUILDER calculations, and therefore a Site needs to be confined to a relatively limited geographic area. A larger area can be covered by an [Organization](#) made up of multiple Sites.

Site-Level Properties

Several properties of Buildings are determined or affected by the Building's geographic location (Site), most critically the Area Cost Factor, a multiplier that adjusts national average labor/material/equipment costs to local costs.

In addition to the Area Cost Factor, the following properties are also affected by geographic location:

- HVAC zone
- seismic zone

Other factors that can be set at the Site level are:

- selections for reference books such as cost book, inflation book, service life book, and/or component importance index (CII) set
- policy sequence
- prioritization scheme

- FCI goal (for POM Scenarios)
- selection of cost modifier library

Property Inheritance

Unlike Area Cost Factor, HVAC zone, and seismic zone (which are set only at the Site level), the policy sequence, prioritization scheme, FCI goal and selections for the cost book, inflation book, service life book, CII set, and cost modifier library can also be set at the Organization level.

If the Site and Organization values differ, then the Site level settings take priority.

Site Tasks

Tasks that can be performed on Sites are:

["Add a Site" below](#)

["Edit Site Inventory Data" on page 29](#)

["Delete a Site" on page 38](#)


Add a Site

This topic shows how to add a Site and describes the required information to be entered. Additional information that can be entered for the Site is described in ["Edit Site Inventory Data" on page 29](#).


Permissions Note: This action requires Master Planner or Administrator permission for the relevant location in inventory.

To add a new Site to an Organization, navigate to that Organization in the inventory tree and do one of the following:

- a. Right-click the Organization where the Site is to be located. Then select "Add Site" from the options.



- b. Alternatively, select the Organization. Then activate the **Add Site** icon on the main toolbar, as shown below.



The "Add Site" popup window will appear.

Add Site

Cancel Add

Site Number:

Site Name:

☐ Use factors from following location:

State:

Location:

Data for this location

Area Cost Factor: 0.82

Seismic Zone: 1

HVAC Zone: 3

☐ Use Location Code and Name for Site Information

Enter Required Site Information

This documentation segment describes the minimum data to be entered when creating a new Site. Other data that can be entered is described in ["Edit Site Inventory Data" on the facing page](#).

In the "Add Site" popup window, enter the following required data:

1. **Site Number.** Enter the identifying number for the Site. Site Number may be left blank if you wish to supply only a name. You must enter at least a Site name or a Site number, and the combination of the two must be unique in the navigation tree.

Specifications: The ID Number is limited to 12 alphanumeric characters.

2. **Site Name.** Enter the identifying name for this Site. Site Name may be left blank if you wish to supply only a number. You must enter at least a Site name or a Site number, and the combination of the two must be unique in the navigation tree.

Specifications: The name is limited to 50 alphanumeric characters.

Best Practice Recommendation: Avoid using single quotes, double quotes, and ampersands. These characters can interfere with query formation.

Copy Factors from a Listed Location (Optional)

In the popup window, you are also given the opportunity to copy Site location factors (Area Cost Factor, seismic zone, and HVAC zone) from an existing location. The BUILDER database contains this data for most major cities in the United States as well as Department of Defense installations. To copy factors, mark the **Use factors from following location** checkbox and select a location from the dropdown lists.

Copying factors from an existing location can also be done later by selecting **Lookup Location** from the Site toolbar.

Note: Until you set location factors, they will all be set by default to 1.00.

WARNING: Selecting the checkbox **Use Location Code and Name for Site Information** will overwrite your Site information with that of the location you are copying factors from.

Confirm or Cancel

Once the required minimum Site data is entered,



- a. Activate the **Add** button on the popup toolbar to create the Site. Additional Site details can then be added as described in ["Edit Site Inventory Data" below](#).
- b. Alternatively, to close the window without creating the Site, activate the **Cancel** button.

Edit Site Inventory Data

This topic describes the information that can be found and edited at the Site data screen.

To edit the inventory data for a specific Site, first select the Site in the inventory tree. The following sections describe information that can be obtained and actions that can be performed on the Site.

Toolbar

-  **Save.** Saves changes made to the Site data.
-  **Comment.** Allows you to add, edit, and view comments about the Site.

- **Reports**. Launches the Report Selection tool, which gives you access to a list of standard reports relevant to Site inventory. See ["Generate a Report" on page 186](#).
- **Lookup Location**. Launches the site selection window, where you can adopt location factors (Area Cost Factor, seismic zone, and HVAC zone) from an existing location:

Number: 3 Name: Test

General Info. Location Factors Area Cost Factor: Seismic Zone: HVAC Zone: Index Data

Metric	V
CI	-
FI	-
PI	-
FCI	-

Policy Sequence: System Prioritization Scheme: USMC

How to Use the Lookup Location Button to Set Site Location Factors

Select the state and then the location within that state where your Site is. The location list includes Department of Defense installations and most major cities in the United States. After the state and location are selected, activate the **Select** (Proceed) button to automatically fill in the factor data fields at your Site's **General Information** tab. If you activate the **Cancel** button, you will return to the Site content screen without making changes. If the location of your particular Site is not listed, choose a location close to your Site.

If you mark the **Use Location Code and Name for Site Information** checkbox, the location from the lookup list will be used as the name of your Site. If you leave that checkbox unmarked, your designated Site Number and Site Name will be pre-

served. If you mark the checkbox unintentionally, then you can rename your Site at the ID line in the Site content pane.

ID Line

On the ID line, you can edit the following:

- **Site ID Number.** The ID Number is limited to 12 alphanumeric characters.
- **Site Name.** Site Name is allowed 50 alphanumeric characters. **Best Practice Recommendation:** Avoid using single quotes, double quotes, and ampersands. These characters can interfere with query formation.

General Information Tab (Site Level)

Initially, after a Site is selected in inventory tree, the **General Information** tab (abbreviated **General Info.**) is shown with the following information:

Location Factors

- **Area Cost Factor.** The Area Cost Factor is a multiplier used to adjust national average cost for labor/materials/equipment to local costs. It is generally a number between 0.8 and 1.2 for continental U.S. locations, but it can be even greater than 2.0 in high-cost geographic locations. The Area Cost Factor is set at the Site level.
- **Seismic Zone.** The seismic zone is an integer from 1 to 7 following the Federal Emergency Management Agency's (FEMA) U.S. seismic zoning. Determine your Site's seismic zone by consulting the seismic map of the U.S. seismic zones, which can be accessed by clicking the **Map** button next to the **Seismic Zone** dropdown selection box. The seismic zone is set at the Site level.
- **HVAC Zone.** The HVAC zone is an integer from 1 to 11. You can set your Site's HVAC zone by clicking the **Lookup Location** button on the toolbar, then selecting "State" and "Location" from the dropdown lists in the popup window, and finally clicking the **Select** button on the toolbar in the popup. Alternatively, you can consult the map of the U.S. HVAC zones, which can be accessed by activating the **Map** button next to the HVAC Zone text box. The HVAC Zone is set at the Site level.

Index Data (Read-Only)

- **Site Condition Index (Site CI).** The Site CI displays the average CI of the Buildings in the Site, weighted by replacement cost. This metric provides an overall sense of the condition of the Site as a whole.

- **Site Functionality Index (Site FI).** The Site FI displays the average FI of the Buildings in the Site, weighted by replacement cost. This metric provides an overall sense of the functionality of the Site as a whole.
- **Site Performance Index (Site PI).** The Site PI displays the average PI of the Buildings in the Site, weighted by replacement cost. This metric provides an overall sense of the performance of the Site as a whole.
- **Site Facility Condition Index (Site FCI).** The Site FCI metric provides an overall sense of deferred repair work at the Site level. It differs from the Site CI in that it is a monetary based metric. The formula is: $FCI = (1 - \text{\$current repair needs} / \text{\$PRV}) \times 100$, where the dollar amount of repair needs is obtained from BUILDER work items. More information about the FCI is available at ["Appendix B: Facility Condition Index" on page 192](#).

Calculated Data

- **Number of Facilities.** Displays the number of Buildings included in the Site inventory.
- **PRV.** Displays the aggregate Plant Replacement Value of the Buildings at the Site, computed by adding the individual Building replacement costs.

Reference Settings

- **Cost Book.** From the dropdown list, select the cost book to be used for the entire inventory of the Site. The cost book selected will provide inventory replacement and defect repair costs for inventory.
- **Inflation Book.** From the dropdown list, select the inflation book to be used for the entire inventory of the Site. The inflation book selected provides inflation multipliers per year for the projected replacement costs and defect repair costs for the inventory.
- **Service Life Book.** From the dropdown list, select the service life book to be used for the entire inventory of the Site. The service life book selected will estimate the remaining service life of Component-Sections in the inventory on the basis of its life expectancy and condition. Also, the service life is used in estimating a rate of deterioration in the condition index of a Component-Section when no more than one inspection has been recorded.
- **Policy Sequence.** From the dropdown list, select the policy sequence to be used for the entire inventory of the Site. The policy sequence selected will establish the order of precedence for applying policies so that only one standard is chosen for the inventory in the Building.
- **Prioritization Scheme.** From the dropdown list, select the prioritization scheme to be used for the entire inventory of the Site. The prioritization scheme selected will prioritize and rank your work plan in a quick, objective, repeatable, and representative method with the touch of a button.

- **CII Set.** Select either the Reference (default) CII set, or a custom CII set if available.
- **FCI Goal.** Select an FCI goal from the dropdown list.
- **Cost Multiplier Library.** Select the cost modifier library you wish to use for the entire inventory of the Site. The active library selected determines the cost modifiers available for assignment at the Complex, Building, System, Component, or Section levels contained in the Organization.

CAUTION: Reference data can be set at the Organization level and at the Site level. If this data is set at both levels, the reference settings at the Site level will override the reference settings at the Organization level.

Additional Site Data

In addition to data available at the **General Information** tab, further Site information is displayed and can be edited at the tabs listed below.

All of the additional Site information listed below is optional, or else generated by BUILDER.


Contact Information Tab

Point of contact (POC) information for the Site may be viewed and edited by selecting the Contact Information (**Contact Info.**) tab. The available fields are as follows:

- **Name.** Enter the name of the Site point of contact. Limit: 30 alphanumeric characters.
- **Address.** Enter the official street address of the Site. Limit: 30 alphanumeric characters.
- **City.** Enter the city where the Site is located. Limit: 15 alphanumeric characters.
- **State.** Enter the state where the Site is located. Limit: 2 alphanumeric characters.
- **Zip Code.** Enter the zip code of the Site. Limit: 10 alphanumeric characters.
- **Phone Number.** Enter the phone number of the Site POC. Limit: 20 alphanumeric characters.
- **FAX Number.** Enter the FAX number of the Site POC. Limit: 20 alphanumeric characters.
- **Email Address.** Enter the email address of the Site POC. Limit: 75 alphanumeric characters.
- **WWW.** Enter the URL (Web address) for this Complex. Limit: 75 alphanumeric characters.

Assessment History Tab

The Assessment History tab provides a graph of the condition, functionality, and performance history of the Site, displaying the Site CI, Site FI Site PI, and Site FCI over time.



Facility Summary Tab

Basic information regarding Buildings at the Site is available under the **Facility Summary** tab. All of the data shown at this tab is read-only; however, which information is displayed can be influenced using the search filters provided. Each column shown at the **Facility Summary** tab is described below.

Save Comment Reports Lookup location

Number: Name: Site Two - Same Section Different Standard

General Info. Contact Info. Assessment History Facility Summary Attachments (0)

Export

Facility	Complex	Quantity	UM	PRV	BCI	BFI	BPI	FCI
100 - Std CI greater than Section, Std RSL LT Asset	Unassigned	10,000	SF	\$2,133,360	60	100	72	100,000
200 - Std CI less than Section, Std RSL LT Asset	Unassigned	10,000	SF	\$2,133,360	60	100	72	100,000

- **Facility.** Displays the Building number and name of each Building at the Site.
- **Complex.** Displays the Complex that the Building is part of, if applicable.
- **Quantity.** This is the primary measure of the size of the facility. For buildings, it will usually be square feet, if the unit of measure (UM) selected at User Preferences is "English."
- **Unit of Measure (UM).** Displays the unit of measure in use.
- **Plant Replacement Value (PRV).** Displays the aggregate Plant Replacement Value of the Buildings at the Site.
- **Building Condition Index (BCI).** Displays the current CI of each Building at the Site.
- **Building Functionality Index (BFI).** Displays the current FI of each Building at the Site.
- **Building Performance Index (BPI).** Displays the current PI of each Building at the Site.
- **Facility Condition Index (FCI).** Displays the current FCI of each Building at the Site. For more information about the Facility Condition Index, see ["Appendix B: Facility Condition Index" on page 192.](#)

Additionally, the Site CI, Site FI, Site PI and Site FCI are shown at the top of the tab, which are the average of each index of the Buildings at the Site, weighted by replacement cost.

Export Information from the Facility Summary Tab

All the information at the **Facility Summary** tab can be exported to a Microsoft Excel spreadsheet by activating the **Export** button, located below "Number" on the ID line.

Attachments Tab

The **Attachments** Tab allows files such as an image file to be attached to the Site's record. An image might be a photograph, or it could be an electronic image of written notes or diagrams made during inventory.

The attachment may be in any of the following formats:

- .jpg
- .jpeg
- .png
- .zip
- .doc
- .pdf

Note: As of March 7, 2019, .doc format is allowed, but not .docx.

Attach a File

To attach a file,

1. At the **Attachments** tab, activate the  **Add** button in the toolbar below the row of tabs.

The screenshot shows the main application window with a toolbar at the top containing 'Save', 'Comment', 'Reports', and 'Lookup location'. Below the toolbar are input fields for 'Number: 123' and 'Name: Testing Site One'. A tabbed interface below shows 'General Info.', 'Contact Info.', 'Assessment History', 'Facility Summary', and 'Attachments (0)'. The 'Attachments (0)' tab is active, displaying a table with a 'Title' column. Above the table are 'Add' and 'Delete' buttons. The 'Add' button, which has a document icon, is highlighted with a red rectangular box. Below the table, the text 'No records to display.' is visible.

This will open the "Add Image" popup window:

The screenshot shows the 'Add Image' popup window. It has a title bar with a document icon and the text 'Add Image'. Below the title bar is a toolbar with 'Cancel', 'Save', and 'Help' buttons. The main area contains three text input fields: 'Title:', 'Description:', and 'Image:'. To the right of the 'Image:' field is a 'Select' button, which is highlighted with a red rectangular box.


2. Enter Title and Description information for the attachment.
3. Activate the **Select** button to the right of the "Image" field to browse to the desired image or other file.
4. If you are adding an attachment at the Building level, use the "Image Type" radio buttons to indicate whether the attachment is a Key Plan, a Section Plan, or "Other."
5. Once the required attachment data is entered, activate the **Save** button on the popup toolbar. Alternatively, to close the popup window without attaching the selected file or image, activate the **Cancel** button.

Delete a Site

This topic shows how to delete a Site, which also deletes all other records (Buildings, Systems, etc.) contained in the Site.

Permissions Note: This action requires Administrator permission. If the inventory item is empty of any contents, then the deletion may also be performed by a Master Planner with permission for the relevant location in inventory.

To delete a Site, navigate to it in the inventory tree and do one of the following:

- a. Right-click the Site. Then select "Delete Site" from the options.
- b. Alternatively, select the Site, then activate the **Delete Site** icon  on the menu toolbar.

WARNING: Deleting a Site deletes all inventory (Complexes, Buildings, Systems, Components, and Sections) in that Site. This is a significant step to take and should only be done when certain that you wish to clear the entire inventory of the selected Site.

Best Practice Recommendation: Making frequent backups of the inventory database will protect you from significant data losses if an unintended deletion is performed.

Working with Complexes

A Complex is an optional level in the asset tree, used to group Buildings/facilities together into one management unit. This topic briefly introduces the features of a Complex and how to use it in organizing your real property inventory. It also provides links to the operations that can be performed at the Complex level.

Grouping Buildings into Complexes

BUILDER allows you to group multiple Buildings at a Site into an organizational level between Sites and Buildings, called a Complex. This is especially useful if your inventory has a large number of Buildings at a single location.

The grouping may be based on a similarity between the Buildings, or it may have a different basis such as who manages the group, or who the Buildings are leased from or to.

Each Building may belong to at most one Complex, but it is not required for a Building to be in a Complex at all. Three alternative strategies are possible:

- a. You may choose not to use Complexes at all, in which case Buildings will be listed directly under their Site in the inventory tree.
- b. You can group all of your Buildings into Complexes.
- c. You can create Complexes, but you may also have Buildings at your Site that are not assigned to any Complex. In this case, you may choose either to list unassigned Buildings directly under their Site, or to create a Complex named "Unassigned" which will have all such Buildings listed under it in the inventory tree.

Complex Tasks

Tasks that can be performed on Complexes are:

["Add a Complex" on the next page](#)

[" Edit Complex Inventory Data" on page 45](#)

["Delete a Complex" on page 51](#)


Add a Complex

This topic shows how to add a Complex and describes the required information to be entered. Additional information that can be entered is described in ["Edit Complex Inventory Data" on page 45](#).


Permissions Note: This action requires Work Planner permission or above for the relevant location in inventory.

To add a new Complex to a Site, navigate to that Site in the inventory tree and do one of the following:

- a. Right-click the Site. Then select "Add Complex" from the options.



- b. Alternatively, select the Site, then activate the **Add Complex** icon on the main toolbar, as shown below.



The "Add Complex" popup window will appear.



Enter Required Complex Data

This documentation segment describes the minimum data to be entered when creating a new Complex. Other data that can be entered is described in ["Edit Complex Inventory Data" on page 45](#)

In the "Add Complex" popup window, enter the following required data:

1. **Complex Number.** Enter the identifying number for the Complex. The Complex Number field may be left blank if you wish to supply only a name. You must enter at least a Complex name or a Complex number, and the combination of the two must be unique within the Site.

Specifications: The Complex The ID Number is limited to 12 alphanumeric characters.

2. **Complex Name.** Enter the identifying name for this Complex. The Complex Name field may be left blank if you wish to supply only a number. You must enter at least a Complex name or a Complex number, and the combination of the two must be unique within the Site.

Specifications: The name is limited to 50 alphanumeric characters.

Best Practice Recommendation: Avoid using single quotes, double quotes, and ampersands. These characters can interfere with query formation.

Confirm or Cancel

Once the required minimum Complex data is entered,

- a. Activate the **Add** button on the popup toolbar to create the Complex. Additional Complex details can then be added as described in ["Edit Complex Inventory Data" on page 45](#)
- b. Alternatively, to close the window without creating the Complex, activate the **Cancel** button.

Assign One or More Buildings to a Complex

Complexes can be used to group similar Buildings, but assigning a Building to a Complex is optional. The steps below outline how to assign (move) or unassign (remove) a Building to/from a Complex.

To prepare for assigning Buildings to a Complex, first navigate to the Complex in the inventory tree and select it.

In the content area (illustrated below), select the **Facility Mgmt.** tab. This will bring up two columns:

- **Unassigned Buildings** (the column on the left) lists Buildings available to be assigned to a Complex.
- **Assigned Buildings** (the column on the right) lists Buildings already assigned to the selected Complex.

Note: The Buildings and the Complex must be in the same Site.

The screenshot shows a web application interface for managing buildings and complexes. At the top, there is a toolbar with buttons for 'Save', 'Comment', and 'Reports'. Below the toolbar, there is a breadcrumb trail showing the current location: '0032 - Sample Site' > '0033 - Sample Complex'. Below the breadcrumb trail, there are two input fields: 'Number: 0033' and 'Name: Sample Complex'. Below the input fields, there is a tabbed interface with six tabs: 'General Info.', 'Contact Info.', 'Assessment History', 'Facility Mgmt.', 'Facility Summary', and 'Attachments (0)'. The 'Facility Mgmt.' tab is currently selected. Below the tabs, there are two columns: 'Unassigned Buildings' and 'Assigned Buildings'. The 'Unassigned Buildings' column contains two items: '00331 - Building 1' and '00332 - Building 02'. The 'Assigned Buildings' column is currently empty. Between the two columns, there are four arrow buttons: a single right-pointing arrow, a single left-pointing arrow, a double right-pointing arrow, and a double left-pointing arrow.

Move Buildings into a Complex

To move one or more Buildings from the **Unassigned Buildings** column into the Complex, use the arrow keys located between the two columns as described below.

To move all of the Buildings into the Complex,

1. Activate the button with double right-pointing arrows.
2. Use the **Save** button on the content area toolbar to lock in your change.

To move one Building into the Complex,

1. Select the Building in the **Unassigned Buildings** column.
2. Activate the single right-pointing arrow.
3. Use the **Save** button on the content area toolbar to lock in your change.

To move multiple Buildings into the Complex,

1. Select the Buildings in the **Unassigned Buildings** column, using the **Shift** and **Tab** keys as needed.
2. Activate the single right-pointing arrow.
3. Use the **Save** button on the content area toolbar to lock in your change.

Remove Buildings from a Complex

To move one or more Buildings from the Complex back into the **Unassigned Buildings** column, use the arrow keys located between the two columns as described below.

To move all of the Buildings,

1. Activate the button with double left-pointing arrows.
2. Use the **Save** button on the content area toolbar to lock in your change.

To move one Building,

1. Select the Building in the **Assigned Buildings** column.
2. Activate the single left-pointing arrow.
3. Use the **Save** button on the content area toolbar to lock in your change.

To move multiple Buildings,

1. Select the Buildings in the **Assigned Buildings** column, using the **Shift** and **Tab** keys as needed.
2. Activate the single left-pointing arrow.
3. Use the **Save** button on the content area toolbar to lock in your change.


Move Buildings from one Complex to Another

To move a Building from one Complex to a different one, you must first navigate to the Complex it is assigned to and unassign it (see *Remove Buildings from a Complex*, immediately above). Then navigate to the destination Complex and follow the instructions in *Move Buildings into a Complex*, above).

Edit Complex Inventory Data

This topic describes the information that can be found and edited at the Complex data screen.




To edit the inventory data for a specific Complex, first select the Complex in the inventory tree.



The following sections describe information that can be obtained and actions that can be performed on the Complex.

Toolbar

The following options are available at the content area toolbar:

-  **Save.** Saves changes made to the Complex data.
-  **Comment.** Allows you to add, edit, and view comments about the Complex.
-  **Reports.** Launches the Report Selection tool, which gives you access to a list of standard reports relevant to Complex inventory. See ["Generate a Report" on page 186](#).

ID Line

On the ID line, you can edit the following:

- **Complex ID Number.** The ID Number is limited to 12 alphanumeric characters.
- **Complex Name.** Complex Name is allowed 50 alphanumeric characters.
Best Practice Recommendation: Avoid using single quotes, double quotes, and ampersands. These characters can interfere with query formation.

General Complex Information Tab

Initially, after a Complex is selected in the inventory tree, the **General Information** tab (abbreviated **General Info.**) is shown with the following information:


- **Index Data (Read-Only).**
 - **Complex Condition Index (Complex CI).** The Complex CI displays the average CI of the buildings in the Complex, weighted by replacement cost. This metric provides an overall sense of the condition of the Complex as a whole.
 - **Complex Functionality Index (Complex FI).** The Complex FI displays the average FI of the buildings in the Complex, weighted by replacement cost. This metric provides an overall sense of the functionality of the Complex as a whole.
 - **Complex Performance Index (Complex PI).** The Complex PI displays the average PI of the buildings in the Complex, weighted by replacement cost. This metric provides an overall sense of the performance of the Complex as a whole.
 - **Complex Facility Condition Index (Complex FCI).** The Complex FCI metric provides an overall sense of deferred repair work at the Complex level. It differs from the Complex CI in that it is a monetary based metric. The formula is: $FCI = (1 - \$\text{current repair needs} / \$\text{PRV}) \times 100$, where the dollar amount of repair needs is obtained from BUILDER work items. More information about the FCI is available at ["Appendix B: Facility Condition Index" on page 192.](#)
- **Calculated Data (Read-Only).**
 - **Number of Facilities.** Displays the number of Buildings included in the Complex inventory.
 - **PRV.** Displays the aggregate Plant Replacement Value of the Buildings at the Complex, computed by adding the individual Building replacement costs.

Contact Information Tab

Point of contact (POC) information for the Complex may be viewed and edited by selecting the Contact Information (**Contact Info.**) tab. The available fields are as follows:

- **Name.** Enter the name of the Complex point of contact. Limit: 30 alphanumeric characters.
- **Address.** Enter the official street address of the Complex. Limit: 30 alphanumeric characters.
- **City.** Enter the city where the Complex is located. Limit: 15 alphanumeric characters.
- **State.** Enter the state where the Complex is located. Limit: 2 alphanumeric characters.
- **Zip Code.** Enter the zip code of the Complex. Limit: 10 alphanumeric characters.
- **Phone Number.** Enter the phone number of the Complex POC. Limit: 20 alphanumeric characters.
- **FAX Number.** Enter the FAX number of the Complex POC. Limit: 20 alphanumeric characters.
- **Email Address.** Enter the email address of the Complex POC. Limit: 75 alphanumeric characters.
- **WWW.** Enter the World Wide Web (WWW) URL address for this Complex. Limit: 75 alphanumeric characters.

Assessment History Tab



The Assessment History tab provides a graph of the condition, functionality, performance and FCI history of the Complex, displaying the Complex CI, Complex FI, Complex PI and Complex FCI over time.

Facility Management Tab

The Facility Management (**Facility Mgmt.**) tab lists the Buildings currently assigned to the Complex. Buildings can be assigned to or removed from the Complex at this tab. The Buildings are separated into two columns:

- **Unassigned Buildings.** Lists the Buildings at the Site that are not assigned to a Complex.
- **Assigned Buildings.** Lists the Buildings assigned to the current Complex.

The screenshot shows the 'Facility Mgmt.' tab selected in a software interface. At the top, there is a navigation bar with 'Save', 'Comment', and 'Reports' buttons, and a breadcrumb trail '013 - Sample Site 02 > 0044 - new complex'. Below this, there are input fields for 'Number: 0044' and 'Name: new complex'. A tabbed interface below shows 'General Info.', 'Contact Info.', 'Assessment History', 'Facility Mgmt.' (selected), 'Facility Summary', and 'Attachments'. The 'Facility Mgmt.' tab is divided into two main sections: 'Unassigned Buildings' on the left and 'Assigned Buildings' on the right. In the 'Unassigned Buildings' section, there is one entry '003 - buildout'. Between the two sections is a vertical column of four arrow buttons: a single right arrow, a single left arrow, a double right arrow, and a double left arrow, used for moving buildings between the lists.

Select the desired Building and use the arrow keys to move unassigned Buildings onto the assigned list or to remove Buildings from the assigned list to the unassigned list. Only Buildings that are not assigned to a Complex will appear in the list on the left. If you wish to move a Building from one Complex to another, you must remove it from the first Complex before you can add it to the second.

Facility Summary Tab

Basic information regarding Buildings at the Complex is available under the **Facility Summary** tab. All of the data shown at this tab is read-only; however, which information is displayed can be influenced using the search filters provided. Each column shown at the **Facility Summary** tab is described below.

Save Comment Reports 013 - Sample Site 02 ▶ 0044 - Training

Number: 0044 Name: Training

General Info. Contact Info. Assessment History Facility Mgmt. **Facility Summary** Attachments (0)

Export

Facility	Quantity	UM	PRV	BCI	BFI	BPI	FCI

No records to display.

- **Facility.** Displays the number and name of each Building in the Complex.
- **Quantity.** This is the primary measure of the size of the facility. For buildings, it will usually be square feet, if the User Preferences (UM) selected at User Preferences is "English." (User preferences are explained in the *BUILDER Getting Started Guide*)
- **Unit of Measure (UM).** Displays the unit of measure in use.
- **Plant Replacement Value (PRV).** Displays the aggregate Plant Replacement Value of the Buildings in the Complex.
- **Building Condition Index (BCI)** . Displays the current Building Condition Index of each Building in the Complex.
- **Building Functionality Index (BFI).** Displays the current Building Functionality Index of each Building in the Complex.
- **Building Performance Index (BPI).** Displays the current Building Performance Index of each Building in the Complex.
- **Facility Condition Index (FCI).** Displays the current Facility Condition Index of each Building in the Complex. For more information about the Facility Condition Index, see ["Appendix B: Facility Condition Index" on page 192.](#)

Additionally, the Complex CI, Complex FI Complex PI and Complex FCI are shown at the top of the tab, which are the average of each index of the Buildings in the Complex weighted by replacement cost.

Export Information from the Facility Summary Tab

All the information at the **Facility Summary** tab can be exported to a Microsoft Excel spreadsheet by activating the **Export** button, located below "Number" on the ID line.

Save Comment Reports Lookup location

Number: 013 Name: Sample Site 02

General Info. Contact Info. Assessment History Facility Summary

Export

Facility Com

Cost Modifiers Tab

Cost modifiers allow you to modify cost information by applying cost multipliers and adders.

Attachments Tab

The **Attachments** Tab allows files such as an image file to be attached to the Complex's record. An image might be a photograph, or it could be an electronic image of written notes or diagrams made during inventory.

The attachment may be in any of the following formats:

- .jpg
- .jpeg
- .png
- .zip
- .doc
- .pdf

Note: As of March 7, 2019, .doc format is allowed, but not .docx.

Attach a file

To attach a file,

1. At the **Attachments** tab, activate the  **Add** button in the toolbar below the row of tabs.

The screenshot shows the top of a web application. At the top, there is a toolbar with 'Save', 'Comment', and 'Reports' buttons. Below this is a breadcrumb trail: '123 - Testing Site One > A - Complex B'. Underneath the breadcrumb are two input fields: 'Number: A' and 'Name: Complex B'. Below these are several tabs: 'General Info.', 'Contact Info.', 'Assessment History', 'Facility Mgmt.', 'Facility Summary', and 'Attachments (0)'. The 'Attachments (0)' tab is active. Below the tabs, there is a table with a header row containing a red 'Add' button (highlighted with a red box) and a red 'Delete' button. Below the table, it says 'No records to display.'

This will open the "Add Image" popup window:

The screenshot shows a 'Add Image' popup window. It has a title bar with 'Add Image'. Below the title bar are three buttons: 'Cancel', 'Save', and 'Help'. The main area of the window contains three input fields: 'Title:', 'Description:', and 'Image:'. To the right of the 'Image:' field is a 'Select' button, which is highlighted with a red box.

2. Enter Title and Description information for the attachment.
3. Activate the **Select** button to the right of the "Image" field to browse to the desired image or other file.
4. If you are adding an attachment at the Building level, use the "Image Type" radio buttons to indicate whether the attachment is a Key Plan, a Section Plan, or "Other."
5. Once the required attachment data is entered,
 - a. Activate **Save** on the popup toolbar.
 - b. Alternatively, to close the popup window without attaching the selected file or image, activate the **Cancel** button.


Delete a Complex

This topic shows how to delete a Complex, which also deletes all other records (Buildings, Systems, etc.) contained in the Complex.

Permissions Note: This action requires Administrator permission. If

the inventory item is empty of any contents, then the deletion may also be performed by a Master Planner with permission for the relevant location in inventory.

To delete a Complex, navigate to it in the inventory tree and do one of the following:

- a. Right-click the Complex. Then select "Delete Complex" from the options.
- b. Alternatively, select the Complex, then activate the  **Delete Complex** icon on the main toolbar.

WARNING: Deleting a Complex deletes all inventory (Buildings, Systems, Components, and Sections) in the Complex. This is a significant step to take and should only be done when you are certain that you wish to clear the entire inventory of the Complex you have selected.

Best Practice Recommendation: Making frequent backups of your inventory database will protect you from significant data losses if mistakes in deleting are made.

Working with Buildings

A large amount of information is stored at the Building level of the asset tree. This topic describes what a Building is and how to use it in organizing your real property inventory. It also provides links to the operations that can be performed at the Building level.

The Building level is a pivotal level in BUILDER. Levels above the Building level give the organizational and geographic context of the Building. Levels below the Building exist to conceptually subdivide the Building to create an organization for the Component-Sections that represent the physical parts of the Building.

The Building level is the lowest level in the SMS hierarchy that is shared by both BUILDER and ROOFER. (Below the Building level, ROOFER has just one more hierarchical level, the roof section.)

Note: Because a Building record is almost always larger and more complex than any other hierarchical record in BUILDER, it will take longer for a Building record to process and appear on the screen than it will for records at other levels in the hierarchy.

Building Information




Main Toolbar

When you select a Building in the inventory tree, icons corresponding to actions you can take at that level of inventory will display in the main toolbar.

Content Area Toolbar

Buttons

Buttons on the content area toolbar allow you to do the following:

-  **Save.** Save changes made to the Building data.
-  **Comment.** View, add, or edit comments about the Building.
-  **Reports.** Launch the Report Selection tool, which gives you access to a list of standard reports relevant to Building inventory. See ["Generate a Report" on page 186](#).

Breadcrumbs

The breadcrumbs shown on the content area toolbar provide both orientation and an alternative method of navigation.

Building Identification

On the ID line, below the content area toolbar, you can edit the following:

- **Building ID Number.** The ID Number is limited to 12 alphanumeric characters.
- **Building Name.** Building Name is allowed 50 alphanumeric characters.
Best Practice Recommendation: Avoid using single quotes, double quotes, and ampersands. These characters can interfere with query formation.

Information Tabs

At the information tabs is where you will view or enter specific details about the Building. By default, the **General Information** tab (abbreviated General Info) will appear when you navigate to a Building in the inventory tree.

Information at these tabs is described in [Building General Information Tab](#) and ["Edit Additional Building Inventory Data" on page 64](#).

Building Tasks

Tasks that can be performed on Buildings are:

- ["Add a Building" on the facing page](#)
- [Building General Information Tab](#)
- ["Edit Additional Building Inventory Data" on page 64](#)
- ["Delete a Building" on page 70](#)

Additional useful information can be found here:


- ["About the Building Current Status Property" on page 72](#)
- ["Use Current Status to Track Non-Current Inventory" on page 75](#)

Add a Building


This topic shows how to add a Building and describes the required information to be entered. Additional information that can be entered is described in [Building General Information Tab](#) and ["Edit Additional Building Inventory Data" on page 64](#).

After you ["Add a Site" on page 26](#), you can add Buildings to your inventory. To add a new Building to a Site, navigate to that Site in the inventory tree and do one of the following:

- a. Right-click the Site. Then select "Add Building" from the options.



- b. Alternatively, select the Site, then activate the **Add Building** icon on the main toolbar, as shown below.



Enter Required Building Information

In the "Add Building" popup window, enter the following required data:

1. **Building Number.** Enter the identifying number for the Building. For DoD applications, the RPUID is helpful here. The Building Number field may be left blank if you wish to supply only a name. You must enter at least a Building name or a Building number, and the combination of the two must be unique within the Site.

Specifications: The Building The ID Number is limited to 12 alphanumeric characters.

Best Practice Recommendation: Because the Building number is alphanumeric instead of numeric, the alphabetic ordering of Buildings in a list will follow character order rather than number order: for example, Building number 10 will be listed before Building number 2. To avoid this situation, use the correct number of leading zeros (for example, use 02 or 002 or 0002 instead of 2), depending on the maximum number of digits used in numbering Buildings.

2. **Building Name.** Enter the identifying name for this Building. The Building Name field may be left blank if you wish to supply only a number. You must enter at least a Building name or a Building number, and the combination of the two must be unique within the Site.

Specifications: The name is limited to 50 alphanumeric characters.

Best Practice Recommendation: Avoid using single quotes, double quotes, and ampersands. These characters can interfere with query formation.

3. **Building Use.** Select the Building Use category from the dropdown list that most closely matches the Building's use. If you are a Department of Defense activity, BUILDER should display familiar category codes for your service.
4. **Construction Type.** Select the construction type from the dropdown list that matches the Building. Construction type options include:
 - Permanent
 - Leased
 - Semi-Permanent
 - Temporary
5. **Status (Current Status).** Select the appropriate status of the Building from the dropdown list. See ["About the Building Current Status Property" on page 72](#) for more information. Status type options include:
 - Active
 - Demolished
 - To be acquired
 - To be built
 - To be demolished
 - To be transferred
 - Transferred
 - Vacant

The default Building status is "Active." The last four of these values indicate that the designated Building is not currently part of the inventory, and two others indicate that the Building will be removed from the inventory in the future. In essence, the [Current Status property](#) allows you to enter future Buildings into the inventory and to plan for their maintenance even though they are not presently owned. In addition, the Current Status property allows you to keep records for Buildings that are no longer in the physical inventory. Such records are ignored in processes that should only consider current Buildings, such as condition rollups and work planning.

6. **Does Not Contain (New as of Version 3.4.0).** If there are Systems that the Building does not contain, you can indicate this by selecting from the dropdown list.
7. **Year Built.** Enter the year construction of the Building was completed. This data element determines the age of the Building, which is a critical factor in BUILDER's decision-making processes.

8. **Year Renovated (New as of Version 3.4.0).** If the Building has been renovated, enter the year that the renovation was completed.
9. **Number of Floors.** Enter the number of floors of the Building. This data element is used to estimate the size of the Building's footprint by dividing the area by the number of floors.
10. **Area.** Enter the gross area of the Building.

This data is required because BUILDER's internal algorithms generally have parameters determined by the Building's Building Use, size, age, number of floors, status, and construction type, so it is essential that the information be provided as a part of creating the Building record.

Add Building

Cancel Add

Building No: Building Name:

Building Use:

Const. Type: Permanent

Status: Active

Year Built:

No. of Floors:

Area: SF

Confirm or Cancel

Once the required minimum Building data is entered,

- a. Activate the **Add** button on the popup toolbar to create the Building. *The Building Summary window will open to allow you to immediately add to and edit the Building data at the various tabs. These tabs are described in [Building General Information Tab](#) and ["Edit Additional Building Inventory Data" on page 64.](#)*
- b. Alternatively, to close the window without creating the new Building, activate the **Cancel** button.

Edit Building General Information

This topic describes the information that can be found and edited at the **General Information** tab on the Building screen. Additional Building information is described in the topic ["Edit Additional Building Inventory Data" on page 64](#).

The sections below, as well as the topic ["Edit Additional Building Inventory Data" on page 64](#), describe information that can be obtained about and actions that can be performed on the Building.

To view and edit Building inventory data, select the Building in the navigation pane:

Inventory

Sample

- Sustainment Management System
 - 010 - Sample Site
 - 011 - Sample Org
 - 012 - Sample Site 01
 - 1 - Complex 1
 - 001 - Building One**

Save Comment Reports 012 - Sample Site 01 ▶ 001 - Building One

Building No: 001 Building Name: Building One

General Info Additional Info Assess. History Work Item History Systems at a Glance Attachments (0)

Building Use: 891024 - BUILDING HOUSING MISCELLANEOUS UTILITY PLANT

Building Type:

Current Status: Active

Construction Type: Permanent

Area: 4,300 SF

Year Constructed: 1985

Number of Floors: 1

ISR Rating:

Replacement Cost: \$0

Check box to override automated updates and manually enter replacement cost: ☐

Mission Dependency Index

MDI:

Check box to override automated updates and manually enter MDI: ☐

Status

☐ Historic

☐ Child-Occupied Facility

Condition

Metric	Value
BCI	42
BFI	100
BPI	59
FCI	100

Functionality

Issue	Rating
Location	100
Cultural Resources	No
Building Size and Configuration	100
Structural Adequacy	100
Access	100

By default, the **General Information** tab (abbreviated General Info) will appear.

Toolbar

The following buttons and information are available at the content screen toolbar:

- **Save**. Saves changes made to the Building data.
- **Comment**. Allows you to add, edit, or view comments about the Building.
- **Reports**. Launches the Report Selection tool, which gives you access to a list of standard reports relevant to Building inventory. See ["Generate a Report" on page 186](#).

- **Breadcrumbs.** The breadcrumbs shown on the toolbar provide both orientation and an alternative method of navigation:

[013 - Sample Site 02](#) ▶ [0044 - Training](#) ▶ [00002 - Physio](#)

ID Line

On the ID line, you can edit the following:

- **Building ID Number.** The ID Number is limited to 12 alphanumeric characters.
- **Building Name.** Building Name is allowed 50 alphanumeric characters.
Best Practice Recommendation: Avoid using single quotes, double quotes, and ampersands. These characters can interfere with query formation.

General Building Information Tab

Initially after a Building is selected in the inventory tree, the **General Information** tab is shown with the following information, all of which is required:

Type, Age, and Size Data

- **Building Use.** From the dropdown list, select the Building Use category that most closely matches the Building's use. For a Department of Defense activity, BUILDER should display familiar category codes for your service.
- **Current Status.** From the dropdown list, select the appropriate Building status. See ["About the Building Current Status Property" on page 72](#) for more information. Status type options include:
 - Active
 - To be acquired
 - To be built
 - To be demolished
 - To be transferred
 - Demolished
 - Transferred
 - Vacant

The options "To be acquired" and "To be built" allow you to enter future Buildings into the inventory and to plan for their maintenance in Scenarios even though they are not presently owned. Along with Transferred and Demolished, these options allow you to keep information about the Building

in your database without the data on these Buildings affecting your current condition indices.

The options "Transferred" and "Demolished" allow you to keep records for Buildings that are no longer in the physical inventory. Such records are ignored in processes that should only consider current Buildings, such as condition rollups and work planning.

- **Effective Year of Status.** When you choose a Building status other than the default "Active" status, you must also provide a year in which the permanent status will take effect. For vacant, demolished, and transferred Buildings, the effective year is the year the action occurred. For future ("To be") status options, the effective year is the year the future event will occur—i.e., the year the Building will actually be built, acquired, transferred, or demolished.
- **Construction Type.** Select the construction type from the dropdown list that matches the Building. Construction type options include:
 - Permanent
 - Semi-Permanent
 - Temporary
 - Leased
- **Area.** Enter the gross area of the Building.
- **Year Constructed.** Enter the year that construction of the Building was completed. This data element determines the age of the Building, which is a critical factor in BUILDER's decision-making processes.
- **Number of Floors.** Enter the number of floors of the Building. This data element is used to estimate the size of the Building's footprint by dividing the area by the number of floors.

Calculated Data

Data calculated by BUILDER is usually read-only. However, **Replacement Cost** and **Mission Dependency Index (MDI)** each have a checkbox that allows manual entry or manual override of the system-calculated figure.

- **Replacement Cost.** This data element contains the current replacement cost for a Building of the current Building's use and size under current construction standards. BUILDER provides a cost module to estimate the replacement cost. If you don't check the manual override checkbox, the cost module will update the replacement cost using the default, adjusted for inflation and geographic location, when costs are updated. If you check the manual override checkbox, the cost module will not affect this Building's replacement cost, and you will have to periodically update its replacement cost manually to account for inflation.

Note: For further Information about working with cost books and inflation books, see Work Configuration documentation.

- **Mission Dependency Index.** The availability of the Mission Dependency Index (MDI) is the result of ongoing U.S. Navy research to develop a process for computing a 0-100 index that measures how critical the facility is to the overall mission of its owner. This measure allows user input to shape an automated planning process that uses metrics and rules to identify and prioritize budget allocations and work plans. See ["About the Mission Dependency Index" on page 72](#) for more information about the MDI.

Note: As of July 2016, the MDI is currently not calculated within BUILDER. See the following section, ["How To Enter or Change the Mission Dependency Index \(MDI\)" below](#).

How To Enter or Change the Mission Dependency Index (MDI)

To enter or change the MDI,

1. First check the override box at the Building's **General Information** tab:

The screenshot shows the 'General Info' tab of a building's record. The 'Mission Dependency Index' section on the right contains an input field for the MDI score and a checkbox to override automated updates. The checkbox is checked and highlighted with a red rectangle.

2. Next, enter the desired MDI score in the entry box above the checkbox.
3. Finally, activate the **Save** icon in the content area toolbar.

Index Data (Read-Only)

All of the indices below are updated every time a rollup is performed.

- **Building Condition Index (BCI).** The BCI measures the condition of the Building as a whole. It is computed by averaging the condition indices of the Building's Systems, weighted by the replacement costs of the systems.

- **Building Functionality Index (BFI).** The BFI measures the functionality of the Building as a whole. It is computed from the results of a functionality assessment of the Building as a whole.
- **Building Performance Index (BPI).** The BPI measures the overall performance of the Building as a whole. It is computed using a weighted combination of the BCI and BFI.
- **Facility Condition Index (FCI).** The FCI metric provides an overall sense of deferred repair work. It differs from the BCI in that it is a monetary based metric. The formula is: $FCI = (1 - \text{\$/current repair needs} / \text{\$/PRV}) \times 100$, where the dollar amount of repair needs is obtained from BUILDER work items. More information about the FCI is available at ["Appendix B: Facility Condition Index" on page 192.](#)

Status

- **Historic Building (Read-Only).** This checkbox indicates whether or not the Building is historic. It is automatically marked if a functionality assessment has been performed in the Building and it has been determined that the Building is historic or has cultural resources in the Building.

Note: This feature is not selectable. It is calculated by BUILDER.

- **Child-Occupied Facility.** This checkbox indicates whether or not the facility is child-occupied. You can mark or un-mark this box as appropriate.
- **High Security.** This checkbox indicates whether or not the facility is deemed High Security. You can mark or un-mark this box as appropriate. Because working at a high security location generally increases labor time and other costs, this feature will apply higher security-related cost factors if the cost books have been set up for this in advance.

Note: This feature will have no effect unless the cost books have been appropriately modified.

- **Additional Access.** This checkbox indicates whether or not the facility has access issues, such as radioactivity or remote location. You can mark or un-mark this box as appropriate. Because working at a location with access issues generally increases labor time and other costs, this feature will apply higher access-related cost factors if the cost books have been set up for this in advance.

Note: This feature will have no effect unless the cost books have been appropriately modified.

Additional Information Tabs

See ["Edit Additional Building Inventory Data" below](#) for details available at additional information tabs in the Building level.

Edit Additional Building Inventory Data

This topic describes information available at all of the Building screen tabs except the **General Information** tab. Information at the General Information tab is described in the topic [Building General Information Tab](#).

Additional Building data is displayed and can be edited at the **Additional Information**, **Assessment History**, **Work Item History**, **Systems at a Glance**, **Cost Modifiers**, and **Attachments** tabs when a Building is selected in the inventory tree.

Additional Information Tab

Additional information shown at this tab includes address, point of contact, architect, contractor, and documents information for the Building, plus various Building dimensions, if they have been entered.

To view or edit this information, select the **Additional Information** tab on the Building screen:

The screenshot displays the Sustainment Management Systems WITH BUILDER interface. The top navigation bar includes 'Work Configuration', 'Work Plan', 'Scenarios', 'Reports', and 'Tools'. The left sidebar shows an 'Inventory' tree with a hierarchy: Sample > Sustainment Management System > 010 - Sample Site > 011 - Sample Org > 012 - Sample Site 01 > 001 - Building One (selected). The main content area shows the 'Additional Info' tab for '001 - Building One'. The tab is highlighted with a red box. The form contains the following fields:

- Building No: 001
- Building Name: Building One
- General Info (tab)
- Additional Info (tab, highlighted with a red box)
- Assess. History (tab)
- Work Item History (tab)
- Systems at a Glance (tab)
- Attachments (0) (tab)
- POC Name: [text box]
- Phone: () - -
- E-Mail: [text box]
- Street: [text box]
- City: [text box]
- State: [text box] Zip: - -
- Architect: [dropdown menu]
- Contractor: [dropdown menu]
- Documents: [dropdown menu]
- Building Dimensions: [text box] LF
- Table with columns: Description, Length, Width. No records to display.

All of the additional Building information is optional and includes:

Point of Contact

- **POC Name.** The name of the point of contact for the Building. Limit: 30 characters.
- **Phone.** The Building POC's phone number. Limit: 20 characters.
- **Email.** The Building POC's Email address. Limit: 75 characters.

Address

- **Street.** The Building's street address. Limit: 30 characters.
- **City.** The city portion of the Building's address. Limit: 15 characters.
- **State.** The state portion of the Building's address. Limit: 2 characters.
- **Zip.** The zip code of the Building's address. Limit: 10 characters.

Building Design

- **Architect.** Lists the architects of the Building. Add and delete names by using the adjacent buttons. Each architect's name is limited to 30 characters.
- **Contractor.** Lists the contractors of the Building. Add and delete names by using the adjacent buttons. Each contractor's name is limited to 30 characters.
- **Documents.** Lists the documents related to the Building. Add and delete document names by using the adjacent buttons. Each document's name is limited to 24 characters.

Dimensions

Building Dimensions

Building Perimeter: LF

Add

	Description	Length	Width	
	New Dimension	0	0	

The "Building Dimensions" area contains information about perimeter, description, length, and width. The Building perimeter can be entered directly in the form field; however, for Description, Length, or Width, see instructions below about adding or editing an entry.

Add an Entry

If there are no entries in the Description/Length/Width table, activate the **Add** button above the table, then select the pencil icon in the leftmost column of the table to enable data entry. When finished with entry, make sure to activate the blue check mark to the left of the entry, then **Save** at the content area toolbar.

Alternatively, if you wish to cancel the entry, select the red no-entry button below the blue check mark. This will erase any data you have entered into the table, but that row of the table will persist unless you fail to activate **Save** at the content area toolbar.

Edit an Entry

If there is an entry you wish to edit in the Description/Length/Width table, select the pencil icon of that entry to enable editing. When you are finished editing, make sure to activate the blue check mark to the left of the entry, then **Save** at the toolbar.

Alternatively, if you wish to cancel the edit, activate the red no-entry button below the blue check mark.


The following information can be added or edited here:

- **Perimeter.** Enter the linear measure of the perimeter of the Building.
- **Description.** Enter a description of the distinct areas of the Building you wish to add dimensions for. For example, you may list "East Wing/West Wing," or "Offices/Library/Warehouse," or "Public Areas/Secure Areas." Each description is limited to 50 characters.
- **Length.** Enter the length of the area identified in the description.
- **Width.** Enter the width of the area identified in the description.

Note: The unit of measure is indicated just after the Building Perimeter field above the table.

Assessment History Trends Tab

This tab displays two graphs showing how different metrics in the Building have changed over time. The graph on the displays the condition, functionality, performance and FCI history of the Building (by displaying the BCI, BFI, BPI, and FCI) from the year the Building was constructed to the current fiscal year.



Work Item History Tab

This tab shows a list of the work items that have been performed and/or are scheduled to be performed in the Building. The work items can be filtered by FY, status, System, Component, or Section using the dropdown lists on the screen.

For more information on work items, see the Work Planning Overview in the *Work Planning Guide* (not yet published) or consult the online help documentation.

Save Comment Reports 002 - Main Headquarters Philadelphia 0009 - Lodgings 00091 - Comm

Building No: 00091 Building Name: Committee Lodging A

General Info Additional Info Assess. History **Work Item History** Systems at a Glance Attachments (0)

Export

FY: - All - System: - All -

Status: - All - Component: Section:

Description	Activity	Cost	Status
No records to display.			


- .doc
- .pdf

Note: As of March 7, 2019, .doc format is allowed, but not .docx.

Attach a File


To attach a file,

1. At the **Attachments** tab, activate the  **Add** button in the toolbar below the row of tabs.



The screenshot shows a software interface with a toolbar at the top containing 'Save', 'Comment', and 'Reports' buttons. Below the toolbar, there are input fields for 'Building No: 55555' and 'Building Name: High Five'. A row of tabs includes 'General Info', 'Additional Info', 'Assess. History', 'Work Item History', 'Systems at a Glance', and 'Attachments (0)'. The 'Attachments (0)' tab is active, and within its toolbar, the 'Add' button (represented by a document icon with a plus sign) is highlighted with a red rectangular box. Below the tabs, there is a table with columns 'Title' and 'Description', and a message 'No records to display.'

This will open the "Add Image" popup window:



The screenshot shows a 'Add Image' popup window. It has a title bar with 'Add Image' and a toolbar with 'Cancel', 'Save', and 'Help' buttons. Below the toolbar, there are three text input fields labeled 'Title:', 'Description:', and 'Image:'. The 'Image:' field is followed by a 'Select' button, which is highlighted with a red rectangular box.

2. Enter Title and Description information for the attachment.
3. Activate the **Select** button to the right of the "Image" field to browse to the desired image or other file.
4. If you are adding an attachment at the Building level, use the "Image Type" radio buttons to indicate whether the attachment is a Key Plan, a Section Plan, or "Other."

5. Once the required attachment data is entered,
 - a. Activate the **Save** button on the popup toolbar.
 - b. Alternatively, to close the popup window without attaching the selected file or image, activate the **Cancel** button.


Delete a Building


This topic shows how to delete a Building. It also recommends an alternative to deletion that preserves Building records without allowing them to affect the calculation of indices.


Permissions Note: This action requires Work Planner permission or above for the relevant location in inventory.

To delete a Building, navigate to it in the inventory tree and do one of the following:

- a. Right-click the Building. Then select "Delete Building" from the options, as shown here:



- b. Alternatively, select the Building, then activate the **Delete Building** icon  on the menu toolbar:



WARNING: Deleting a Building deletes all the inventory (Systems, Components, and Sections) in the Building. This is a significant step to take and should only be done when you are certain that you wish to clear the entire inventory of the Building you have selected. Making frequent backups of your inventory database will protect you from significant data losses if mistakes in deleting are made.

Best Practice Recommendation: Instead of deleting a Building, you can use the [Current Status](#) property to mark buildings that have been demolished or transferred to another owner. With this method, the Building's records remain in the database, but the Building is ignored in processes that should only consider current buildings. See ["Use Current Status to Track Non-Current Inventory" on page 75](#).

About the Mission Dependency Index

The Mission Dependency Index (MDI) is a risk-based metric to link facilities to specific mission elements, and it measures how important a particular Building or facility is to the mission.

Each Building can have an MDI score in the 0-100 range, where 100 is most critical and 0 is least critical. With such a score available, the most critical Buildings can be easily identified, especially by the automated computer decision processes used by BUILDER.

The Mission Dependency Index is typically obtained from an organization's real property database of record. For those organizations where the MDI is not a real property data element, the score can be entered directly on the Building Summary screen, as shown in "[How To Enter or Change the Mission Dependency Index \(MDI\)](#)" on page 62.

For more information about determining the score for the Mission Dependency Index, users can refer to the following links:

<http://ascelibrary.org/doi/pdf/10.1061/9780784409589#page=152>

http://www.assetinsights.net/Glossary/G_Mission_Dependency_Index.html

<http://www.dtic.mil/dtic/tr/fulltext/u2/a552791.pdf>

The MDI was developed by the Naval Facilities Engineering Command Engineering Service Center (Antelman and Miller 2002) and the U.S. Coast Guard Office of Civil Engineering. MDI scores identify the severity of loss of mission-enabling facilities and infrastructure.

About the Building Current Status Property

The Current Status property of a Building allows you to maintain database records for Buildings not currently in your physical inventory, whether for historical purposes or future planning. A Building's current status is used in the decision processes of both BUILDER and Scenarios, and it is the basis for a number of useful capabilities, including allowing you to:

- Define policies so that Buildings scheduled for demolition are maintained at a lower standards than might generally apply. Simply use the Current Status as one of the attributes used to define a policy and assign standards as appropriate to each status type.
- Define work prioritization schemes that consider future changes in a Building's status in prioritizing work items. This can be done by using the Current Status property as an initial split in your prioritization scheme and assigning

weights appropriate for each status type (probably using 0 weight for non-current status types).

- Plan for the maintenance load of Buildings to be added to your inventory in the future by analyzing a Scenario.
- Change the status of a Building dynamically during a Scenario simulation to study the effects of a changing inventory on the budget and the work load.

The Current Status property is set on the [Building Summary](#) screen. Local variation (typically an added option) is possible due to database customization, but generally this property has one of the following values:

Building No: 00091 Building Name: Committee Lodging A

Building Use: DOE 300 - Visitor Housing

Building Type:

Current Status: **Active**

Construction Type:

Area:

Year Constructed:

Number of Floors:

ISR Rating:

Replacement Cost: \$0

Check box to override automated updates and manually enter replacement cost: ☐

Mission Dependency Index

MDI:

Check box to override automated updates and manually enter MDI: ☐

Condition

Metric	Value
BCI	37
BFI	100
BPI	100
FCI	100

Status

☐ Historic

☐ Child-Occupied Facility

☐ High Security

☐ Additional Access

Functionality

Issue	Rating
Location	N/A
SubIssueOne	N/A
Building Size and Configuration	N/A
Cultural Resources	N/A
Structural Adequacy	N/A

- **Active.** This is the default status. Use this status for Buildings that are currently in use. This status is the end status for Buildings with status "To be built" or "To be acquired."
- **Demolished.** Use this status to remove a Building from BUILDER's automated processes for condition/service life assessment and work planning but leave the inventory and inspection records intact. *The effective year for this status is the year in which the Building is demolished.* This status is the end status of the "To be demolished" status.
- **To be acquired.** Use this status to enter inventory records for an existing Building prior to its acquisition. *The effective year of this status is the year in which the Building is expected to be acquired.* You will be able to edit the Building and inspection data for this type of Building, and BUILDER's condition and remaining service life predictions will be applied based on the inspection data entered. In this way, you will be able to estimate the

maintenance requirements of such a Building prior to its acquisition. In a Scenarios simulation, this feature allows you to acquire Buildings as the simulation progresses.

- **To be built.** Use this status to enter inventory records for a new Building prior to its commissioning for occupancy. *The effective year of this status is the year in which the Building is expected to be recognized as part of your physical inventory.* In BUILDER, you will be able to edit the Building data on the Building Summary screen but will not be able to add inspection records until the status changes to "Active." In a Scenarios simulation, this feature allows you to add new Buildings dynamically as the simulation progresses.
- **To be demolished.** Use this status for Buildings that will be demolished in the future. *The effective year of this status is the year in which the Building is to be demolished.* In a Scenarios simulation, a Building-level work item to demolish the Building will be generated, including a cost estimate for the work. In addition, maintenance policies may be associated with this status that lower the standards usually required for this type of Building.
- **To be transferred.** Use this status for Buildings that will be transferred to another owner in the future. *The effective year of this status is the year in which the transfer will take place.* No BUILDER or Scenarios cost is associated with such a transfer. However, maintenance policies may be associated with this status that yield different standards than would ordinarily be in effect.
- **Transferred.** Use this status to force BUILDER's automated processes for condition/service life assessment and work planning to skip the Building but leave the inventory and inspection records intact. *The effective year for this status is the year in which the transfer takes place.* This status is the end status of the "To be transferred" status.
- **Vacant.** This status replaces the **Vacant** checkbox property used in earlier versions of BUILDER. Use this status for Buildings that are currently in your physical inventory but not in use.

Four of these values indicate that the designated Building is not currently part of the inventory: **To be acquired**, **To be built**, **Transferred**, and **Demolished**.

Two other status values (**To be transferred** and **To be demolished**) indicate that the Building will be removed from the inventory in the future.

At the current time, **Active** and **Vacant** are treated the same by BUILDER.

The Current Status property allows you to enter future Buildings into the inventory and to plan for their maintenance in Scenarios even though they are not presently owned. In addition, the Current Status property allows you to keep records for Buildings that are no longer in the physical inventory. Such records are ignored in

processes that should only consider current Buildings, such as condition rollups and work planning.

Best Practice Recommendation: When you delete a Building, you actually remove all database records associated with that Building. If you wish to keep the records, whether for historical purposes, analysis, or possible transfer to another BUILDER database (perhaps the Building is being transferred from one property book to another), you should simply set the Current Status property to an appropriate value.

Use Current Status to Track Non-Current Inventory

This topic shows how the Current Status property can be used to keep historical records of demolished or transferred Buildings, or to anticipate short-term and long-term needs for Buildings about to be built or otherwise acquired.

The Building-level Current Status property allows you to have records in your BUILDER database for Buildings that are not currently in your physical inventory. This is useful for Buildings at both ends of the lifecycle. You may keep records for Buildings that have been demolished or transferred, and you may add Buildings planned for future construction or acquisition.

Add Future Buildings

Using the Current Status property, it is possible to enter Buildings into the database before they are actually in the physical inventory. This includes Buildings under construction (designated with status "To be built") and existing Buildings being considered for acquisition from another owner (designated with status "To be acquired").

"To Be Acquired"

By setting the Current Status property to "To be acquired" and entering data in advance, you will be able to anticipate short-term work requirements for existing Buildings about to be acquired. In BUILDER, the "To be acquired" status can also be used to plan long-term maintenance requirements for future Buildings using Scenarios.

Enter Inventory Records

Use this status to enter inventory records for a new Building prior to its acquisition.

Record Inspection Results

Once you have entered inventory records for a Building with status "To be acquired," you may record inspection results prior to acquisition. The BUILDER processes that determine remaining service life and condition prediction will track the condition of the Building after it is first entered and prior to its acquisition.

Generate a Work Plan

With inspection results, BUILDER will be able to generate a work plan for the Building to upgrade it (or its roofing, in the case of ROOFER) to your established standards. Such information could be invaluable in planning for the load such a Building will place on both short and long term budgets.

"To Be Built"

Enter Inventory Records

Use this status to enter inventory records for a new Building prior to its commissioning for occupancy.

No Recording of Inspection Results

If you enter a Building with status "To be built," you may not record new inspections until the status changes to "Active." The BUILDER processes that determine remaining service life and condition prediction will skip such a Building under the assumption that quality assurance during the construction process will force all Systems to a condition index of 100 prior to commissioning.

Use Scenarios to Simulate "Active" Status (BUILDER Only)

The advantage of entering the Building before it is built is that you may include it in Scenarios to measure its long-term effects on work plans and budgets. That is, the Scenario can change the status of a new Building to "Active" at a scheduled time and begin treating it as a normal Building with predictable deterioration rates and work requirements.

Keep Records of Past Buildings (Demolished, Transferred)

In earlier versions of BUILDER, the only way to exclude a Building from automated assessment and planning processes was to [delete the Building](#). With this approach, all records related to the Building were actually deleted from the database.

Now, the Current Status property gives you another option.

If you have records in the BUILDER database for a Building which is to be demolished or transferred to another owner, you can keep the inventory, inspection, and work history records in the database, while at the same time making the Building invisible to BUILDER's automated processes, simply by changing the Building's status to "Demolished" or "Transferred."

Best Practice Recommendation: When you delete a Building, you actually remove all database records associated with that Building. If you wish to keep the records, whether for historical purposes, analysis, or possible transfer to another BUILDER database (perhaps the Building is being transferred from one property book to another), then you should simply set the Current Status property to the appropriate value, either "Demolished" or "Transferred."

Below is a summary of what happens when a Building has the status of either "Demolished" or "Transferred":

- **Inventory records are locked.** You will be unable to change the Building's data properties or its composition.
- **Condition and Functionality Assessment records are locked.** You will be unable to change existing records or to add new records.
- **Functionality Assessment records are locked (BUILDER only).** You will be unable to change existing records or to add new records.
- **Work Planning records are locked.** You will be unable to change existing records or to add new records.
- **Cost data is not updated.** The Building's cost data will not be affected by annual cost updates at the beginning of the calendar year.
- **The RSL and CI or RCI values will not be updated** for the Building.
- **The Building will not be considered during automatic work generation.**
- **The Building will not appear in Scenarios simulations (applies to BUILDER only).** If the Building's status is changed to "Demolished" or "Transferred" during a Scenarios simulation, it will have records for the years prior to its status change and then after that date in the Scenario, it will be treated as above. That is, there will be no further updates of data, no new inspections, no changes in condition or service life, etc.

About Identifying Systems, Components and Sections

This topic provides valuable advice to assist in the process of dividing Buildings into their constituent Systems, Component, and Component-Sections.

After you ["Add a Building" on page 55](#) and have entered its required data elements, you should identify the Systems, Components and Sections in the Building. Your decomposition of a Building into its Systems and the decomposition of those Systems into Components will be very straightforward. The formation of Sections, however, will require some thought on your part. BUILDER manages Buildings at the Section level, and you will inspect Sections and plan work for Sections.

BUILDER's representation of Building Sections has been designed to be very flexible. With flexibility comes choices; choices that add complexity to the process. Pay particular attention to the ["Defining Sections" on the facing page](#) subsection.

As an alternative option to adding all Systems, Components, and Sections manually, BUILDER provides several mechanisms to speed the inventory process. For example, you can ["Copy Inventory to Another Building" on page 145](#) or ["Add Building Inventory Using a Template" on page 153](#).

Defining Systems

Systems are used to help you organize the records for the actual physical items in your Building. You may create only one System of each System type for any given Building. When you add a new System to a Building, the dropdown list of choices for which kind of System to add will include only those Systems that have not already been added to the Building. See ["Add, View, or Delete a System" on page 86](#) for details.

Defining Components

Like Systems, Components are used to help organize the records of the actual physical items in the Building. The Components that can be added to a System will depend on the System representation you have chosen for the Building. You may create only one Component of each type for each System. In creating a new Component, the list of choices will only include those Components of the appropriate System that have not already been created. See ["Add, View, or Delete a Component" on page 95](#) for details.

If you have a Component that is not in the list of available Component types, please contact your SMS support agent. BUILDER does not have a feature for user-defined Components. Each Component has a number of data elements associated with it (varieties of types and materials, costs, service lives, standard units of measure, inspectable subcomponents, etc.) which must be researched before the Component can be added.

Defining Sections

Building Sections are the key structures in a BUILDER inventory. The System and Component structures are organizational in nature, serving to categorize what is in a Building into manageable groups. Building Sections actually represent the physical items of a Building, belong to a particular Component, and have the following properties:

- Component Type
- Material/Equipment Type
- Quantity
- Age
- Whether or not it is painted, and, if so, when it was last painted and paint type

BUILDER has been designed to be flexible in allowing you to represent your Building's Sections in a number of ways to support how you intend to manage them. Some examples may be helpful:

- Building A has 5 exterior doors (System: Exterior Closure, Component: Exterior Door). Four of the doors are metal personnel doors and the fifth is a metal overhead door. Because there are two different types of doors (personnel, overhead), you will have to create at least two Sections. In this situation, you should create a Section for the metal overhead door and enter the appropriate data about it. You don't need to create a Section name for this door since there is only one. For the four metal personnel doors, if you intend to manage them as a unit, create one more Section and enter the appropriate data about the doors. Again, you don't need to enter a Section name because you are only creating one Section of this material and type.
- Building A has 5 exterior doors (System: Exterior Closure, Component: Exterior Door). You lease Building A to two tenants X and Y. Two metal personnel doors and a metal overhead door are in the tenant X area, and the other two metal personnel doors are in the tenant Y area. Because you plan to inspect and maintain the doors by tenant, you create three Sections:
 - Tenant X Metal Personnel with quantity 2

- Tenant X Metal Overhead with quantity 1
- Tenant Y Metal Personnel with quantity 2.

When you create each Section for Tenant X, you use "Tenant X" as the name of the Section. Do the same for Tenant Y. In fact, you may want to name every Section (especially Interior Construction Sections) in the Tenant X area "Tenant X." When you inspect the Building, you can use the Section name to distinguish Sections belonging to each of the tenants.

- Building A has two reciprocating 20-ton chillers (System: HVAC, Component: Cooling Unit/Plant). If they are the same age and you plan to manage them as a unit, then create one Section with quantity 2. However, if you want to manage them individually, or if they were installed at different times and may therefore have different maintenance requirements, then create two Sections of quantity 1 each. Since both Sections have the same equipment type (Reciprocating 20-30 Ton) and component type (Chillers), you will have to have distinct Section Names for the two Sections. You may use their barcode IDs as the Section names of your wish.
- Building B has 50 interior wood personnel doors, all alike and all installed when the Building was built. You originally create one Section with quantity 50 for these doors. You may have several years of inspection data regarding the doors, which have deteriorated uniformly over time. With the current inspection, however, two of the doors are found to be severely damaged and will have to be replaced. If the two doors remain in their original Section, inspection samples for these two doors will have to be marked as "non-representative." When the condition index is calculated, the condition of the two doors, which are only 4% of the Section, will have only a small impact on the overall Section CI. Since you will be replacing the two doors, perhaps with a different quality of door since they may be subject to higher user abuse, you should use component sectioning to isolate the two doors. To do this, reduce the original Section quantity to 48. Then create a new Section for the two damaged doors and enter the current inspection data for this new Section, which will then have a low CI.

From these examples you can see that some thought will have to be given to how you decompose a Building into Sections. Hopefully, you can also see that BUILDER is flexible enough to allow you to manage at the level of detail that you choose. See ["Add, Edit, or Delete a Section" on page 104](#) for details.

Inventory Suggestions

It is not necessary to do a complete inventory initially. Implementation funds and/or time may be limited, so it is possible and permissible to begin with only some of the Component-Sections and expand the inventory on an as-needed

basis. If the desire is to begin with a limited set, the following suggestions are made:

- Focus on the Components that are most critical to Building function
- Focus on the Components that traditionally dominate Maintenance and Rehabilitation (M&R) needs.

When sectioning, a few rules of thumb are offered:

- To avoid a data burden, use the smallest number of Sections possible to meet managerial needs. For example, it is usually not necessary to individually Section every room, each exterior wall, etc.
- Since material differences (e.g. wood vs. masonry) are criteria for sectioning, only create Sections for material differences when the quantity is significant enough to warrant individual management attention. For example, an exterior wall may be made of wood, but a few square feet of wall is made of masonry, essentially for decoration. The wood wall is clearly a Section, but what about the masonry? Should it be its own Section? If the masonry quantity is a mere fraction of the wood and work would be accomplished on the masonry at the same time as the wood (in other words, the entire wall is being managed as a unit), then there is no need to create a Section just for the masonry. However, if the quantities of both the wood and masonry are significant, then create Sections for both.
- Equipment sectioning should be thought out carefully when multiple units of the same equipment are present. For example, there may be three air handling units of the same type, age, etc. In this case, there could be one Section with the quantity of three, or three Sections with the quantity of one. Which approach should be taken? If the desire is to manage them as essentially one unit as far as planning repair and replacement, then one Section will suffice. However, if it is expected that over time, they will be replaced individually, etc, then each should be its own Section.
- Obtaining accurate an accurate quantity can be difficult, and often times there are many sources for obtaining quantity. These include drawings, actual measurement or count, or other records. It must be understood that the more detailed or accurate the count or measurement, the more costly it is to collect the data. Extracting information from records, including drawings, and doing a field validation is the most costly. Reasonable estimates within reasonable error are very acceptable as it will result in reasonable error in BUILDER's analyses. For example, the wall finish may truly be 10,634 SF. An estimate of 11,000 SF will suffice for planning purposes especially if the cost to get the true value is twice that for an estimate. Component-Sections that cover an area (SF or SM) are the most difficult to obtain with precision whereas those that are "each" are the easiest.

Generally, field count the "each" Component-Sections and estimate the others. The estimates can be refined in the future when projects are developed for M&R work.

- *Care should be taken when establishing Year Built/Renewed.* Error here will result in erroneous remaining service lives and add error to the projected year when M&R should be performed. Experience has shown, however, that sometimes the year in which Component-Sections were replaced, rehabilitated, or initially installed/constructed is truly unknown as the records are no longer available. In those cases, make a reasonable estimate and mark the **Estimated** checkbox. Often, there are people who will remember when that work was done, at least in a generalized way (e.g. early 1990's). Fortunately, through subsequent inspections and condition assessments, the Year Installed/Built becomes less important, as BUILDER's prediction models will use the condition assessment information to adjust the remaining service life and to predict when M&R will be required in the future.

BUILDER Systems and Components

To divide a Building into Systems and Components, BUILDER follows the [Naval Facilities Engineering Command \(NAVFAC\) UNIFORMAT II classification](#) for building elements (Level 2 and 3).

Level 2	Level 3
A10 Foundations	A1010 Standard Foundations A1020 Special Foundations A1030 Slab on Grade
A20 Basement Construction	A2010 Basement Excavation A2020 Basement Walls
B10 Superstructure	B1010 Floor Construction B1020 Roof Construction
B20 Exterior Closure	B2010 Exterior Walls B2020 Exterior Windows B2030 Exterior Doors
B30 Roofing	B3010 Roof Coverings (Note: Roof openings are a subcategory of Roof Coverings)
C10 Interior Construction	C1010 Partitions C1020 Interior Doors C1030 Specialties
C20 Stairs	C2010 Stair Construction
C30 Interior Finishes	C3010 Wall Finishes C3020 Floor Finishes C3030 Ceiling Finishes C3040 Interior Coatings and Special Finishes
D10 Conveying	D1010 Elevators and Lifts D1020 Weight Handling Equipment D1030 Escalators and Moving Walks D1090 Other Conveying Systems
D20 Plumbing	D2010 Plumbing Fixtures D2020 Domestic Water Distribution D2030 Sanitary Waste D2040 Rain Water Drainage D2090 Other Plumbing Systems

D30 HVAC	D3010 Energy Supply D3020 Heat Generating Systems D3030 Cooling Generating Systems D3040 Distribution Systems D3050 Terminal & Package Units D3060 Controls & Instrumentation D3070 Systems Testing & Balancing D3080 HVAC Valves D3090 Other HVAC Systems & Equipment
D40 Fire Protection	D4010 Fire Alarm and Detection Systems D4020 Fire Suppression Water Supply and Equipment D4030 Standpipe Systems D4040 Sprinklers D4050 Fire Protection Specialties D4090 Other Fire Protection Systems
D50 Electrical	D5010 Electrical Service & Distribution D5020 Lighting & Branch Wiring D5030 Communication & Security D5090 Other Electrical Services
E10 Equipment	E1010 Commercial Equipment E1020 Institutional Equipment E1030 Vehicular Equipment E1090 Other Equipment
E20 Furnishings	E2010 Fixed Furnishings E2020 Movable Furnishings
F10 Special Construction	F1010 Special Structures F1020 Integrated Construction F1030 Special Construction Systems F1040 Special Facilities F1050 Special Controls and Instrumentation
F20 Selective Building Demolition	F2010 Building Elements Demolition F2020 Hazardous Components Abatement
G10 Site Preparations	G1010 Site Clearing G1020 Site Demolition & Relocations G1030 Site Earthwork G1040 Hazardous Waste Remediation

G20 Site Improvements	G2010 Roadways G2020 Parking Lots G2030 Pedestrian Paving G2040 Site Development G2050 Landscaping G2060 Airfield Paving
G30 Site Civil/Mechanical Utilities	G3010 Water Supply G3020 Sanitary Sewer G3030 Storm Sewer G3040 Heating Distribution G3050 Cooling Distribution G3060 Fuel Distribution G3090 Other Site Mechanical Utilities
G40 Site Electrical Utilities	G4010 Electrical Distribution G4020 Site Lighting G4030 Site Communication and Security G4090 Other Site Electrical Utilities

Working with Systems

Add, View, or Delete a System


The System level in the BUILDER hierarchy is what allows your real property inventory to conform to Level 2 of the UNIFORMAT II system shown in ["BUILDER Systems and Components" on page 83](#). This topic describes the operations that can be performed at the System level.

Tip: Please be familiar with the topic [Identifying Systems, Components and Sections](#) before proceeding with this topic.


Add a System

To add a new System to an existing Building, navigate to the Building in the inventory tree and do one of the following:

- Right-click the Building. Then select "Add System" from the options.
- Alternatively, as shown below, select the Building (1). Then activate the **Add System** icon (2) on the main toolbar:



The "Add Building System" popup window will appear.



Activate the dropdown list and select the System you wish to add to the Building. Then activate the **Add** button on the popup toolbar to add the System. If you do not wish to add a System to the Building, activate the **Cancel** button instead.

Note: Each Building can contain only one System of each type. The dropdown list for adding a System will display only the System types that don't already exist in the Building.

System Data

Once the System is added, you can navigate to it in the tree and activate it to view or edit its data, or to add attachments.

At the top of the System data page you will see the System description. The System Condition Index (SCI) and System replacement cost field will be blank until underlying inventory has been entered and a rollup has been performed. The replacement cost is calculated via rollup from the underlying Sections.



Additional information regarding the System is found at these tabs:

- **Condition Analysis Tab**
- **Components at a Glance Tab**
- **Cost Modifiers Tab**
- **Attachments**

These tabs are described in ["View a System" on page 90](#).

Attach a File

At the **Attachments** tab on the System's data page, you have the option to attach files to the System's record. An attached file might be a photograph, an electronic image of written notes or diagrams made during inventory, or a file generated on a computer.

Acceptable Attachment Formats

The attachment may be in any of the following formats:

- .jpg
- .jpeg
- .png
- .zip
- .doc
- .pdf

Note: As of March 7, 2019, .doc format is allowed, but not .docx.

Attach


To attach a file,

1. At the **Attachments** tab, activate the  **Add** button in the toolbar below the row of tabs.



The screenshot shows a software interface for managing system records. At the top, there's a header bar with a folder icon and the word "Reports". Below this, the record details are displayed: "Description: D30 HVAC", "SCI: 99" (with "99" in a green box), and "Replacement Cost: \$104,000.00". A row of tabs is visible: "Condition Analysis", "Components at a Glance", and "Attachments (0)". The "Attachments (0)" tab is selected. Below the tabs is a toolbar with two buttons: "Add" (with a document and plus icon) and "Delete" (with a red X icon). The "Add" button is highlighted with a red rectangle. Below the toolbar is a table with a single column header "Title". The table content area displays the message "No records to display."


This will open the "Add Image" popup window:




2. Enter Title and Description information for the attachment.
3. Activate the **Select** button to the right of the "Image" field to browse to the desired image or other file.
4. If you are adding an attachment at the Building level, use the "Image Type" radio buttons to indicate whether the attachment is a Key Plan, a Section Plan, or "Other."
5. Once the required attachment data is entered,
 - a. Activate **Save** on the popup toolbar.
 - b. Alternatively, to close the popup window without attaching the selected file or image, activate the **Cancel** button.

Troubleshooting

If the selected attachment is in an acceptable format, the "Image" field will be replaced with a green dot (plus a label that gives you the option to remove the attachment).



However, if it is not in an acceptable format, the "Image" field will be replaced with a red dot. Activate "Remove" and select an attachment file in one of the formats listed at ["Acceptable Attachment Formats" on the previous page](#).




Add Image

Cancel Save Help

Title: docx

Description: Need doc, not docx


Image:  Test-doc.docx Remove

View a System

Data for an existing System can be viewed by selecting the System in the inventory tree. At the top of the content area, the System description, System Condition Index (SCI), and System replacement cost are shown. Additional information regarding the System is found at the tabs described below.

Condition Analysis Tab

The Condition Analysis tab displays a graph of the CI history of the System over time.



Components at a Glance Tab

Basic information regarding the Components in the System can be viewed by selecting the "Components at a Glance" tab. The table at this tab shows:

- The Components inventoried in the System,
- Each Building Component's condition index (BCCI), and
- The replacement cost of each Component.

The replacement cost is computed from BUILDER's cost models based on Component type and quantity, and the BCCI is computed based on condition assessment data for the Sections contained in the Component.

All of the data shown at this tab is read-only.

Reports		
Description: B20 EXTERIOR ENCLOSURE	SCI: 84	Replacement Cost: \$258,637
Condition Analysis	Components at a Glance	Attachments (0)
Description	BCCI	Replacement Cost
B2010 EXTERIOR WALLS	93	\$230,695
B2030 EXTERIOR DOORS	8	\$27,942

Cost Modifiers Tab

The **Cost Modifiers** tab allows you to view and assign cost multipliers or adders.

Attachments Tab

The **Attachments** tab will show whether any files have been attached to the System's record. The number in parentheses after the word "Attachments" shows how many of them have been attached. An attachment might be a photograph, an electronic image of written notes or diagrams made during inventory, or a file generated on a computer.

To view one or more attachments,

1. Navigate to/activate the **Attachments** tab. *If attachments are present, a table will display their type, title, and description.*
2. Activate the link in the **Title** column. *The attachment will appear in the "Image Viewer" popup window.*
3. When finished viewing, activate the **Close** button on the popup window toolbar. and you will be returned to the table of attachments.
4. Repeat the two steps immediately above for additional attachments as desired.

Edit a System

The only changes that can be made at the System level are to add an attachment, remove an attachment, or to edit the title and/or description of an attachment.

You can edit the title and/or description of an attachment as follows:

1. Navigate to the **Attachments** tab to view the attachments table.
2. Activate a link in the **Title** column. *The attachment will appear in the "Image Viewer" popup window.*
3. In the header section above the attachment, make the desired changes in the **Title** and/or **Description** field(s).
4. Activate **Save** on the popup toolbar to store your changes and return to the table of attachments.
5. Alternatively, if you want to cancel the change, activate **Close** on the popup toolbar. *You will be returned to the table of attachments.*





If you wish to change the contents of the attachment, you will need to delete the existing attachment file and add a new one.

For information about adding an attachment, see ["Attach a File " on page 88](#).

To delete an attachment,

1. Navigate to the **Attachments** tab to view the attachments table.
2. Select the attachment you wish to delete (do *not* activate the link in the **Title** column). *When properly selected, that record in the table will change background color as illustrated below:*


Description: B20 EXTERIOR ENCLOSURE SCI: 75 Replacement Cost: \$82,250.00


Condition Analysis	Components at a Glance	Attachments (2)	
 Add  Delete			
		Title	Description
		attach1	screenshot
		attach2	delete this one

3. Activate the **Delete** button above the table.
4. Activate **Yes** in the confirmation box to delete the attachment, or **No** to cancel.

Delete a System

To delete a System from a Building, navigate to the System in the inventory tree and do one of the following:

- Right-click the System. Then select "Delete System" from the options.
- Alternatively, select the System. Then activate the **Delete System** icon  in the menu toolbar.




WARNING: Deleting a System will delete all inventory (Components and Sections) in the System. This is a significant step to take and should only be done when you are certain that you wish to clear the entire inventory of the System you have selected.

Best Practice Recommendation: Making frequent backups of your inventory database will protect you from significant data losses if mistakes in deleting are made.

Reports Available at the System Level

When you activate the **Reports** button on the toolbar, the following selection of reports shown in the screen shot is available. To see the list of reports, activate the down arrow in the "Select a Report" text box.



To generate and view a report, select it in the list, then activate the **View Report** button.

See ["Generate a Report" on page 186](#) for more details.

Working with Components

Add, View, or Delete a Component


The Component level in the BUILDER hierarchy is what allows your real property inventory to conform to Level 3 of the UNIFORMAT II system shown in ["BUILDER Systems and Components" on page 83](#). This topic describes the operations that can be performed at the Component level.

Note: Please be familiar with the topic [Identifying Systems, Components and Sections](#) before proceeding with this topic.


Add a Component

To add a new Component to an existing System, navigate to the System in the inventory tree and do one of the following:

- Right-click the System. Then select "Add Component" from the options.
- Alternatively, as shown below, select the System in the inventory tree. Then activate the **Add Component** icon on the main toolbar:




The "Add System Component" popup window will appear.



From the dropdown list, select the Component you wish to add. Then activate the **Add** button on the popup toolbar to add the Component.

Alternatively, if you do not wish to add a Component to the System, activate the **Cancel** button instead.

Note: Each System can contain at most one Component of each type. The dropdown list for adding a Component will display only the component types that don't already exist for the System. If the System already contains all permissible Component types, you will see this message:



Component Data

Once the Component is added, you can navigate to it to view its data or add attachments.

At the top of the data page you will see the Component description. The (Building) Component Condition Index (BCCI) and Component replacement cost fields will be blank until underlying inventory has been entered and a rollup has been performed. The replacement cost is calculated via rollup from the underlying Sections.

Additional information regarding the Component is found at these tabs:

- **Condition Analysis**
- **Sections at a Glance**

- **Cost Modifiers**
- **Attachments.**

These tabs are described under ["View a Component" on page 99](#).

Attach a File

At the **Attachments** tab on the Component's data page, you have the option to attach files (images and other documents) to the Component's record. An attached file might be a photograph, an electronic image of written notes or diagrams made during inventory, or a file generated on a computer.

Acceptable Attachment Formats

The attachment may be in any of the following formats:


- .jpg
- .jpeg
- .png
- .zip
- .doc
- .pdf

Note: As of March 7, 2019, .doc format is allowed, but not .docx.


Attach

To attach a file,

1. At the **Attachments** tab, activate the  **Add** button in the toolbar below the row of tabs.




This will open the "Add Image" popup window:




2. Enter Title and Description information for the attachment.
3. Activate the **Select** button to the right of the "Image" field to browse to the desired image or other file.
4. If you are adding an attachment at the Building level, use the "Image Type" radio buttons to indicate whether the attachment is a Key Plan, a Section Plan, or "Other."
5. Once the required attachment data is entered,
 - a. Activate **Save** on the popup toolbar.
 - b. Alternatively, to close the popup window without attaching the selected file or image, activate the **Cancel** button.

Troubleshooting

If the selected attachment is in an acceptable format, the "Image" field will be replaced with a green dot (plus a label that gives you the option to remove the attachment).



If it is not in an acceptable format, the "Image" field will be replaced with a red dot. Activate "Remove" and select an attachment file in one of the formats listed at ["Acceptable Attachment Formats" on the previous page](#).




Add Image

Cancel Save Help

Title: docx

Description: Need doc, not docx


Image:  Test-doc.docx Remove

View a Component

Data for an existing Components can be viewed by selecting the Component in the inventory tree. At the top of the context area, the component description, Building Component condition index (BCCI), and component replacement cost are shown. Additional information regarding the component is found in the different tabs and is described below.

Condition Analysis Tab


The Condition History tab displays a graph of the CI history of the Component over time.



Sections at a Glance Tab

Basic information regarding the Sections in the Component can be viewed by selecting the "Sections at a Glance" tab. The table at this tab shows:

- The Sections inventoried in the Component,
- Each Component-Section's condition index (CSCI), and
- The replacement cost of each Section. All of the data shown at this tab is read-only.



Description: B2020 EXTERIOR WINDOWS BCCI: 75 Replacement Cost: \$78,000.00		
Condition Analysis Sections at a Glance Attachments (0)		
Description	CSCI	Replacement Cost
North windows B202001 WINDOWS Aluminum Windows	88	\$19,500
South windows B202001 WINDOWS Aluminum Windows	61	\$19,500
West windows B202001 WINDOWS Aluminum Windows	100	\$19,500
East windows B202001 WINDOWS Aluminum Windows	50	\$19,500

Cost Modifiers Tab

The **Cost Modifiers** tab allows you to view and assign cost multipliers or adders.

Attachments Tab

The **Attachments** tab will show whether any files have been attached to the Component's record. The number in parentheses after the word "Attachments" shows how many of them have been attached. An attachment might be a photograph, an electronic image of written notes or diagrams made during inventory, or a file generated on a computer.

To view one or more attachments,

1. Navigate to/activate the **Attachments** tab. *If attachments are present, a table will display their type, title, and description.*
2. Activate the link in the **Title** column. *The attachment will appear in the "Image Viewer" popup window.*
3. When finished viewing, activate the **Close** button on the popup window toolbar. and you will be returned to the table of attachments.
4. Repeat the two steps immediately above for additional attachments as desired.

Edit a Component

The only changes that can be made at the Component level are to add an attachment, remove an attachment, or to edit the title and/or description of an attachment.


You can edit the title and/or description of an attachment as follows:

1. Navigate to the **Attachments** tab to view the attachments table.
2. Activate a link in the **Title** column. *The attachment will appear in the "Image Viewer" popup window.*
3. In the header section above the attachment, make the desired changes in the **Title** and/or **Description** field(s).
4. Activate **Save** on the popup toolbar to store your changes and return to the table of attachments.
5. Alternatively, if you want to cancel the change, activate **Close** on the popup toolbar. *You will be returned to the table of attachments.*

If you wish to change the contents of the attachment, you will need to delete the existing attachment file and add a new one.



For information about adding an attachment, see ["Attach a File " on page 97](#).



1. Navigate to the inspection's **Attachments** tab to view the attachments table.
2. Select the attachment you wish to delete (do *not* activate the link in the **Title** column). *When properly selected, that record in the table will change background color as illustrated below:*



Description: B2020 EXTERIOR WINDOWS BCCI: 75 Replacement Cost: \$78,000.00

Condition Analysis Sections at a Glance Attachments (0)


 Add  Delete


	Title	Description
	attach2	delete this one
	attach1	screenshot

3. Activate the **Delete** button above the table.
4. Activate **Yes** in the confirmation box to delete the attachment, or **No** to cancel.

Delete a Component

To delete a Component, navigate to it in the inventory tree and do one of the following:

- Right-click the Component. Then select "Delete Component" from the options.
- Alternatively, select the Component, then activate the **Delete Component** icon  on the menu toolbar.




WARNING: Deleting a Component will delete all Sections in the Component. Be sure that you wish to take this action. This is a significant step to take and should only be done when you are certain that you wish to clear the entire inventory of the Component you have selected.

Best Practice Recommendation: Making frequent backups of your inventory database will protect you from significant data losses if mistakes in deleting are made.

Reports Available at the Component Level

When you activate the **Reports** button on the toolbar, the following selection of reports shown in the screen shot is available. To see the list of reports, activate the down arrow in the "Select a Report" text box.



To generate and view a report, select it in the list, then activate the **View Report** button.

See ["Generate a Report" on page 186](#) for more details.

Working with Sections


Add, Edit, or Delete a Section


The Section level in the BUILDER hierarchy is where inspections actually take place. This topic describes operations that can be performed at the Section level.

Note: Please be familiar with the topic [Identifying Systems, Components and Sections](#) before proceeding with this topic.

Add a Section

To add a new Section to an existing Component, navigate to the Component in the inventory tree and do one of the following:

- a. Right-click on the Component. Then select "Add Section" from the options.
- b. Alternatively, select the Component in the inventory tree. Then activate the  **Add Section** icon on the main toolbar:



The "Add Component Section" popup screen will appear.

Add Component Section

Cancel Add

Section Name: N/A

Equipment Category: A103001 STANDARD SLAB ON GRADE

Component Subtype: General

Quantity: SF

Year Install/Renewed: 1961 ☐ Estimated

Section Status: Active

Painted/Coated: ☐

Section Data

Before adding the Section, the following data must be recorded:

- **Section Name.** Enter the name of the Section. A Section is described by its name, its material/equipment category, and its Component subtype. You may have multiple Sections of the same material/equipment category and Component subtype, but each such Section must have a unique name. A given Section name may be used, however, for the Sections of different Systems and Components, which allows the Section name to be used in organizing your inventory and condition assessment procedures. For example, you may use the Section name "Room 101" for the floor, walls, doors, plumbing, HVAC etc. Sections in Room 101. When inspecting Room 101, all of the Building Sections with the name "Room 101" can be easily selected. To simplify the process of creating multiple types of Sections with the same Section name, the Section Name property includes a dropdown list of current Section names for the building. You may either type in a new Section name or choose a name from the dropdown list.
- **Material/Equipment Category.** Select the material/equipment category of the Section from the dropdown list. Each Component has a set of distinct material/equipment categories. For example, a "Door" Component has material categories "Wood," "Metal," "Glass," etc.
- **Component Subtype.** Select the Component subtype of the Section from the dropdown list. Each Component type and material/equipment category

has a set of distinct Component subtypes. For example, a "Door" Component with material category "Wood" has Component subtypes of "Personnel," "Overhead," etc.

- **Quantity.** Enter the quantity of the Section.
- **Year Install/Renewed.** Enter the four-digit year the Section was either (a) built or installed or (b) renewed.
- **"Estimated" checkbox.** If you have no record of the year the Section was installed or last replaced, you can enter an estimated year and mark the **Estimated** checkbox. Initially, BUILDER algorithms estimate the year the Section was last replaced. The default value is the Building's year of construction if the age of the building is less than 1.5 times the expected service life of the Section. If the estimating algorithm is used or you are unsure of when the Section was built or renewed, make sure you mark the **Estimated** checkbox.
- **Current Status (Optional).** A status field has been added to interface for the Component-Section inventory level. Here, a user can optionally assign a status to the Component. Current status options are shown in the drop-down list:

The screenshot displays the 'Section Details' tab of a software interface. It contains the following elements:

- Quantity:** 4,855 SF
- Year Install/Renewed:** 1961
- Estimated:** ☐
- Age:** 57
- RSL:** 0
- Current Status:** A dropdown menu is open, showing the following options: Active (highlighted), Archived, De-Activated, De-Commissioned, Missing, and Replaced.
- Painted:** ☐

- **Painted.** Mark this checkbox if Section is painted or has a surface coating. *Additional fields will appear below when this checkbox is marked, including BUILDER's estimate of remaining paint life (RPL).*
- **Year Painted.** If the Section is marked as painted, enter the four-digit year the Section was last painted or coated. If you have no record of the year, you can enter an estimated year and mark the **Estimated** checkbox. Initially,

BUILDER algorithms estimate the year in which the Section was last painted or coated. The default value is the Building's year of construction if the age of the building is less than 1.5 times the expected paint life of the Section.

Best Practice: If the estimating algorithm is being used, or if you are unsure of when the Section was last painted or coated, make sure you mark the **Estimated** checkbox.

- **Paint Type.** If the Section is marked as painted/coated, select the paint/-coating type from the dropdown list.

After adding the Section data,

- a. Activate the **Add** button on the popup toolbar to add the Section to your inventory.
- b. Alternatively, if you do not wish to add the Section, activate the **Cancel** button to close the popup.

Attach a File

At the **Attachments** tab on the Section's data page, you have the option to attach files to the Section's record. An attached file might be a photograph, an electronic image of written notes or diagrams made during inventory, or a file generated on a computer.

Acceptable Attachment Formats


The attachment may be in any of the following formats:

- .jpg
- .jpeg
- .png
- .zip
- .doc
- .pdf

Note: As of March 7, 2019, .doc format is allowed, but not .docx.

Attach

To attach a file,

1. At the **Attachments** tab, activate the  **Add** button in the toolbar below the row of tabs.

Save
 Comment
 Reports

Section Name:

General Info. Section Details Condition Trend Inspection History Attachments (0)

Add
 Delete

☐ Show All ☐ Section Only ☐ Details Only

	Detail ID	Level	Title
No records to display.			

This will open the "Add Image" popup window:

Add Image


Cancel
 Save
 Help

Title:


Description:

Image:

2. Enter Title and Description information for the attachment.
3. Activate the **Select** button to the right of the "Image" field to browse to the desired image or other file.
4. If you are adding an attachment at the Building level, use the "Image Type" radio buttons to indicate whether the attachment is a Key Plan, a Section Plan, or "Other."
5. Once the required attachment data is entered,
 - a. Activate **Save** on the popup toolbar.
 - b. Alternatively, to close the popup window without attaching the selected file or image, activate the **Cancel** button.
 - c. *Troubleshooting*
 - d. If the selected attachment is in an acceptable format, the "Image" field will be replaced with a green dot (plus a label that gives you the option to remove the attachment).




- e. If it is not in an acceptable format, the "Image" field will be replaced with a red dot. Activate "Remove" and select an attachment file in one of the formats listed at ["Acceptable Attachment Formats" on page 107](#).



Edit Section Data

Data for a given Section can be viewed and edited by selecting the Section in the inventory tree:



The Section information is distributed over several tabs:

General Information Tab

After a Section is selected in the inventory navigation tree, the **General Information** (abbreviated **General Info.**) tab is shown, where all of the Section data described above can be edited. Be sure to save the edits using the **Save** icon in the content area toolbar.

Reports Tools

Save Comment Reports

Section Name: North windows Equipment Category: B202001 WINDOWS
Component Subtype: Aluminum Windows

General Info. Section Details Condition Trend Inspection History Attachments (0)

Quantity: 19 EA Latest Inspection No Standard
Year Install/Renewed: 1966 Estimated Date: 10/11/2017
Age: 51 CSCI: 88 CCI: Minimum CI for Repair:
RSL: 39 Current Estimated Condition Minimum CCI for Paint:
Painted: Painted: Maximum RPL for Paint:
Year Painted: 1991 CSCI: 88 CCI: 53 Maximum RSL for Replacement:
Paint Type: Alkyd Modified Oil Paint
RPL: 4

Additional data on this tab includes:

- **Age** (Read-Only). Displays the age of the Section calculated from the Year Installed/Built.
- **RSL** (Read-Only). Displays the remaining service life, in years, of the Section. The remaining service life is calculated during the [rollup process](#) using age, Section service life, and Section condition index trend.
- **Latest Inspection** (Read-Only). Displays the date that the last condition assessment was performed on the Section. Also displayed is the Component-Section Condition Index (CSCI) computed on the inspection date based on the assessment results. If the Section is painted, the Coating Condition Index (CCI) computed at the last inspection date will also be shown.
- **Current Estimated Condition** (Read-Only). Displays the estimated CSCI based on service life and condition index trend. The estimated CSCI is computed during the [rollup process](#). If the Section is painted, the CCI computed

at the last inspection date will also be shown. If the Section is painted, the current estimated CCI will also be shown.

The following fields show numbers that have been set using BUILDER's "Standards" capability to generate work items, if this procedure has been done. For more information about applying standards, see the Work Configuration Guide.


- **Minimum CI for Repair** (Read-Only). This field shows what threshold Condition Index value will trigger a work item. For Sections with a CI above this value, no work item is triggered. For Sections with a CI at or below this value, a work item is triggered.
- **Minimum CCI for Paint** (Read-Only). This field shows the threshold value for the Coating Condition Index. For painted Sections with a CCI above this value, no paint work item is triggered. For painted Sections with a CCI at or below this value, a paint work item is triggered.
- **Maximum RPL for Paint** (Read-Only). This field shows the threshold value for remaining paint life. For painted Sections with a RPL greater than this value, no paint work item is triggered. For painted Sections with a CCI at or less than this value, a paint work item is triggered.
- **Maximum RSL for Replacement** (Read-Only). This field shows the threshold value for remaining service life. For Sections with a RSL above this value, replacement would not be considered as an option unless it is more cost effective to replace than to repair.

Section Details Tab

In addition to information at the **General Information** tab, details regarding individual pieces of equipment that are part of the Section can be stored at the [Section Details](#) tab.


Condition Trend Tab (Read-Only)

The Condition Trend tab shows the trend of the CSCI based on inspection information, as well as the projected CSCI trend into the future based on observed deterioration rates and expected service life.



Inspection History Tab (Read-Only)

The Inspection History tab displays a graph of the CSCI history of the Section over time, based on inspection information.



Attachments Tab

The **Attachments** tab will show whether any files have been attached to the Section's record. The number in parentheses after the word "Attachments" shows how many of them have been attached. At the **Attachments** tab, you have the option to view or change the Section's attachments, as well as attachments to the Section's Section Details.

An attachment can be a photograph, an electronic image of written notes or diagrams made during inventory, or a computer file. For acceptable file formats, see ["Acceptable Attachment Formats" on page 107](#).

You can edit the title and/or description of an attachment as follows:

1. Navigate to the **Attachments** tab to view the attachments table.
2. Activate a link in the **Title** column. *The attachment will appear in the "Image Viewer" popup window.*
3. In the header section above the attachment, make the desired changes in the **Title** and/or **Description** field(s).
4. Activate **Save** on the popup toolbar to store your changes and return to the table of attachments.
5. Alternatively, if you want to cancel the change, activate **Close** on the popup toolbar. *You will be returned to the table of attachments.*



If you wish to change the contents of the attachment, you will need to delete the existing attachment file and add a new one.

To add an attachment, see ["Attach a File " on page 107](#).



To delete an attachment,

1. Navigate to the **Attachments** tab to view the attachments table.
2. Select the attachment you wish to delete (do *not* activate the link in the **Title** column). *When properly selected, that record in the table will change background color as illustrated below:*

General Info. Section Details Condition Trend Inspection History Attachments (2)


 Add  Delete

☐ Show All ☐ Section Only ☐ Details Only




	Detail ID	Level	Title	Description
		Component_Section	attch1	screenshot
		Component_Section	attch2	delete this one

3. Activate the **Delete** button above the table.
4. Activate **Yes** in the confirmation box to delete the attachment, or **No** to cancel.

To add an additional attachment,


1. At the **Attachments** tab, activate the  **Add** button in the toolbar below the row of tabs. *The "Add Image" popup will appear.*
2. Enter Title and Description information for the attachment.
3. Activate the **Select** button to the right of the "Image" field to browse to the desired image or other file. (Alternatively, you can enter the path to the image in the "Image:" field.)
4. If you are adding an attachment at the Building level, use the "Image Type" radio buttons to indicate whether the attachment is a Key Plan, a Section Plan, or "Other."
5. Once the required attachment data is entered,
 - a. Activate **Save** on the popup toolbar.
 - b. Alternatively, to close the popup window without attaching the selected file or image, activate the **Cancel** button.


Toolbar Options

-  **Save**. Saves changes made to the Section.
-  **Comment**. Allows you to add, edit, and view comments about the Section.
- **Deleted: Images**. Note that this toolbar option has been removed; it has been replaced with the **Attachments** tab in the content area.
-  **Reports**. Launches the Report Selection tool, which gives you access to a list of standard reports relevant to Section inventory. See ["Generate a Report" on page 186](#) for details about how to select and generate a report, or below for a list of reports available at the Section level of inventory.

Delete a Section

To delete a Section, navigate to it in the inventory tree and do one of the following:

- Right-click the Section, then select "Delete Section" from the options. Or,
- Select the Section, then activate the **Delete Section** icon  on the menu toolbar, as shown below.




Note: This is a significant step to take and should only be done when you are certain that you wish to clear the Section you have selected from the inventory in the Building.

Best Practice Recommendation: Making frequent backups of your inventory database will protect you from significant data losses if mistakes in deleting are made.

Reports Available at the Section Level

When you activate the **Reports** button on the toolbar, the following selection of reports shown in the screen shot is available. To see the list of reports, activate the down arrow in the "Select a Report" text box.



To generate and view a report, select it in the list, then activate the **View Report** button.


See ["Generate a Report" on page 186](#) for more details.

The Effect of the "Estimated" Checkbox for a Component-Section

When entering the inventory for a Component-Section in BUILDER, one of the primary data elements that gets recorded is the year that Component-Section was installed or constructed. This denotes the time that the Component-Section was put in service, and is used by BUILDER to determine the Component-Section age and its projected life-cycle condition. It is a fundamental data element in the determination of a component's condition index.

There are cases where the Component-Section install date is explicitly known, such as if the component is original to the Building, or if the component was replaced recently and work records exist. There are also many cases where

obtaining the exact install year for a Component-Section is difficult. This may be the case, for example, if the Component-Section is very old but not original to the Building, and the year when it was installed or replaced is not known. In these situations, the surveyor collecting and entering the data for that Component-Section should enter a year installed that best reflects the observed age based on professional judgment, and the year estimated check box shall be checked in BUILDER to reflect that. As a guide to determine the year installed for a Component-Section, the following flow diagram should be considered.




If a Component-Section's install year is estimated, as denoted by the check box, BUILDER will factor that into account when projecting the current condition index. The condition index reflects the expected condition state, based on life cycle information such as its age in relation to its expected service life, as well as inspection based observations against that component. When no inspection are recorded against the Component-Section, the projection of current Component-

Section CI (CSCI) is solely based on age of the component calculated from the year installed value, whether it is estimated or not. However, if an inspection is performed, the expected value gets adjusted based on the condition based observations that are observed.

Basically, what BUILDER is doing is reconciling any differences between the expected CI based on age, and the observed condition at a point in time based on the inspection. If the expected age based CI projection and observation-based inspected CI are not significantly different, the adjustments to the projected CI curve over time are relatively minor and the projected CI tends to be close to the last inspected CI in the time frame immediately after that inspection.

However, if the difference between the age-based expected CI and observation based inspected CI are drastically different, as may be the case where a component receives a high condition rating when its age is past its expected service life, the adjustment will be more significant. In these situations, BUILDER has to determine whether to place more emphasis on the age of the component, or the observed condition. If the estimated year installed box is checked, BUILDER places less emphasis on the age-based CI, and the latest observation-based inspected CI controls the projected CI calculation. If the year installed check box is not checked, we have a higher confidence in the age of the Component-Section, and the age-based CI projection has more emphasis on the current CI calculation, limiting the amount that the expected service life is allowed to be adjusted.



Working with Section Details

Add, Edit, or Delete Section Details

The Section Details level in the BUILDER hierarchy is where you can record detailed information, such as serial number and warranty date, for equipment that constitutes a Section or is part of one. This topic describes operations that can be performed at the Section Detail level.

Section Details include critical information regarding warranties, model number, manufacturer, equipment serial numbers and property identifiers, and location. After defining a Section, you may add details regarding individual items of equipment or constructed elements (materials) at the **Section Details** tab, as shown below.

The screenshot displays the BUILDER software interface. On the left, a tree view under 'Inventory' shows a hierarchy: Sample > Sustainment Management System > 010 - Sample Site > 011 - Sample Org > 012 - Sample Site 01 > 001 - Building One > B10 SUPERSTRUCTURE > B20 EXTERIOR ENCLOSURE > B2010 EXTERIOR WALLS > B201001 EXTERIOR CLOSURE Brick Veneer w/CMU Backup. The main panel shows the 'Section Details' tab selected. At the top, there are buttons for 'Save', 'Comment', and 'Reports'. Below these, 'Section Name' is set to 'N/A', 'Material Category' is 'B201001 EXTERIOR CLOSURE', and 'Component Subtype' is 'Brick Veneer w/CMU Backup'. A table with columns 'Attachments', 'Eq. Type', 'Eq. Make', 'Serial No.', 'Model', and 'Capacity' is shown, with a message 'No records to display.' above it. An 'Add new record' button is located above the table.

Add Section Details

To add Section Details,

1. Activate the **Add new record** button (located just above the Section Details table column headers).
2. Enter information; each of the fields is described in ["Edit Section Detail Data" on page 123](#). You can use the **Tab** key to proceed left to right, from one entry field to another, or **Shift-Tab** to move from right to left.
3. **IMPORTANT:** After entering the information, activate the checkmark icon, as shown below.

Note: You may need to scroll back to the left side of the table to see the checkmark icon.

Section Name: N/A

General Info. Section Details Condition Trend

+ Add new record

	Attachments	Eq. Type
	✓ ✗	

No records to display.

Alternately, to exit the record without saving the data, activate the red **Cancel** icon next to the checkmark icon.

- When finished with entries, or intermittently, activate **Save** on the toolbar.

Attach a File

From the **Attachments** column of the Section Details table, you have the option to attach files to the Section Detail's record. An attached file might be a photograph, an electronic image of written notes or diagrams made during inventory, or a file generated on a computer.

Acceptable Attachment Formats

The attachment may be in any of the following formats:

- .jpg
- .jpeg
- .png
- .zip
- .doc
- .pdf


Note: As of March 7, 2019, .doc format is allowed, but not .docx.

You have the option to attach one or more files to the Section Detail's record.

Attach


To attach a file,

- Activate the image in the **Attachments** column of the desired row in the Section Details table.




The "Section Details Attachments" popup window will appear.

2. In the "Section Details Attachments" popup window, activate the **Add** button on the toolbar.




This will open the "Add Image" popup window:




5. Enter Title and Description information for the attachment.
6. Activate the **Select** button to the right of the "Image" field to browse to the desired image or other file.
7. If you are adding an attachment at the Building level, use the "Image Type" radio buttons to indicate whether the attachment is a Key Plan, a Section Plan, or "Other."

8. Once the required attachment data is entered,
 - a. Activate **Save** on the popup toolbar.
 - b. Alternatively, to close the popup window without attaching the selected file or image, activate the **Cancel** button.

After you activate **Save** on the popup toolbar, an entry for the attachment will appear in the "Section Details Attachments" table in the popup.




Section Details Attachments		
Close Add Delete		
	Title	Description
	One	sample attach 1

Section Detail attachments can also be accessed from the **Attachments** tab at the Section data screen by selecting either the "Show All" or "Details Only" radio button above the Section Attachments table.

Troubleshooting

If the selected attachment is in an acceptable format, the "Image" field will be replaced with a green dot (plus a label that gives you the option to remove the attachment).




Add Image


Cancel
Save
Help

Title:

Description:

Image:  3_3_5-search-bar.PNG x Remove

If it is not in an acceptable format, the "Image" field will be replaced with a red dot. Activate "Remove" and select an attachment file in one of the formats listed at ["Acceptable Attachment Formats" on page 120](#).



Toolbar Options

- **Save**. Saves changes made to the Section Detail.
- **Comment**. Allows you to add, edit, and view comments about the Section Details.
- **Deleted: Images**. Note that this toolbar option has been removed. Images and other attachments are now initiated or accessed via the **Attachments** column of the Section Details table, or from the **Attachments** tab in the Section data page.
- **Reports**. Allows you to run standard BUILDER reports appropriate to the current inventory level.

Edit Section Detail Data

General Info. Section Details Condition Trend Inspection History Attachments (0)							
+ Add new record							
		Attachments	ID Number	Eq. Type	Eq. Make	Serial No.	Model
		x 0	9541	Single Pole	K-270-SPO	0005-43258J	270 series

Because Section Detail data can be recorded for both equipment and non-equipment Section Detail items, some of the data elements (columns in the table of items at the **Section Details** tab) might not apply to a particular Section. Simply fill in the applicable data fields and leave the non-applicable fields blank. Section Detail data that can be entered includes:

- **ID Number** (Required for individual items of equipment; not used for non-equipment types of Section Detail items). Enter the identifier for the individual equipment. Limit: 20 alphanumeric characters.
- **Equipment Type**. Enter the equipment type. Limit: 50 alphanumeric characters.
- **Equipment Make**. Enter the equipment make. Limit: 30 alphanumeric characters.


- **Serial Number.** Enter the serial number. Limit: 30 alphanumeric characters.
- **Model.** Enter the model. Limit: 20 alphanumeric characters.
- **Capacity.** Enter the capacity (such as gallons, horsepower, or MBH, depending on equipment type). Limited to 70 alphanumeric characters.
- **Manufacturer.** Enter the manufacturer. Limit: 40 alphanumeric characters.
- **Warranty Company.** If the item has a warranty, enter each warranty company, which is limited to 50 alphanumeric characters each. For each item, up to two warranty companies may be listed.
- **Warranty Date.** If the item has a warranty, select each warranty date using the dropdown calendar. For each item, up to two warranty dates may be listed, numbered to match the warranty company.
- **Location.** Enter where the time is located. Limit: 40 alphanumeric characters.
- **Date Manufactured.** Select the date the item was manufactured, using the dropdown calendar.
- **Control Type/Make.** Enter the Section control type or make. Limit: 50 alphanumeric characters.
- **Year Installed.** Enter the 4-digit year in which the item was installed.
- **Comment.** Enter comments about the Section Detail.




View Section Detail Attachments

Two methods are available to view Section Detail attachments: They can be accessed from either the **Attachments** or **Section Details** tab of the Section data page.

A. To view Section Details at the **Attachments** tab,

1. Select either the "Show All" or "Details Only" radio button.



General Info. Section Details Condition Trend Inspection History Attachments (1)				
 Add  Delete				
<input type="radio"/> Show All <input type="radio"/> Section Only <input checked="" type="radio"/> Details Only				
	Detail ID	Level	Title	Description
	9541	Section_Detail	<u>One</u>	sample attach 1

2. Next, activate the attachment's link, located in the **Title** column of the table.

The attachment will show in the "Image Viewer" popup window:

Image Viewer

Close Save

Title: One

Description: sample attach 1

General Info Additional Info Assess. History Work Item History Attachments (0)

Building Use: 13310 - FLT CONT TOWER

Building Type:

Current Status: Active

Construction Type: Permanent

Area: 46 SM

Year Constructed: 1985

Number of Floors: 1


Mission Dependency Index

MDI: 77

Check box to override automated updates and manually enter MDI: ☒

B. To view Section Details via the Section Details table,

1. Activate the image in the **Attachments** column of the desired row in the Section Details table.

General Info.	Section Details	Condition
+ Add new record		
	Attachments	ID Number
<input checked="" type="checkbox"/>		9541



2. Next, activate the attachment's link, located in the **Title** column of the table.

The attachment will show in the "Image Viewer" popup window:

Delete a Section Detail

To delete a Section Detail,

1. Open the **Section Details** tab at the data page for the relevant Section.
2. In the row containing the Section Detail to be deleted, activate the red "X" in the first column by double-clicking:


General Info. Section Details Condition Trend Inspection History Attachments (0)							
+ Add new record							
	Attachments	ID Number	Eq. Type	Eq. Make	Serial No.	Mod	
	 x 0	9541	Single Pole	K-270-SPO	0005-43258J	270	

3. Activate **Yes** in the "Confirm Action" confirmation popup.

Reports Available at the Section Details Level

At the **Reports** button on the toolbar, the following selection of reports (shown in the screen shot) is available. To see the list of reports, activate the down arrow in

the "Select a Report" text box. These are the same reports as those available at the Section level.



Remote Inspection and Inventory Entry Using BuilderRED

This topic

- Introduces the BUILDER Remote Entry Database (BuilderRED) tool.
 - Provides the download location.
 - Explains briefly what the tool can do.
 - Links to topics giving detailed instructions for exporting to and importing from BuilderRED.
-

What is BuilderRED?

The BUILDER™ Remote Entry Database (BuilderRED, or BRED) is an optional tool designed for use with BUILDER. It allows you to (1) capture and collect inventory and inspection data using a Windows tablet or laptop as you walk through a Building, and then (2) later, load that data into the BUILDER database.

You can download BRED from the SMS community user's group website at <https://www.sms.erd.c.dren.mil>. Navigate to **PRODUCTS > BUILDER > Downloads** and look under the heading **BUILDER Remote Entry Database (BRED)**.

Collecting Inventory Data

When performing inventory, Buildings and their subparts can be created in BuilderRED, then imported into BUILDER. If the Buildings have already been created in BUILDER, they can be exported to BuilderRED, where inventory details can be entered on-site, then imported back into BUILDER.

Performing Inspections

Inspectors can use BuilderRED to enter condition assessment data in BUILDER format and then import it into BUILDER. Standard functionality assessments are also built into BuilderRED. These assessments can be initiated and filled out in the field, then imported into BUILDER.

Export Data to BuilderRED

You can choose to export database items to BuilderRED (aka BRED) either (a) with or (b) without the images that are linked to these items.

Below are some recommendations for best practices to follow to help ensure successful and less time-consuming export of files to BuilderRED:

Best Practice Recommendation #1: Be sure to observe the 30-day [time limit on editing inspections](#) and re-importing them into BUILDER, or the time limit in effect for your implementation of BUILDER if it differs from 30 days.


Best Practice Recommendation #2: Some Facilities (Buildings) within your Site can already contain several hundred photos. If you know beforehand that you will not need to view or edit these existing photos in BuilderRED, the best practice is to just download the BRED file without images.

Best Practice Recommendation #3: 800 pixels is the recommended maximum width and maximum height for images to be used in BuilderRED.

The next section describes how to export both database information and images to BuilderRED. For instructions on exporting database information without images, see [Export Database Information Alone to BuilderRED](#).

Export Database Information and Images to BuilderRED

1. In the BUILDER navigation tree, right-click the lowest level node (Site, Complex, or Building) that contains the items you wish to export.
2. Select the "Export to BRED" option:




3. In the "BRED Exporter" popup window, highlight the Building(s) you want to export, using the arrows to move Buildings in or out of the Selected Build-


ings list. Click here to see different ways you can select Buildings.¹

1


All Buildings:	Activate the double arrow.
One Building:	<ol style="list-style-type: none">1. Select the Building.2. Activate the single arrow.
Multiple Buildings, contiguous in the list:	<ol style="list-style-type: none">1. Select the first Building.2. Press and hold SHIFT, then select the last Building.3. Release SHIFT.4. Activate the single arrow.
Multiple Buildings, not contiguous in the list:	<ol style="list-style-type: none">1. Select the first Building.2. Press and hold CTRL, then select each subsequent Building desired.3. Release CTRL.4. Activate the single arrow.
To deselect a high- lighted Building from the list:	<ol style="list-style-type: none">a. Press and hold CTRL, then select the Building.b. Alternatively, you can wait until the Building has been moved to the right-hand column under "Selected Buildings", then select the Building, and activate the single arrow pointing to the left. This will move the Building back into the "Available for Selection" column.




4. Once the desired Buildings are in the Selected Buildings column, do one of the following in the lower section of the "BRED Exporter" window:
 - a. Choose "All Systems" (radio button; this is the default), or
 - b. Select specific systems (using radio button and checkboxes).
5. (Optional) In order to download images with the BRED file, you must select "Also Export Images" at the bottom of BRED Exporter Window, as shown below:



Note: If instead of “Also Export Images” you see “No Images to Export” it means that the Building(s) you have selected to export do(es) not currently have any images:




6. To start the export, click the **Proceed** button near the top of the window. A progress bar will display as the BRED database file is downloaded:




By clicking the **Proceed** button, the following tasks area accomplished:

- A Microsoft Access database is created, which will be identified by the path and name you choose after the export has completed. The database will contain the inventory and condition assessment data for the selected Systems in the Buildings in the Selected Buildings list. This database is accessible to a computer with the BRED software, where inventory and/or condition assessment data can be recorded. Once complete, this file can be imported into BUILDER to add the new data is added to the database.
- The Building inventory records of the selected Systems that were exported are locked so changes cannot be made to them in BUILDER while being edited with BRED. The records are unlocked when the BRED data is imported back into the database.


7. After the database file has successfully downloaded, select the “Save As” option to choose a file location for it:



8. If the BRED file did not download correctly, select “Redownload Export File.” Otherwise, select “Download Images File” to start the second download (the download of the images file into BRED):




9. After the second download completes, click “Save As” and choose the **same file location** as your BRED database file.
10. Lastly, select “Complete Export” to finish the export process:



Time Limit on Editing Inspections

Once the export is complete, you can use BuilderRED to collect Inventory data or perform Inspections. Note that it is a common standard to have a 30-day time limit from the date of an Inspection to edit the Inspection or the comments in it. This time limit applies both in BuilderRED and after the data has been imported back into BUILDER.

Known Issue with Image Export from Builder




This issue applies to versions of BUILDER 3.3.9 and older.

If the BRED Export error message shown above displays after you try to download the image file from BUILDER, that indicates that somewhere in the exported files there is an attachment (such as a PDF, an Excel file, etc.) that is not an image. The workaround is to export the Building(s) without images.

Export Database Information Alone to BuilderRED

This section outlines the procedure to export data from BUILDER to BuilderRED without any of the associated image files.

1. In the BUILDER navigation tree, right-click the lowest level node (Site, Complex, or Building) that contains the items you wish to export.
2. Select the "Export to BRED" option:




3. In the "BRED Exporter" popup window, highlight the Building(s) you want to export, using the arrows to move Buildings in or out of the Selected Build-


ings list. Click here to see different ways you can select Buildings.¹

1

All Buildings:	Activate the double arrow.
One Building:	<ol style="list-style-type: none">1. Select the Building.2. Activate the single arrow.
Multiple Buildings, contiguous in the list:	<ol style="list-style-type: none">1. Select the first Building.2. Press and hold SHIFT, then select the last Building.3. Release SHIFT.4. Activate the single arrow.
Multiple Buildings, not contiguous in the list:	<ol style="list-style-type: none">1. Select the first Building.2. Press and hold CTRL, then select each subsequent Building desired.3. Release CTRL.4. Activate the single arrow.
To deselect a high- lighted Building from the list:	<ol style="list-style-type: none">a. Press and hold CTRL, then select the Building.b. Alternatively, you can wait until the Building has been moved to the right-hand column under "Selected Buildings", then select the Building, and activate the single arrow pointing to the left. This will move the Building back into the "Available for Selection" column.




4. Once the desired Buildings are in the Selected Buildings column, do one of the following in the lower section of the "BRED Exporter" window:
 - a. Choose "All Systems" (radio button; this is the default), or
 - b. Select specific systems (using radio button and checkboxes).
5. In order to download the BRED file without downloading the associated images, make sure that the **Also Export Images** checkbox at the bottom of the BRED Exporter Window is *not* checked.
6. To start the export, click the **Proceed** button near the top of the window. *A progress bar will display as the BRED database file is downloaded:*




By clicking the **Proceed** button, the following tasks area accomplished:

- A Microsoft Access database is created, which will be identified by the path and name you choose after the export has completed. The database will contain the inventory and condition assessment data for the selected Systems in the Buildings in the Selected Buildings list. This database is accessible to a computer with the BRED software, where inventory and/or condition assessment data can be recorded. Once complete, this file can be imported into BUILDER to add the new data is added to the database.
 - The Building inventory records of the selected Systems that were exported are locked so changes cannot be made to them in BUILDER while being edited with BRED. The records are unlocked when the BRED data is imported back into the database.
7. After the database file has successfully downloaded, select the “Save As” option to choose a file location for it:



8. If the BRED file did not download correctly, select “Redownload Export File.” Otherwise, select “Complete Export” to finish the export process:



Time Limit on Editing Inspections

Once the export is complete, you can use BuilderRED to collect Inventory data or perform Inspections. Note that it is a common standard to have a 30-day time limit from the date of an Inspection to edit the Inspection or the comments in it. This time limit applies both in BuilderRED and after the data has been imported back into BUILDER.

Import Data from BuilderRED to BUILDER

Overview of the Import Process

In order to load data collected using BRED into the BUILDER database, you will need to import the database from BRED into BUILDER. It is important to note that the database file containing your new data must be loaded so that the BUILDER program has access to its path and can complete the importing process.

If you added new images during Inventory or Inspections, then importing your information back into BUILDER will be done in two steps: (1) importing the BRED database into BUILDER, and (2) importing the image archive file.

These two steps may be followed by an optional third step: (3) performing a manual condition rollup. This step is optional because the system performs automated rollups nightly.


If you have no images to import, then you can go straight from importing the BRED database information into BUILDER to [performing a rollup](#).

How To Import Database Information


After you have finished adding, editing, and deleting Inventory and/or Inspections data, the updated database must be imported back into BUILDER, to assess the condition of the installation and to plan maintenance and repair.

To import database information into BUILDER from BuilderRED:


1. Save all changes to the database in BuilderRED.
2. Open BUILDER.
3. Select **Tools > Import > Import from BRED** starting at the main menu.



The "Import from BRED" popup window will appear:



4. Locate the database you wish to import, by either (a) entering the full path and file name in the text box or (b) clicking the **Select** button, navigating to the database file, and selecting it.
5. All changes to the database will be imported into BUILDER and you will see a popup window with the following message:



6. If you don't have any images to be imported into BUILDER, activate **OK**. You are finished with the import, and can [perform a rollup](#) if you wish.
7. **IMPORTANT:** If you have images to import from BuilderRED, it is recommended that you NOT click **OK** to perform a manual condition rollup at this point. Instead, close the popup box by activating the "x," then follow the instructions in the next section:

How To Import Images

The process of importing images makes use of an image archive file that has the extension .bredpackage. By default, the image archive file has the same name as the .mdb BRED data file containing the imported data, except for the extension.

WARNING: It is very important that the name of the image archive file match the name of the .mdb data file. If you rename one of these files, be sure to rename the other one identically (except for the extension). Images will not be found by the BRED (.mdb) file if the .bredpackage file name doesn't match.

To import images into BUILDER from BuilderRED:

1. If you have new images that need to be imported from BRED, this procedure needs to be done *after* importing the database information (see section above).
2. Select **Tools > Import > Import image archive** starting at the main menu. (*The "Import image archive" popup window will appear.*)
3. Locate the image ("bredpackage") file corresponding to the database you just imported, by either (a) entering the full path and file name in the text box or (b) clicking **Select**, navigating to the database file, and selecting it. The image archive will be in the same location as the database file, and similarly named except that the extension is .bredpackage instead of .mdb.
4. When you see the message "Upload successful," close the "Import image archive" window. Follow with a manual condition rollup as warranted (see next section).



Should I Perform a Rollup after Import?

The items you import from BuilderRED are unlocked as soon as the import is complete, whether you do a manual condition rollup or not. However, the condition and Functionality Indexes will not yet have been updated.

If you only performed inventory with BuilderRED, you need to do a rollup only if

- one or more cost books or other reference books have changed, or
- you wish to see updated PRVs or RSLs immediately instead of waiting on BUILDER's automated rollup (performed overnight)

If you entered inspection data in BuilderRED, performing a rollup after the import is completed allows you to see the changes in the following indexes right away:


- condition indexes
- functionality indexes
- performance indexes


If you do not perform a rollup at this time, the SMS will do the rollup automatically overnight, and the updated index figures will be available the next day.

How To Perform a Manual Rollup after Importing from BuilderRED

To perform a manual rollup, do one of the following:

- a. Right-click on the affected Building (or Complex, if multiple Buildings were exported from the same Complex). Then select **Rollup Building** or **Rollup Complex**.



- b. Alternatively, select the Building (or Complex, if multiple Buildings were exported from the same Complex) and click the Rollup icon  on the toolbar.




You have the option to roll up the entire Site in similar fashion, but be aware that a Site rollup can take an extremely long time. It would typically be less time consuming to sequentially select the applicable Complexes and Buildings for manual rollup.

Working with Rapid Inventory Methods

This topic gives an overview of three ways that the BUILDER inventory creation process can be made faster. These methods depend on a level of similarity between Sections or Buildings.

Note: A previously available method, Embedded Building Models, has been discontinued.

One of the most time-consuming aspects of inventory is the decomposition of a Building into its Systems, Components, and Sections. To help with this Building decomposition, BUILDER™ has multiple alternative methods designed to help you quickly establish an inventory database for your Buildings. The main toolbar icon for each is shown in the listing below.

1.  Copy the inventory of one Building into another Building ("Copy Inventory to Another Building")
2.  Copy Sections using the Copy Sections tool (within the same Building only).
3.  Create and use Building templates


Method Availability

Site and Complex Level

At the Site and Complex level, these methods are available:

- Copy the inventory of one Building into another Building
- Create and use Building templates

The icons for these methods sit side by side on the BUILDER toolbar at the inventory levels where they are available for use.



Building Level

At the Building level, the Copy Sections tool also becomes available:



List of Rapid Inventory Methods

Method 1: Copy the Inventory of One Building into Another

One method that can ease the data input process is to copy the existing inventory of one Building into another Building. This provides a starter set of Systems, Components, and Sections that can then be refined, instead of all entered from scratch. The amount of refinement needed will depend on the amount of similarity between the structures.

This inventory creation method is especially useful if you have a number of Buildings in your inventory that were all built at the same time using the same plans and specifications.

Tip: If you have more than two or three Buildings or facilities that are very similar to each other, you should consider creating a Building template instead of copying from another Building. If one of the applicable Buildings is already created and populated, it can be used to create that template.

For instructions on copying inventory from another Building, see ["Copy Inventory to Another Building" on the facing page](#).

Method 2: Copy Sections

Within a Building, the process of adding inventory can be accelerated by using the Copy Sections tool, which allows you to copy pre-existing Sections from one area of a Building to another area of the same Building. An example of when to use this tool is in a multistory building with similar or identical inventory on multiple floors. The first floor can be inventoried and then copied to other floors, saving time and reducing inventory costs.

For instructions, see ["Copy Sections" on page 147](#).

Method 3: Create and Use Building Templates

Building templates are "cookie cutter" models that can be used to create Buildings with identical features. These template-generated Buildings can be used to get your inventory task off to a fast start, because their contents only need editing and adapting instead of each inventory item and sub-item being entered from scratch.

For an overview and a jumping-off location for instructions, see ["Working with Building Templates" on page 150](#).

Copy Inventory to Another Building

BUILDER has been designed to help you quickly establish an inventory database for your Buildings. One of the most time-consuming aspects is the decomposition of a Building into its Systems, Components, and Sections. One method that eases the data input process is copying a Building's inventory from one Building (the source Building) to another (the target Building). This feature is very useful if you have a number of Buildings in your inventory that were all built at the same time using the same plans and specifications.


Follow the steps below to copy Building inventory.

☐ ***Prepare the Source Building***

Before you can copy a Building's inventory from one Building to another, you must first [create the source Building](#) and complete its inventory as fully as possible, including all of the related Building data.

☐ ***Activate "Copy Inventory to Another Building"***

Once the source Building has been created, navigate to it in the inventory tree and do one of the following:

- a. Right-click on the source Building in the inventory tree. Then select "Copy Inventory to Another Building" from the options.
- b. Alternatively, select the source Building in the inventory tree. Then activate the  **Copy Inventory to Another Building** icon on the toolbar.

The "Copy Building" popup window will appear. The number and/or name of the source Building whose inventory you wish to copy, should appear in the "Select Building to Copy" dropdown list.

☐ ***Enter Required Data***

In the "Copy Building" popup, enter the data listed below.

Copy Building

Close Proceed Help

Select a Building to Copy: 0001 - DORM AM PP/PCS-STD

☒ New Building ☐ Existing Building

Copy Target

Building Number: Building Name:

Categories to be Included

☐ System/Component Structure ☐ Architect/Contractor Information

☐ Copy Section Date as "Estimated" ☐ Applicable Housing Information



☐ Last Inspection Rating ☐ Building Dimensions Data

1. Just above the "Copy Target" area of the window, use the radio buttons to select whether you want to copy that Building's inventory to a New Building or into an Existing Building:
 - a. If you select a **New Building**, you must supply Building Number and Building Name in the "Copy Target" area of the window. Building summary information such as year constructed will automatically be transferred into the new Building when you later activate **Proceed**.
 - b. If you select an **Existing Building**, a dropdown list of Buildings currently in the inventory will be provided. Do the following:
 1. From the list, select the Building you wish to copy the source Building's inventory to.
 2. If you wish to use the Inventory Summary Information (such as year constructed, number of floors) of the source Building into the target Building, mark the **Copy Inventory Summary Information** checkbox. Otherwise, leave the checkbox blank.
2. In the "Categories to be Included" area of the window, check all of the categories you wish to have copied to the target Building. The following record categories can be copied to the target Building:
 - **System/Component Structure**. Marking this checkbox will copy all of the Systems, Components, and Sections to the target Building.

- **Copy Section Date as "Estimated."** Marking this checkbox will mark all of the Section install dates in the target Building as estimated. This checkbox can only be marked if the **System/Component Structure** checkbox is marked.
- **Last Inspection Rating.** Marking this checkbox will copy the last condition assessment rating for each Section to the target Building. This checkbox can only be marked if the **System/Component Structure** checkbox is marked.
- **Architect/Contractor Information.** Marking this checkbox will copy all of the [architect and contractor information](#) to the target Building.
- **Building Dimension Data.** Marking this checkbox will copy all of the [dimension data](#) to the target Building.

☐ **Confirm or Cancel**

Once the required data is entered, do one of the following:


- a. Activate the  **Proceed** button on the popup window's toolbar to start the copy process. After the copy process is complete, you can edit any of the copied Building's records if adjustments are necessary.
- b. Alternatively, if you do not wish to copy the Building, activate the  **Close** button on the popup window's toolbar.

Copy Sections

BUILDER has been designed to help you quickly establish an inventory database for your Buildings. One of the most time-consuming aspects is the decomposition of a Building into its Systems, Components, and Sections. One method that eases the data input process is the Copy Sections tool, which allows you to copy pre-existing Sections from one area of a Building to another area of the same Building. An example of when to use this tool is in a multistory building with similar or identical inventory on multiple floors. The first floor can be inventoried and then copied to other floors, saving time and reducing inventory costs.


To use the Copy Sections tool,

1. Navigate in the inventory tree to Building into which you wish to copy the Section, then do one of the following:
 - a. Right-click the Building. Then select "Copy Sections" from the options. (This is illustrated in the lower half of the screen shot below).



- b. Alternatively, select the Building, then activate the **Copy Sections** icon in the toolbar as shown above.

After your selection, the "Copy Sections" popup window will appear.



2. In the "Copy Sections" window, enter the following data:
 - **Name to Copy** (Required). Choose the existing Section name to copy from the dropdown list. All Sections that match the selected name will be copied as new Sections.
 - **Replacement Name** (Required). Enter the replacement name for the copied Sections. The replacement name will appear as the Section name for the copied Sections.
 - **Copy Comment** (Optional). Mark the **Copy Comments** checkbox if you wish to copy the comments associated with the copied Sections and associate them with the replacement Sections also.
 - **Set Installed Date as "Estimated" for all Sections being copied** (Optional). Mark this checkbox if you want all of the replacement Sections' year installed to be marked as estimated.
3. After all of the data has been entered, activate the **Proceed** button in the popup window toolbar to copy the Sections. The copied Sections will be added to the database and appear on the inventory tree. Alternatively, if you do not wish to copy the Sections, activate the **Cancel** button instead.

Building Templates

Building Templates are explained in detail in the next section, starting with ["Working with Building Templates" on the next page](#).

Working with Building Templates

Building templates are one of BUILDER's methods for speeding up the process of initial inventory. They provide a convenient way to rapidly create Building inventory when:

- You have multiple Buildings with the same design and composition; or
- An existing template can be obtained that is similar to the Building you wish to create and populate with inventory.

A template stores the basic data about a generic Building that can be used to create many Buildings at one time using an automated process that copies the structure of the template to each desired Building.

Recommendation: The template feature is designed to be used as an initial step in the construction of your inventory database. However, in order to achieve the greatest benefit from using templates, you must be very familiar with BUILDER's approach to inventorying a Building. See ["Add a Building" on page 55](#) and ["About Identifying Systems, Components and Sections" on page 78](#) for important information regarding how Buildings and their template counterparts are structured in the database.

One of the most time-consuming aspects of inventory is the decomposition of a Building into its Systems, Components, and Sections. The Building Template feature is designed to ease the inventory development process in BUILDER.

If your physical inventory contains a number of Buildings that are essentially of the same design and composition, you can establish a template for that design to use as a "cookie cutter" and then apply an automated process with the template to create the matching Buildings in your BUILDER inventory with little additional effort. These matching Buildings can then be edited to reflect any individual features that differ from the template used to create them.

Additionally, due to the ability to import and export Building templates, you may be able to save time by either importing or finding in your template library an existing template that is similar to the Building you wish to create and populate with inventory.

What Is a Building Template?

A Building template looks very much like a Building in BUILDER. Every data element belonging to a template or one of its substructures has a corresponding data element in a Building. A template has general Building data such as use, size, and number of floors as well as a decomposition into Systems, Components, Sections (including Section Details). If the template is designated as family housing, then you may specify data about each dwelling unit regarding number of rooms and types and makes of appliances. A template does *not* contain data that is only known for each specific Building, such as its year of construction, its condition ratings, its costs, its location, etc.

Successful use of Building templates consists of three tasks:

1. Creating or importing a template;
2. Managing the template library; and
3. Using a template to create one or more new Buildings.

About Creating a Template

BUILDER offers multiple options for creating a template:

Option A: Import

You can [import templates](#) from another user's template library for use in your own library. This import capability is especially useful for military installations, which may have many Buildings constructed from a few standard service-wide designs.

For instructions, see ["Import Procedure" on page 161](#) under ["Import a Building Template" on page 160](#).

Option B: Use the Inventory of an Existing Building

Each Building in your inventory database is equipped with data elements comparable to those of a Building template. Therefore, you can use BUILDER's feature of copying a Building's inventory into a template to create a template quickly.

For instructions, see ["Copy Building Inventory to a Template" on page 163](#).


Option C: Enter Template Inventory

You can create a template by inputting each data element in much the same way that you create a Building.

For instructions, see ["Add a Building Template" on page 165](#).

About Managing the Template Library

The "Building Templates" window serves as a dashboard for most of the tasks you can do with respect to Building templates.



The screenshot shows the "Building Templates" window. At the top is a toolbar with icons for Close, Save, New, Delete, Comment, Import, Export, and Help. Below the toolbar is a section titled "Current Template Type" with a list containing "00009 - Utilities" and "00009 - Utilities(2)". To the right of this list is a form for editing a template. The form has a "Template Name:" field. Below it are three tabs: "Summary", "Systems", and "Additional Information". The "Summary" tab is active. It contains fields for "Building Use:" (a dropdown menu), "Construction Type:" (a dropdown menu with "Leased" selected), "Area:" (a text input with "0" and "SF" next to it), "Number of Floors:" (a text input with "1"), and "Child Occupied:" (a checkbox). At the bottom of the form is a button labeled "Housing Information".

An exception is creating a template by [copying the inventory of an existing Building](#). This is done from the inventory tree.

Using the "Building Templates" window, you can add, edit, delete, import, or export a template. The topic titled ["Manage the Template Library" on page 181](#) gathers together in one place a collection of links to these tasks.

About Using a Template to Create Inventory

Once a template is established, a Building with the same design can be created in an automated fashion by copying the template data into the appropriate Building data elements. This process can save hours of manual input if you have multiple Buildings for which the template applies.

To learn how to use a template to create or expand the data either for one Building at a time, or for multiple Buildings at the same time, see ["Add Building Inventory Using a Template" on the facing page](#).

You can also share your template with others using the feature ["Export a Building Template" on page 183](#).

Building Template Tasks

Building template tasks that can be performed are:

[Add Building Inventory Using a Template](#)

[Import a Building Template](#)

[Copy Building Inventory to a Template](#)

[Add a Building Template](#)
[Edit Building Template Data](#)
[Delete a Building Template](#)
[Manage the Template Library](#)
[Export a Building Template](#)

Add Building Inventory Using a Template

This topic describes how you can use an existing Building template to create new Buildings in your inventory. If there is no appropriately useful template in your template library, you can do one of the following:


- Copy and [edit](#) an existing template
 - [Import a template](#)
 - [Create a new template from an existing Building](#), or
 - [Create a new template](#) "from scratch" and enter inventory into it.
-

Building templates provide a convenient method for rapidly creating your Building inventory when you have multiple Buildings with the same design and composition. A template stores the basic data about a generic Building and can be used to create many Buildings at one time using an automated process that copies the structure of the template to each desired Building. For more information about templates, see ["Working with Building Templates" on page 150](#).


Add Building Template Inventory to One Existing Building

Once you have created a template, you can use it to create Building inventory. If you have an single existing Building and wish to expand its inventory using the template,

1. Select the Building in the inventory tree.
2. Take a look at the general information for the Building to make sure that the data for important properties such as Building Use, Area, and number of floors is correct.
3. If you still wish to expand its inventory using the template, do one of the following:
 - a. Right-click the Building whose inventory you wish to copy, and select the "Create Inventory Using Template" option.
 - b. Alternatively, activate the **Create Inventory Using Template** icon in the main toolbar, as shown below:



The "Apply Template" popup window will appear.



4. Select from the dropdown list the template you wish to apply to the Building, then activate **Proceed**. Alternatively, if you do not wish to apply the template

to the Building, activate the **Close** button.

WARNING: When you activate **Proceed**, existing general information for the Building *may or may not be replaced with the template data*:

- a. If no Systems have been created for a Building, the template's Systems, Components, Sections, and Section Details will be copied to it.
- b. However, if a Building already has Systems, the template's Systems structure will not be copied to it.

This same pattern applies to building dimensions, architects, contractors, and family housing records. That is, each of these template lists will be copied to a Building if and only if the Building's corresponding list is empty. Otherwise, the Building's existing list will be left unchanged.


Tip: If you are adding inventory to an existing Building, and Building Dimensions (**Additional Info** tab) have been populated by the template, double check these dimensions against the Area (**General Info** tab) that presumably was entered during Building creation, to see if they match.

When the template process is complete, a small popup window will announce "Application of template completed." You will be able to select each of the newly created Systems, Components, and Sections in the inventory tree and to edit the new data if adjustments need to be made. This same pattern applies to building dimensions, architects, contractors, and family housing records.


Add Building Template Inventory to Multiple Buildings

The most efficient way to use templates is to create the inventory for multiple similar Buildings at one time. To initiate the process of creating inventory for multiple Buildings using a template, follow these steps:

1. Navigate to the smallest organizational item (node) in the inventory tree that contains all of the Buildings that will have inventory created from the template. Then do one of the following:
 - a. Right-click on the node. Then select **Create Inventory Using Template** from the list of options.
 - b. Alternatively, select the node and then activate the **Create Inventory Using Template** button in the main toolbar.



The "Copy Template to Building(s)" popup window will appear.



2. In the **Select a template** field, activate the dropdown and select a template from the list.
3. When applying a template to multiple Buildings, you have two options to choose from:
 - a. Create new Buildings along with the template (continue reading at ["Option 1: Create New Buildings" on the facing page](#)).

- b. Alternatively, apply the template to multiple existing Buildings (continue reading at ["Option 2: Create Inventory for Existing Buildings" on page 159](#)).

Each option is described at a heading below.

Copy Template to Building(s)

Close Proceed Help

Select a template: 00009 - Utilities

☐ Create inventory for existing item ☒ Create new buildings

Add information below to create new buildings from the template.

Add new building Refresh

Number	Name	Year Built
No records to display.		

Option 1: Create New Buildings

The window shown above illustrates what happens when the **Create new buildings** radio button is activated. An information table, initially empty, will be created. Its headers are [Building] **Number**, [Building] **Name**, and **Year Built**. Year Built information may be entered later.

How to Add a Building to the Table

1. To add a new Building to receive template inventory, activate the **Add Building** button to add a new Building to the table. A new row in the table will be created and expanded to receive information.

Copy Template to Building(s)

Close Proceed Help

Select a template: 00009 - Utilities

☐ Create inventory for existing items ☒ Create new buildings

Add information below to create new buildings from the template.

Add new building Refresh

	Number	Name	Year Built
<input checked="" type="checkbox"/> <input type="checkbox"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>

- For each new Building, you need to assign a Building number and/or name, and put this information in the table.
- When you are finished with the entry, activate the blue checkmark icon at the left side of the row, to save the entry. Alternatively, to cancel and delete the entry before saving, activate the red circle with slash at the left side of the row.

Note: Activating **Add new building** during the entry process will also clear an unsaved entry.

- Repeat Steps 2 and 3 for each Building you wish to add and populate with template inventory.

Making Changes

- To edit an entry, activate the pencil icon, make the changes, then activate the checkmark at the left to save the changes.
- If you wish to delete any of the Buildings from the list, click the red "X" at the right side of its row.

Finalizing the Table of New Buildings

- Review the list of Buildings; make changes as needed until the table accurately lists all of the new Buildings you wish to create using the template.
- Activate the **Proceed** button near the top of the popup window. This starts the process that will create each Building and copy the template data to it.

Note: The Building creation process may take a minute or so for each Building, depending upon the complexity of the template's data structure.

Refining the Template-Installed Inventory (Important!)


9. When the process is complete, the new Buildings with their template-installed inventory will be available for editing. In particular, critical information that applies to each specific Building should be added immediately, especially the year of construction and dates associated with Sections because these data elements are used extensively in BUILDER's algorithms.
10. Finally, when you have completed your inventory input, you should use BUILDER's cost estimating tool (cost book) to establish current costs for all Buildings and their substructures.

Option 2: Create Inventory for Existing Buildings

If you choose to create inventory for existing Buildings (called "existing items" in the selection list),

1. Activate this option by selecting the **Create inventory for existing items** radio button at the "Copy Template to Building(s)" popup window.

The appearance of the "Copy Template to Building(s)" popup window will remain as shown below:



In this window, the complete list of Buildings "Available for Selection" at the selected inventory level will be displayed on the left.

2. Select the Buildings you want to expand using the selected template, and use the arrow buttons to move these Buildings to the "Selected Buildings" list on the right.
3. When the "Selected Buildings" list is complete, activate the **Proceed** button. Alternatively, if you wish to cancel, activate the **Close** button.

WARNING: When you activate **Proceed**, existing general information for each Building *may or may not be replaced with the template data*:

- a. If no Systems have been created for a Building, the template's Systems, Components, Sections, and Section Details will be copied to it.
- b. However, if a Building already has Systems, the template's Systems structure will not be copied to it.

This same pattern applies to building dimensions, architects, contractors, and family housing records. That is, each of these template lists will be copied to a Building if and only if the Building's corresponding list is empty. Otherwise, the Building's existing list will be left unchanged.

Tip: If you are adding inventory to an existing Building, and Building Dimensions (**Additional Info** tab) have been populated by the template, double check these dimensions against the Area (**General Info** tab) that presumably was entered during Building creation, to see if they match.

4. When the process is complete, edit each Building to add or verify critical data elements such as the year of construction, dates associated with Sections, and all quantities since these data elements are used extensively in BUILDER's algorithms.
5. Finally, when you have completed your inventory input, you should use BUILDER's cost estimating tool (cost book) to establish current costs for all Buildings and their substructures.

Import a Building Template

BUILDER provides three methods for creating a Building template: (1) importing; (2) [creating a template from an existing Building](#); or (3) [creating a template](#) from scratch and filling it with inventory. This topic explains the first method, importing a template.

About Importing Building Templates

Building templates provide a convenient method for rapidly creating your Building inventory when you have multiple Buildings with the same design and composition. A template stores the basic data about a generic Building and can be used to create many Buildings at one time using an automated process that


copies the structure of the template to each desired Building. For more information about templates, see ["Working with Building Templates" on page 150](#).

BUILDER allows for different users to share Building templates by importing and exporting individual templates. This capability is especially useful for military installations, which may have many Buildings constructed from a few standard service-wide designs.


Import Procedure

To import a template,

1. Open the template library from anywhere in the navigation tree by activating the **Building Templates** button on the main toolbar.




The "Building Templates" popup window will appear.



2. Select **Import** from the toolbar (see red box above).

The "Import Template" popup window will appear.



3. Activate the **Select** button in the "Import Template" popup, then browse to and select the template you wish to import into your template library. The name of the template will appear in the text box to the left of the **Select** button.
4. Finally, do one of the following:
 - a. Activate the **Import** button on the toolbar to import the template.
 - b. Alternatively, select the **Cancel** button to cancel the operation and return to the "Building Templates" window.

Before BUILDER imports your selections, checks of unique identifiers (internal data hidden from view) and template names are performed to avoid conflicts between your current template library and the template(s) being imported. Possible results are as follows:

1. If duplicate identifiers are found, the selected template will not be imported because it already exists in your library.
2. If you are attempting to import a template with the same name but a different unique identifier as an existing template in your library, then the importing process will stop with an error message indicating the problem templates. If you still wish to import the problem templates, change the names of the corresponding templates in your library so that they are distinct from the templates you wish to import. See ["Manage the Template Library" on page 181](#) for instructions regarding changing the name of a template in your library.

Note: The Building Use property of a template is dependent on the user category (Army, Navy, Air Force, Civilian, etc.). If you are managing an installation from one user category but importing Building templates from a different user category, then the template Building Use properties will not match any of the

Building Use categories in your list. When you view each imported template, the Building Use property will be blank. You will have to select an appropriate Building Use property from your list of uses for each imported template. The template name can be used help choose an appropriate use.

Copy Building Inventory to a Template


BUILDER provides three methods for creating a Building template: (1) importing; (2) creating a template from an existing Building; or (3) creating a template from scratch and filling it with inventory. This topic explains the second method, creating a template from an existing Building in your inventory.

Building templates provide a convenient method for rapidly creating your Building inventory when you have multiple Buildings with the same design and composition. A template stores the basic data about a generic Building and can be used to create many Buildings at one time using an automated process that copies the structure of the template to each desired Building. For more information about templates, see [Using Building Templates](#).


To create a template by copying a Building in your inventory,

1. Navigate to that Building in the inventory tree and do one of the following:
 - a. Right-click the Building, then select "Copy Inventory to New Template" from the options, as shown in the lower part of the screen shot above.
 - b. Alternatively, select the Building in the inventory tree. Then activate the **Copy Inventory to New Template** button on the main menu, above the navigation tree (see the red square in the screenshot

below):



The "Create New Template" popup window will appear.



2. Enter the name of new template, which must be unique among the templates in your library.

Specifications: The name is limited to 50 alphanumeric characters.

Best Practice Recommendation: Avoid using single quotes, double quotes, and ampersands. These characters can interfere with query formation.

Tip: If you expect to create a large template library, especially if you anticipate sharing your library with others or importing other user's templates, then the template name you choose should be sufficiently descriptive of the Building type to allow it to be safely and efficiently selected for use.

3. Finally, do one of the following:
 - a. Activate the **Proceed** button on the popup toolbar to create the new template.
 - b. Alternatively, activate **Close** if you wish to cancel the operation and close the popup.


Add a Building Template

BUILDER provides three methods for creating a Building template: (1) importing; (2) creating a template from an existing Building; or (3) creating a template from scratch and filling it with inventory. This topic explains the third method, creating a template from scratch and filling it with inventory.


To create a new Building template and add it to the template library, perform the following steps:

☐ **Initiate and Name a New Template**


1. From anywhere in the inventory tree, activate the **Building Templates** icon on the main toolbar.



The "Building Templates" popup window will appear.



2. Activate the **New** button on the toolbar of the "Building Templates" popup window shown above. *The "New Building Template" popup window will appear.*



3. Enter a name for the new Building template. This is the name that will appear in the template list and must be unique among the templates in your library.

Specifications: The name is limited to 50 alphanumeric characters.

Best Practice Recommendation: Avoid using single quotes, double quotes, and ampersands. These characters can interfere with query formation.

Tip: If you expect to create a large template library, especially if you anticipate sharing your library with others or importing other user's templates, then the name you choose here should be suf-

ficiently descriptive of the Building type to allow it to be safely and efficiently selected for use.

4. Activate the **OK** button on the popup. (Alternatively, activate the Cancel button to exit the operation without creating a new template.)

☐ **Enter Summary Tab Data**

Enter the following template data at the Summary tab:

- **Building Use.** From the dropdown list, select the Building Use that most closely matches the Building's use.
- **Construction Type.** Select from the dropdown list.
- **Construction Type.** Select from the dropdown list the construction type that matches the Building. Construction type options include:
 - Permanent
 - Semi-Permanent
 - Temporary
 - Leased
- **Area (Required).** Enter the gross area of the Building; this will be square feet (SF) or square meters (SM), depending on the unit of measure selected in the User Preferences.
- **Number of Floors (Required).** Enter the number of floors in the Building.
- **Child Occupied.** Mark this checkbox if the Building is child-occupied.

Save Summary Tab Data


Activate **Save** on the popup toolbar to save your changes.

☐ **Enter Systems Tab Data**

At the Systems tab is where you will enter the Systems, Components, Sections, and (as applicable) Section Details of your template. You will do this starting at the Systems level because the data at the Systems tab is arranged hierarchically, with Systems containing Components which contain Sections. Once a System is added, you may define Components for that System. Once a Component is added, you may define Sections for that Component. Decomposition follows the same pattern used for Buildings. However, Building-specific data (e.g. condition, age, year installed or built, year painted, and warranty dates and companies) is not used for templates.

Troubleshooting Tip: If the **Systems** tab is grayed out even though you saved all the required Summary information,

1. Activate **Save** on the popup toolbar.
2. Exit the popup (using the **Close** button or else the "X" in the upper right corner).
3. Re-activate the Building Templates icon.



4. Select your newly created and named template from the list. *All of the tabs should now display properly.*


You will be using the buttons to the right of each respective field to add or delete inventory to the template.

Add a System

See [Identifying Systems, Components and Sections](#) for a description of how Buildings are decomposed by System.

To add a System to the template,


1. Activate the **New** icon on the System line.



The "Add System" popup window will appear.

2. In the "Add System" popup, activate the dropdown list.
3. In the list, activate the desired System.

Note: Only one System at a time can be added to the template at a time using the "Add System" popup.



4. Activate the **Add** button on the popup toolbar. The popup will disappear, and the selected System will be displayed on the System line at the **Systems** tab.

Repeat the steps above for all desired Systems. Alternatively, you can leave the newly added System displayed in the "System:" field and proceed to entering one or more of its Components.

Tip: Once you have added all the Systems you wish, if you choose to enter each of them at this point, it's a good idea to activate **Save** on the "Building Templates" popup toolbar to lock in your changes.

Add a Component

See [Identifying Systems, Components and Sections](#) for a description of how Systems are decomposed by Component.

To add a Component to the template,

1. Make sure the appropriate System is displayed in the "System:" field.
2. Activate the **New** icon on the Component line. *The "Add Component" popup window will appear.*
3. In the "Add Component" popup, activate the dropdown list.

4. In the list, activate the desired Component .
5. Activate the **Add** button on the popup toolbar. The popup will disappear, and the selected Component will be displayed on the Component line at the **Systems** tab.

Note: The number of Sections contained in the component will be displayed beneath the "Component :" field.

Repeat the steps above for all desired Components. Alternatively, you can leave the newly added Component displayed in the "Component:" field and proceed to entering one or more of its Sections.

Add a Section

At the Section level, you will be entering the following data for each Section in your Building template:

- **Section Name.** Enter a name that will distinguish this Section from others in the same Component.
 - **Material Category.** Selected from the relevant dropdown list.
 - **Component Subtype.** Selected from the dropdown list. This will be a material (wood, concrete, etc.), or in the case of equipment it will be equipment type.
 - **Quantity.** Enter the number of items with the same specification that are contained in this Section.
-

See [Identifying Systems, Components and Sections](#) for a description of how Components are decomposed by Section.

To add a Section to the template,

1. Make sure the appropriate Component is displayed in the "Component:" field.
2. Activate the **New** icon on the Section line.

The "Add Section" popup window will appear.

3. In the "Add Section" popup, enter the Section name; select the equipment or material category from the dropdown; select the Component subtype from the dropdown; and enter the Quantity. The unit of measure for the Quantity will vary depending on the type of Section.
4. Activate the **Add** button on the popup toolbar. The popup will disappear, and the Section will be displayed on the Section line at the **Systems** tab.

Tip: When you've finished entering the Sections in a Component (or, alternatively, after entering each Section) it's a good idea to activate **Save** on the "Building Templates" toolbar to save your changes.

Enter Section Details

Additional data for the Section can be added by activating the **Details** button, which will launch the "Section Template Details" window.

To add Section Details,

1. Activate the **Add new record** button (located just above the Section Details table column headers).
2. Enter information. Each of the fields is described in [Edit Section Detail Data](#) in the inventory entry documentation. You can proceed left to right from one entry field to another using the **Tab** key, or right to left using **Shift-Tab**.
3. **IMPORTANT:** After entering the information, activate the checkmark icon, as shown below.

Note: You may need to scroll back to the left side of the table to see the checkmark icon.

Alternately, to exit the record without saving the data, activate the red **Cancel** icon next to the checkmark icon.

4. When finished with entries, or intermittently, activate **Save** on the "Building Templates" toolbar.

☐ **Enter "Additional Information" Tab Data**

Use the **Additional Information** tab to store additional Building data.

The data that can be recorded on this tab includes:

Dimensions

- **Perimeter.** Enter the linear measure of the perimeter of the Building.
- **Description.** Enter a description of the distinct areas of the Building you wish to add dimensions for. For example, you may list "East Wing/West Wing," or "Offices/Library/Warehouse," or "Public Areas/Secure Areas." Each description is limited to 50 alphanumeric characters. Use the **Add Dimension** and **Delete Dimension** buttons to add and delete items from the list.
- **Length.** Enter the length of the area identified in the description.
- **Width.** Enter the width of the area identified in the description.

Building Design

- **Architect.** Lists the architects of the Building. Add and delete names by using the adjacent buttons. Each architect's name is limited to 30 characters.
- **Contractor.** Lists the contractors of the Building. Add and delete names by using the adjacent buttons. Each contractor's name is limited to 30 characters.

☐ ***Save Building Template Data***

Before closing the "Building Templates" popup window, be sure to activate **Save** on the toolbar.


Edit Building Template Data

After a template has been added to the Building Templates library, it can be edited. It can also be enlarged by adding additional Systems, Components, or Sections. This topic explains how to edit the information in a Building template.


To edit a new Building template, perform the following steps:

☐ ***Open a Template***


1. From anywhere in the inventory tree, activate the **Building Templates** icon on the main toolbar.



The "Building Templates" popup window will appear.



2. Select a template from the list at the left.



☐ **Edit Summary Tab Data**

The following data appears at the **Summary** tab, and can be edited.

- **Name** (Required). The name that will appear in the template list and must be unique among the templates in your library. If you expect to create a large template library, especially if you anticipate sharing your library with

others or importing other user's templates, then the name you choose here should be sufficiently descriptive of the Building type to allow it to be safely and efficiently selected for use.

Specifications: The name is limited to 50 alphanumeric characters.

Best Practice Recommendation: Avoid using single quotes, double quotes, and ampersands. These characters can interfere with query formation.


- **Building Use.** Select the Building Use from the dropdown list that most closely matches the Building's use.
- **Construction Type.** Select the construction type from the dropdown list that matches the Building. Construction type options include:
 - Permanent
 - Semi-Permanent
 - Temporary
 - Leased
- **Area (Required).** The gross area of the Building.
- **Number of Floors (Required).** The number of floors in the Building.
- **Child-Occupied.** Mark this checkbox if the facility is child-occupied.

Save Summary Tab Data

Activate **Save** on the "Building Templates" toolbar if you make changes at the **Summary** tab.

☐ **Edit Systems Tab Data**

The **Systems** tab gives you access to the data regarding the decomposition of the Building into Systems, Components, and Sections.



At the **Systems** tab is where you will enter or edit information about the Systems, Components, Sections, and (as applicable) Section Details of your template. You will do this starting at the System level because the data at the **Systems** tab is arranged hierarchically, with Systems containing Components which contain Sections.

Use the buttons to the right of each respective dropdown list to add or delete inventory to the template. Once a System is added, you may define Components for that System. Once a Component is added, you may define Sections for that Component. This follows the same pattern used for Buildings, except that Building-specific data (e.g., condition, age, year installed or built, year painted, and warranty dates and companies) is not used for templates. See [Identifying Systems, Components and Sections](#) for a description of how Buildings are decomposed by System.

System Level

Add a System


To add another System to the Building template, follow the instructions at ["Add a System" on page 168](#) in the topic ["Add a Building Template" on page 165](#).

Edit System Contents

To change the contents of a System that already exists in the template, you will need to select that System at the System line; then select or add the appropriate Component on the Component line; then proceed as necessary through the levels to the Section line and (if applicable), the **Details** button to make the appropriate additions or changes.

Delete a System

To delete a System, select it from the dropdown list at the System line; then activate the **Delete** icon at the right of the System line.



Component Level

Add a Component

To add another Component to the Building template, follow the instructions at ["Add a Component" on page 169](#) in the topic ["Add a Building Template" on page 165](#).

Edit Component Contents

To change the contents of a Component that already exists in the template, you will need to select that Component at the Component line; then select or add the appropriate Section on the Section line; and (if applicable), activate the **Details** button to make the appropriate additions or changes.

Delete a Component

To delete a Component, select it from the dropdown list at the Component line; then activate the **Delete** icon at the right of the Component line.



Section Level

Add a Section

To add another Section to the Building template, navigate to the Component it will be contained in; then follow the instructions at ["Add a Section " on page 170](#) in the topic ["Add a Building Template" on page 165](#).

Edit Section Contents

Change Quantity

To change the quantity of a Section,

1. Highlight the quantity in the Quantity box;
2. Make the desired change; then
3. Activate **Save** on the "Building Templates" menu bar.


Change Section Details

To change the Section's Section Details,

1. Activate the **Details** button; then
2. Make the desired additions or changes. For more detailed instruction, see [Section Details](#).

Delete a Section

To delete a Section, select it from the dropdown list at the Section line; then activate the **Delete** icon at the right of the Section line.



The screenshot shows a software interface for editing a section. It includes a dropdown menu labeled 'Section:' with the text 'Mail compartments C103006 SHELVING General'. Below this is a 'Quantity:' field with the value '6' and the unit 'LF'. There is a checkbox labeled 'Painted/Coated' which is currently unchecked. To the right of the quantity field is a 'Details' button. Above the 'Details' button is a small icon of a document with a red 'X' over it, which is the delete icon. The entire interface is set against a light blue background.

☐ **Save Systems Tab Data**

Activate **Save** on the "Building Templates" toolbar to save the changes made at the **Systems** tab.

☐ **Edit "Additional Information" Tab Data**

The **Additional Information** tab provides a location to store additional Building data.

Building Templates

Close Save New Delete Comment Import Export Help

Current Template Type

00009 - Utilities

Template Name: 00009 - Utilities

Summary Systems **Additional Information**

Dimensions

Perimeter LF

Add

Description	Length	Width
No records to display.		

NOTE: Length and width are measured in linear feet.

Building Design

Architect: [Dropdown] [Add] [Delete]

Contractor: [Dropdown] [Add] [Delete]

The data that can be recorded and edited at this tab includes:

Dimensions

- **Perimeter.** Enter the linear measure of the perimeter of the Building.
- **Description.** Enter a description of the distinct areas of the Building you wish to add dimensions for. For example, you may list "East Wing/West Wing," or "Offices/Library/Warehouse," or "Public Areas/Secure Areas." Each description is limited to 50 alphanumeric characters. Use the **Add Dimension** and **Delete Dimension** buttons to add and delete items from the list.
- **Length.** Enter the length of the area identified in the description.
- **Width.** Enter the width of the area identified in the description.

Building Design

- **Architect.** Lists the architects of the Building. Add and delete names by using the adjacent buttons. Each architect's name is limited to 30 characters.
- **Contractor.** Lists the contractors of the Building. Add and delete names by using the adjacent buttons. Each contractor's name is limited to 30 characters.


Save Additional Information Tab Data

Activate **Save** on the "Building Templates" toolbar if you make changes at the **Additional Information** tab.


Delete a Building Template

To delete a Building template,

1. From any location in the inventory tree, activate the **Building Templates** icon on the main toolbar.




The "Building Templates" popup window will appear.



2. Select from the list of templates the one you wish to delete.

3. While that template is highlighted, activate the **✖ Delete** button in the popup toolbar. *A confirmation popup will appear.*



4. Do one of the following:
 - a. Activate the **OK** button in the confirmation popup to delete the template. The list of templates on the left side of the "Building Templates" window will refresh after the deletion.
 - b. Alternatively, activate **Cancel** in the confirmation popup to cancel the operation and return to the "Building Templates" window.


Manage the Template Library

This topic provides an overview of capabilities you can initiate at the "Building Templates" window in order to add to, manage, import to, and export from your library of Building Templates held in BUILDER.


BUILDER stores all of the Building templates in your database in a template library. From the template library, you are able to manually add, edit, and delete templates in your database, as well as import and export templates.

Open the Templates Window

To manage the template library, activate the **Building Templates** icon on the main toolbar. This can be done from any location in the inventory tree.



The "Building Templates" popup window will appear.



On the left side, the Building Templates window lists the current templates in the library. On the right side, it shows the data for the selected template. The data shown at the different tabs are described in the topics ["Add a Building Template" on page 165](#) and ["Edit Building Template Data" on page 173](#).

Toolbar Options

Options on the "Building Templates" toolbar are:

- **Close**. Closes the "Building Template" popup window.
- **Save**. Saves changes made to the Building templates.
- **New**. Initiates creating a new template "from scratch" where you can enter inventory detail. (See ["Add a Building Template" on page 165](#).)
- **Delete**. Deletes the currently selected template.
- **Comment**. Allows you to add, edit, and view comments for the template.
- **Import**. Allows you to [import templates](#) from other sources.
- **Export**. Allows you to [export templates](#) to other sources.
- **Help**. Displays context-sensitive location in the online Help documentation.

Building Template Tasks

Operations that can be performed on Building templates are:

["Import a Building Template" on page 160](#)

["Copy Building Inventory to a Template" on page 163](#)

["Add a Building Template" on page 165](#)

["Edit Building Template Data" on page 173](#)

["Export a Building Template" below](#)

["Delete a Building Template" on page 180](#)

["Add Building Inventory Using a Template" on page 153](#)

Additional useful information can be found here:

["Working with Building Templates" on page 150](#)

Export a Building Template

This topic explains how to export a template in order to be able to share it with others or to use it in a different instantiation of BUILDER.

About Exporting Building Templates


Building templates provide a convenient method for rapidly creating your Building inventory when you have multiple Buildings with the same design and composition. A template stores the basic data about a generic Building and can be used to create many Buildings at one time using an automated process that copies the structure of the template to each desired Building. For more information about templates, see ["Working with Building Templates" on page 150](#).

BUILDER allows for different users to share Building templates by importing and exporting individual templates. This capability is especially useful for military installations, which may have many Buildings constructed from a few standard service-wide designs.


Export Procedure

To export a template,

1. From anywhere in the inventory tree, activate the **Building Templates** button on the main toolbar.



The "Building Templates" popup window will appear.



2. To export a template, highlight a template name in the listing on the left side of the Building Template window.
3. Select **Export** from the toolbar.
4. After the template has been successfully exported, you will be asked if you want to (a) save or (b) open the exported template.

- a. If you choose to save the template, you will be prompted for a path and file name for the exported template. The saved exported template can then be sent to other BUILDER users to be utilized in their template libraries.
- b. If you choose to open the exported template after the export is complete, the template will open as a XML document.

Reports


Generate a Report

BUILDER™ offers a number of standard reports. These reports can be viewed, printed, or exported to electronic files of several formats.

How To Generate and View a Report

Note: This topic explains how to access reports from the toolbar at the top of the Content Area, not from the main toolbar.


To view a report,

1. In the navigation tree in the left window pane, navigate to and select the node for which you want to generate a report.
2. Click the **Reports** button  in the local toolbar.

Note: The **Reports** button is available if you are in the inventory tree or condition tree, but not when you are in the functionality navigation tree.

Note: Selected Standard reports are also available from the **Reports** button on the main menu bar.

3. *For Inventory only:* Select either **Standard** or **Custom** (where available) reports:



The "Reports," "Standard Reports," or "Custom Reports" window will appear. This window contains a dropdown list of reports, which includes only reports applicable to that level. Additionally, the report will only show data for the current mode you are in. For example, if you activate the Reports button while in inspection mode, only inspection related reports will be displayed.

4. Activate the dropdown arrow in the bar, and select the desired report from the dropdown list.
5. After you have a report selected, click the **View Report** button in the popup window toolbar; or, if you have selected a Custom Report, click on the **Run Report** button in the popup window toolbar.

The selected report will launch in the Report Viewer window or in the Custom Reports window. The image below shows a sample report in the Report Viewer:

The screenshot shows the 'Report Viewer' application window. The title bar reads 'Report Viewer'. The toolbar includes 'Close', 'Export Type' (set to PDF), 'Export Report', and 'Help'. Below the toolbar is a secondary bar with icons for file operations, a page indicator '1 / 1', a zoom level of '50.7%', and buttons for 'Fill & Sign' and 'Comment'. The main content area displays a report titled 'Direct Condition Rating Inspection Report by Component' from 'SMS'. The report is for 'Sample Site 02 (013)' and '00001 - Flight'. It lists two components: 'A10 FOUNDATIONS' and 'B10 SUPERSTRUCTURE'. Each component has a table of inspection data including 'Last Inspection Date', 'Inspector', 'Condition Rating', 'Used Sampling?', and 'Inspection Source'. The report is dated 'February 01, 2016' and is 'Page 1 of 1'.

System	Component	Section Description	Quantity (UM)
A10 FOUNDATIONS	A1010 STANDARD FOUNDATIONS	Beam A101001 WALL FOUNDATIONS Grade Beams	600 (LF)
Last Inspection Date: 01-Feb-2016 Inspector: Sample User Inspection Comments: Degraded foundation. A/JF.			
B10 SUPERSTRUCTURE	B1010 FLOOR CONSTRUCTION	Auditorium floor B101004 INCLINED AND STEPPED FLOORS	600 (EA)
Last Inspection Date: 01-Feb-2016 Inspector: Sample User Inspection Comments:			

Export a Report


Export a Standard Report

To export a standard report, first follow the steps in ["Generate a Report" on page 186](#). Then

1. In the Report Viewer toolbar, select the Export Type: **PDF**, **Excel**, or **Word (RTF)**.

CAUTION: Not all reports have been adapted to the Excel format.

2. In the Report Viewer toolbar, click **Export Report**.
3. At the bottom of the screen, you will be queried whether you want to save the report:




4. Click the down arrow to the right of the **Save** button.
5. Select **Save as**.
6. In the Save As popup window, browse to the desired location where you wish to save the report.
7. Name the report in the File name: bar; then activate **Save** (lower right).
8. After the download is complete, the bar at the bottom of the screen will give you the option to open the report you just saved, to open the folder, or view downloads. If none of these are needed, click the "x" at the right side of the query bar.
9. If you want to open the report to view it, select **Open**. When you close the viewing window, you will be back at the Report Viewer window.
10. Click **Close** to close the Report Viewer window.

Export a Custom Report

To export a custom report, first follow the steps in ["Generate a Report" on page 186](#). Then

1. With the desired report showing in the Custom Reports popup window, activate the **Save** icon.
2. Select the desired export format from the options in the dropdown list.
3. At the bottom of the screen, you will be queried whether you want to save the report:



4. Click the down arrow to the right of the **Save** button.
5. Select **Save as** (or **Save and open**).
6. In the Save As popup window, browse to the desired location where you wish to save the report.
7. Click the **Save** button.

APPENDIX A: About Rollup

Automated Rollup

BUILDER automatically "rolls up" inventory, condition, and functionality information nightly. (For installations with U.S. Army Corps of Engineers support service, this begins at about 6:00 p.m.). Starting at the Section level, aggregated Section-level information in each Component is recorded for the Component; aggregated Component-level information is recorded for each System; aggregated System-level information is recorded for each Building, and so forth up the entire inventory tree.

Manual Rollup

Users can perform a manual rollup at the Building, Complex, or Site level (subject to permissions). A user-initiated manual rollup is limited in scope to the Building, Complex, or Site where the rollup is run, including all of its sublevels of inventory. A manually initiated rollup of the entire navigation tree can only be performed by a BUILDER Administrator.

What does a Rollup Do?

The following (subcategorized) processes will occur during the rollup:

Inventory

Inventory-related processes accomplished by a rollup are as follows:

- The current remaining service life (RSL) is estimated for all Sections.
- RSL information is reflected upwards through the Inventory tree.
- Plant Replacement Value (PRV) is updated at all levels. For example, if new Sections, Components, or Systems have been added to a Building, its PRV will increase.

Condition Assessment

Condition assessment-related processes accomplished by a rollup are as follows:

- **Components:** The current CI for each Component (BCCI) is estimated by calculating the average of its Component-Sections' condition indices, weighted by replacement cost.
- **Systems:** The current CI for each System (SCI) is estimated by calculating the average of its Components' condition indices, weighted by replacement cost.

- **Buildings:** The current condition index for each Building (BCI) is estimated by calculating the average of its Systems' condition indices, weighted by replacement cost.
- **Complexes, Sites, and Organizations:** The current condition index for all Complexes, Sites, and Organizations is estimated by calculating the average of their Buildings' condition indices, weighted by replacement cost.

FCI

In addition to calculating and rolling up BUILDER condition indexes, rollup also calculates the financially oriented Facility Condition Index (FCI):

- The FCI is estimated for all Buildings using the formula $FCI = (1 - \text{\$current repair needs} / \text{\$PRV}) \times 100$, obtaining the dollar amount of repair needs from BUILDER work items.
- The FCI is estimated for all Complexes, Sites, and Organizations, using the formula $FCI = (1 - \text{\$current repair needs} / \text{\$PRV}) \times 100$, obtaining the dollar amount of repair needs from BUILDER work items for the Complex, Site, or Organization.

Functionality and Performance

Processes accomplished by a rollup related to functionality and performance are:

- The latest functionality assessment records are retrieved. Based on the results of the assessments, the FI is determined for each Functional Area and applicable Building.
- The current FI is estimated for all Complexes, Sites, and Organizations by calculating the average of their Buildings' FIs, weighted by replacement cost.
- The current PI is estimated for each Building, using a weighted combination of the Building's CI and FI.
- The current PI is estimated for all Complexes, Sites, and Organizations by calculating the average of their Buildings' PIs, weighted by replacement cost.

After the rollup process completes, the "Manual Condition Rollup" popup window (or the "Progress" window, in case of a full-tree rollup performed by a BUILDER administrator) will close. You will be returned to the originating BUILDER screen. Updated condition colors (red, amber, green) will be displayed for all elements in the inventory, condition, and functionality trees, and recalculated current condition indices will be shown in the relevant information screens.

Appendix B: Facility Condition Index

This topic defines and discusses the BUILDER term "Facility Condition Index." The definition of this term changed starting with BUILDER Version 3.3.10, from the definition used by the Federal Real Property council to a formula compatible with other BUILDER indexes by producing a value on a 0-100 scale where a higher number indicates better condition.

Note: In ROOFER, "FCI" stands for Flashing Condition Index, not Facility Condition Index.

The *Facility Condition Index* (FCI) is a financially based index showing the relationship between the cost of deferred M&R work and the Plant Replacement Value (PRV). BUILDER uses the following formula for FCI, which produces a value between 0 and 100. A higher value indicates better condition:

$$FCI = [1 - (\$current\ repair\ needs / \$PRV)] \times 100,$$

where *\$current repair needs* represents the total cost of [current repair needs](#) and \$PRV is the Plant Replacement Value. See the Definition section below for an explanation of what is and is not included in *\$current repair needs*.

IMPORTANT: Some organizations define FCI differently, as [\$cost of *all* deferred M&R work] / \$PRV, which should yield a result less than or equal to 1.0 if policy dictates that repair costs for an asset must not exceed the asset's replacement value.

Best Practice Recommendation: Regenerating the work plan before calculating the dollar amount of current repair needs will give you the most accurate result.

Definition of *\$current repair needs*

\$current repair needs includes:

- Work that became a requirement in the current fiscal year (work items of the current fiscal year).
- Work that became a requirement in a past fiscal year, but has not yet been performed and is still a requirement.

\$current repair needs does not include:

- Work that is currently funded for completion.
- Work scheduled for future years.

Glossary

Administrator

A user with Administrator Role can administer users, assign users to Roles, and change software configuration settings.

Area Cost Factor

A multiplier that adjusts national average labor/material/equipment costs to local costs. For example, in a remote area with high shipping costs and a tight labor market, the Area Cost Factor might be 1.3. The Area Cost Factor is generally a number between 0.8 and 1.2 for continental U.S. locations, but it can be even greater than 2.0 in high-cost geographic locations.

ATFP

Antiterrorism Force Protection

BCCI

Building Component Condition Index - a condition rating for the target Building Component. For each Component, the BCCI is computed by taking the average of its Sections' CIs, weighted by replacement cost

BCI

Building Condition Index - a condition rating for the overall Building. For each Building, the BCI is computed by taking the average of its Systems' CIs, weighted by replacement cost.

BFI

Building Functionality Index - computed from the results of a functionality assessment.

BPI

Building Performance Index - a measure of a Building's overall performance, derived from a weighted combination of the BCI and BFI, where the lower of the two values is given two-thirds of the weight and the higher of the two values is given one-third of the weight. If no functional assessment has been performed, the BFI is assigned a value of 100.

BRED

BUILDER Remote Entry Database (BuilderRED)

BUR

Built-up Roofing

CCI

Coating Condition Index

CI

Condition Index

CII

Component Importance Index. This index may be used to rank the relative importance of components against one another. An example of its use is in Work Configuration to hold different Component-Sections to different thresholds, or to prioritize them differently based on relative importance.

CM

Corrective Maintenance

CMC

Component material category

Complex CI

Complex Condition Index - a condition rating for the target Complex. The Complex CI is computed by taking the average of the BCIs of each Building in the Complex, weighted by replacement cost.

CSCCI

Component Section Coating Condition Index

CSCI

Component-Section Condition Index - a condition rating for the target Component-Section. The CSCI is computed by using the assessment data to calculate a deduct value, then subtracting that deduct value from the maximum possible rating of 100. The deduct value computation differs for each condition assessment method.

Equipment Make

The series, collection or line that the equipment is included in, if applicable. For example, a Trane® gas furnace might be designated as S9V2, XC95, or XV95.

ERDC-CERL

U.S. Army Engineer Research and Development Center, Construction Engineering Research Laboratory

ESC

Emergency Service Call

FAFI

Functional Area Functionality Index

FCA

Facility Condition Assessment

FCI (ROOFER)

Flashing Condition Index. In ROOFER the FCI, as determined by inspection and/or algorithm, is used in the calculation of the Roof Condition Index (RCI).

FEMA

Federal Emergency Management Agency

FI

Functionality Index

HABS

Historic American Buildings Survey

HAER

Historic American Engineering Record

HPSB

High Performance and Sustainable Building

IAQ

Indoor air quality

ICI (ROOFER)

Insulation Condition Index

Icon Color

Icon color designates the condition of an SMS element, or whether it has yet been inspected at all. If the icon is gray, no inspection has been performed. Red, amber, and green icons indicate a red-, amber-, or green-level average condition of all sublevels below the designated icon, assuming that a rollup has been performed.

Inspection Supervisor

A user with Inspection Supervisor Role has all the rights of an Inspector, and can also create inspection schedules

Inspector

Person who performs inspections to be input into BUILDER or ROOFER. As a permissions Role, Inspectors can input and edit inventory information in Inventory mode, and can input and edit inspection information from the Condition Assessment screen.

Inventorior

A user with Inventorior Role can add and edit records below the Building level.

KBI

Knowledge-Based Inspection

M&R

Maintenance and Rehabilitation

Master Planner

A user with Master Planner Role has all the rights of a Work Planners, and can also generate multi-year work plan scenarios, and edit any and all data saved by other users of the program. Master Planner is the highest level of user privileges.

MBH

1,000 BTU/hour

MCI (ROOFER)

Membrane Condition Index

MDI

Mission Dependency Index - measures the relative importance of a Building

MOA

Memorandum of Agreement

MOU

Memorandum of Understanding

NAGPRA

Native American Graves Protection and Repatriation Act

PCBs

Polychlorinated biphenyls

PCI (ROOFER)

Panel Condition Index. The PCI is one component making up the Roof Condition Index (RCI) for a metal panel roof, along with the Insulation Condition index (ICI) if applicable, and the Flashing Condition Index (FCI).

PI

Performance Index. See also: BPI. The Performance Index is a weighted combination of the CI value and the FI value, with the lower of the two values being given two-thirds of the weight and the higher of the two values being given one-third of the weight.

PM

Preventative Maintenance

PM inspection

Preventative maintenance inspection

POM

Program Objectives Memorandum

PRV

Plant Replacement Value. For an inventory item above the Building level, this number will be the aggregate of the PRV of all Buildings included in that item.

RCI (ROOFER)

Roof Condition Index

RML

Remaining Maintenance Life

RPIE

Real property installed equipment

RSL

Remaining Service Life

SCCI

Subcomponent condition index, produced when using direct rating in a preventative maintenance (PM) inspection

SCI

System Condition Index - a condition rating for a Building System. For each System, the SCI is computed by taking the average of its

Components' CIs, weighted by replacement cost.

SCI (ROOFER)

Substrate Condition Index

Site CI

Site Condition Index - a condition rating for the target Site. The Site CI is computed by taking the average of the BCIs of each Building at the Site, weighted by replacement cost.

SMS

Sustainment Management System

SOW

Statement of Work

SP

Single Ply

SR

Shingle Roofing

SRM

Sustainment, Restoration, and Modernization

STIG

Security Technical Implementation Guide (DoD)

Stop gap repair

Repair that will keep the CI at its current level for one year, without further deterioration.

SUCI

Sample Unit Condition Index

UM

Unit of Measure. Examples: Each; LF (linear feet)

Work item

A discrete work activity applied to a single managed object such as a Component-Section, intended to improve its life cycle performance.

Work plan

A multi-year collection of work items and/or projects planned for a Site or Organization.

Work planner

A user with Work Planner Role has all the rights of an Inspection Supervisors, and can also create and edit work plans, standards, policies, prioritization schemes, and RSL and cost books.

Work project

A grouping of work items to be managed, prioritized, funded, and executed as a single work effort.

Index

A

Add

- Building 55
- Building inventory using Building template 153
- Building template 165
- Complex 40
- Component 95
- Organization 16
- Section 104
- Section Detail 119
- Site 26
- System 86

Area Cost Factor 31

Attach a file

- to a Building 69
- to a Complex 50
- to a Component 97
- to a Section 107
- to a Section Detail 120
- to a Site 36
- to a System 88

B

BCI 62

BFI 63

BPI 63

BRED See **BuilderRED**

BUILDER Remote Entry Database (BRED) See **BuilderRED**

BuilderRED

- capabilities 128
- export data to 128
- import data from 138
- import images from 140
- rollup after import 141

Building 72

- about 10, 53
- add 55
- child-occupied 63
- condition index 62
- copy 145
- current status 72
- delete 70
- edit 59
- edit additional data 64
- functionality index 63
- Mission Dependency Index (MDI) 62, 72
- name 56
- number 56
- performance index 63
- replacement cost 61
- status 72
- Use category 57

Building inventory

- add using templates 153

Building status

- using to track non-current Buildings 75

Building status property 57

Building template

- add 165

- add Building inventory using 153
- copy Building inventory to 163
- definition 151
- delete 180
- edit 173
- export 183
- import 160
- manage the template library 181
- overview 150

Building templates 153, 163

Building Use 60

Building Use category

- assign to Building 57

C

Child-occupied facility 63

Classification of building subparts 83

Complex

- about 10, 39
- add 40
- delete 51
- edit 45

Component

- about 11, 78, 95
- add 95
- delete 102
- edit 101
- view 99

Component-Section **See Section**

Component subtype 105

Construction type 61

Copy 147

Building 145

Building inventory to template 163

inventory to another Building 145

location factors 29

Sections 147

Copyright 2

CSCI

current estimated 110

latest inspection 110

Current status (Building) 72, 75

D

Delete

Building 70

Building template 180

Complex 51

Component 102

Organization 23

Section 115

Section Detail 126

Site 38

System 93

Disclaimer 2

E

Edit

additional Building inventory data 64

Building 59

Building template 173

Complex 45

- Component 101
- Organization 19
- Section 109
- Section Detail 123
- Site 29
- System 92
- Embedded Building Models 143
- 'Estimated' checkbox 106
- Estimating Building Inventory 143
- Export
 - BuilderRED data 128
 - Building template 183
 - report 188

F

- Facility Condition Index (FCI) 59, 192
- FCI 63, 192

H

- Historic (Building property) 63

I

- Import
 - BuilderRED data 138
 - Building template 160
 - images from BuilderRED 140
- Inheritance 26
- Inspection tools *See also* **BuilderRED**
- Inventory
 - copy 145
 - planning 9

rollup 12
suggestions 80

L

Location factors 31
copy 29
lookup location 29-30

M

Material/equipment category 105
MDI 62
Mission Dependency Index (MDI) 72

N

NAVFAC UNIFORMAT 83

O

Organization
about 9
add 16
delete 23
edit 19
overview 15

P

Planning inventory 9
Property inheritance 26
PRV 20, 32

R

Reference settings 21, 33

Replacement cost

Building 61

Report

export 188

generate 186

select 186

view 186

Reports

Component level 103

Section Detail level 126

Section level 116

System level 93

Rollup

inventory 12

S

Section

about 11, 79, 104

add 104

delete 115

edit 109

Section Detail

about 119

add 119

delete 126

edit 123

view 124

Site

about 10

add 26

delete 38

- edit 29
- number of Sites to establish 25
- overview 25
- Site content area toolbar 29
- Subcomponent 11
- System
 - about 10, 78, 86
 - add 86
 - delete 93
 - edit 92
 - view 90

T

- Template library 181
- Toolbar
 - Building content area toolbar 53
 - Building templates popup toolbar 182
 - Complex content area toolbar 45
 - Organization content area toolbar 19
 - Section content area toolbar 114
 - Section Detail content area toolbar 123
- Track non-current Buildings 75

U

- UNIFORMAT 10, 83

V

- View
 - Component 99
 - report 186
 - Section Detail 124

System 90

W

Welcome 3

